

EasyCAD v7.5x



EasyCAD v7 software designed and written by

**Michael Riddle
Evolution Computing, Inc.**

EasyCAD v7 manual written by

**Dan Ichikawa, John Steen
Evolution Computing, Inc.**

**EasyCAD is a registered trademarks of
Evolution Computing Inc.**

AutoCAD is a registered trademark of Autodesk, Inc.

**Microsoft is a registered trademark, and Windows 95®,
Windows 98®, Windows 98® Me Windows 2000®,
Windows NT® 4.0 and Windows XP® are trademarks
of Microsoft Corporation.**

**Software and documentation © 1986-2009
by Evolution Computing, Inc.
All rights reserved. Published July, 2004.
Produced in the United States of America.**

**Information in this document is subject to change without notice. This
document or any part thereof may not be reproduced, stored, or
transmitted in any media, electronic or mechanical, for any purpose,
without express written permission from Evolution Computing, Inc.**

COPYRIGHT NOTICE PER INTERNATIONAL CONVENTION

Warranty and License Agreement

For your convenience, the enclosed **EasyCAD® v7** for **Windows 95®**, **Windows 98®**, **Windows 98® Me**, **Windows 2000®**, **NT® 4.0** and **Windows XP®** software is supplied on media that is not copy-protected. The program and its intellectual property, however, are protected by both United States Copyright Law and international copyright treaties. This software program is licensed, not sold.

This means you are free to use the software on a single machine (CPU) at a single site and to make archival backups, for your personal use only, as protection from disk or computer failure. The licensed user of this program may make a second copy for his or her exclusive use on a portable computer. We ask that you not abuse this trust by making copies of either the software or the manual for use by others.

Use on networks is limited to storage or installing a copy of the program on a storage device, such as a network system, used only to install or run this program on the licensed user's computer over an internal network; however, a dedicated license is required for each separate computer or workstation on which the program is installed or run from the storage system. A single license for the program may not be shared or used concurrently on different computers or workstations.

If you transfer your rights to this program, you may do so permanently, provided you retain NO copies, and you transfer all components; printed materials, media, and registration of past and present versions of this software. You may not lend, lease, or rent this software program or its components.

For product marked "Educational", you must be a qualified educational user to install and use this program. If the product is marked Not for Resale or NFR, you may not sell, resell, or transfer this program or any of its components.

Please help us avoid the need for software protection by respecting the major investment of time and money that goes into developing quality software for you.

Evolution Computing, Inc. warrants that your **EasyCAD v7 for Windows 95®, Windows 98®, Windows 98 ME®, Windows 2000®, Windows NT® and Windows XP®** software will perform substantially in accordance with the included written materials for a period of **ninety (90) days from the date of receipt**. In the event of defects in the distribution diskettes or documentation, **Evolution Computing, Inc.** will replace them on request. In the event of deviations in the software, **Evolution Computing, Inc.** will make a reasonable effort to bring the software into conformance with the manual and to provide you with a corrected version as soon as possible.

This warranty is void if the software failure has resulted from abuse, accident, or misapplication. **Evolution Computing, Inc.**'s liability is limited to refund of the money paid for the software, and in no event will Evolution Computing, Inc. be liable for any indirect or consequential damages that may arise (including damages for loss of business profits, business information, or other pecuniary losses).

Remember, you may make copies of this software for archival backup purposes only.

US GOVERNMENT RESTRICTED RIGHTS. The software program and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software—Restricted Rights at 48 CFR 52.227-19, as applicable. The Contractor/manufacture is **Evolution Computing, Inc., 7000 North 16th Street, Suite 120 - #514, Phoenix, AZ USA 85020**

SALES: (800) 874-4028
TECHNICAL SUPPORT: (480) 967-6967

Evolution Computing Inc.
7000 North 16th Street
Suite 120 - #514
Phoenix, AZ 85020

Table of Contents

Warranty and License Agreement	xvii
---	-------------

Introduction	1
---------------------------	----------

The Internet	1
Manual Conventions	2
System Requirements:	3
Installing EasyCAD v7	3
Support	4
Key Features	5
EasyCAD Command Menus	7

Communicating with EasyCAD v7	8
--	----------

The EasyCAD v7 Screen	9
The Command Prompt	10
Using the menus	11
The Button Bar	12
Icon bars	13
Standard Icon Bar	14
Color Bar	15
Status Bars	16
Multiple Drawing Windows	20
Default Values	25
Message Boxes	25
Dynamic Cursors	25
Selecting Entities	26
Entity Selection options	27
Advanced Entity Selection	29
Entity Selection popup menu	30

General Concepts	33
-------------------------------	-----------

Entities	34
Units	35
Coordinates	36
Entering Coordinates	36
Bearings and Angles	38
DMS and Surveyor Bearings	38
Entering Distance Values	39
Entering Displacement Values	39
Navigating the Drawing Screen	40
Layers	41
Precision Drawing	42

File Commands	43
New Drawing	43
Open	44
Files Icon Bar	45
Open Prior	45
Save	46
Save As	47
Restore	48
Discard	48
Print Setup	49
Text Page Setup	49
Print	50
Print Drawing dialog box options	50
Bookmark commands	53
Edit Bookmarks	54
Search Files	56
Index	57
File Notes	58
Convert Files	59
Menu	60
Set Menu	61
Script	62
Template	63
AutoSave	64
Exit	65
 Clip Commands	 66
Undo	67
Redo	68
Redo All	68
Flip	68
Copy	69
Cut	69
Paste	69
Clip Options	70
 View Commands	 72
Redraw	73
Background	73
Change Origin	74
View Names	75
Set View Name	76
Dynamic Pan	77
Pan View	78
Zoom Window	78
Zoom Center	79

Zoom Out	79
Zoom Width	80
Zoom Height	80
Zoom Extents	81
Zoom Named	81
Zoom Last	81
Zoom Text	82
Draw Commands	83
Line	84
Lines > Double Lines	85
Lines > Perpendicular	86
Lines > Perpendicular at Length	87
Lines > Tangent to Two Entities	88
Circles > Center and Point On	89
Circles > Diameter and Center	90
Circles > Radius and Center	91
Circles > 2 Point Circle	92
Circles > 3 Point Circle	93
Circles > Tangent to 2 entities	94
Circles > Tangent to 3 entities	94
Circles > Donut	95
Arcs > Center, Start, End	96
Arcs > Center and Radius	97
Arcs > Start, Middle and End	99
Arcs > Start, End and Bulge	100
Arcs > Chained Arcs	101
Arcs > Wedge (Pie Section)	102
Single Line Text	104
Text > Multi Line Text	105
Edit Text dialog	106
Text > File Text	107
Text > Current Date	107
Text > Current Time	108
Text > Current Drawing	109
Text > Keep Text Height and Angle	110
Paths and Polys > Box	111
Paths and Polys > Path	112
Paths and Polys > Polygon	113
Paths and Polys > Regular Polygon	114
Curves > Bezier Curve	115
Curves > Cubic B-Spline	116
Curves > Cubic B-SPoly	117
Curves > Parabolic Spline	118
Curves > Parabolic SPoly	119
Ellipses > Center and Axis Points	120

Ellipses > Circle at Angle to Window	121
Ellipses > Center and Inclination	122
Ellipses > Elliptical Arc	123
Draw > Point	125
Fillets/Chamfer/Offset > Fillet Only	126
Fillets/Chamfer/Offset > Fillet & Trim	127
Fillets/Chamfer/Offset > Chamfer Only	128
Fillets/Chamfer/Offset > Chamfer & Trim	129
Fillets/Chamfer/Offset > Offset Chain	130
Fillets/Chamfer/Offset > Offset One	131
Fillets/Chamfer/Offset > Offset Copy	132
Arrows	133
Double Arrows	135
Draw > Multipoly	136

Drawing with Wall Networks 138

Walls > Wall	141
Walls > Room	142
Walls > Offset	144
Walls > Add to	145
Walls > Cut from	146
Walls > Remove Side	147
Walls > Set Width	148
Walls > Chg Wid All	148
Walls > Chg Wid Span	149
Walls > Chg Wid End	150
Walls popup menu	151

Dimension Commands 153

Linear	154
Horizontal	157
Vertical	158
Parallel	159
Ordinate	160
Baseline	162
Full Angular	164
Quick Angular	166
Radius	168
Diameter	169
Dimension Style Dialog Box	170
Dimension Arrowhead	171
Dimension Leaders	172
Dimension Tolerance Display format	173
Dimension Text	175
Dimension Text Fixed Values Format	176
Dimension Options	178

Edit Commands	179
Erase	180
Edit	181
Dynamic Edit	183
Change	186
Change > Properties	187
Entity Properties dialog	188
Change > Color	190
Change > to Color of SymRef	191
Change > Fill (2nd) color	191
Change > Pen Thickness	192
Change > Layer	192
Change > Line Style	193
Change > Fill Style	193
Change > Line Width	194
Change > Dimension Style	194
Change > Text	195
Change > Text Properties	196
Change > Arrowhead	197
Change > Arrow Style	198
Change > Radius	199
Change > Diameter	199
Properties	200
Drag	201
Move	202
DynStretch	203
Stretch	205
Scale > Scale Value	206
Scale > Dyn Scale	207
Scale > ScaleXY	208
Rotate > Rotate ang	209
Rotate > Dyn Rotate	210
Rotate XY Align	211
Connect	212
Mirror	213
Trims > Trim	214
Trims > Trim to Entity	215
Trims > Trim to Intersection	216
Trims > Trim to Length	217
Trims > Trim Inside Entities	218
Trims > Trim Outside Entities	219
Break	220
Bend	222
Split	223
Node Edit > Delete	223
Node Edit > Insert	223

Front	224
Above	225
Below	226
Back	227
Explode	228
Copy Commands	229
Copy	230
Drag Copy	231
Copy to Layer	232
Copy Connect	233
Dynamic Scale Copy	235
Scaled Copies	236
Dynamic Rotate Copy	237
Rotated Copies	238
Mirrored Copies	239
Rectangular Array	240
Circular Array	241
Insert Commands	243
Part commands	245
Insert Part	246
Insert XREF	248
Part Array	251
Circ Part Array	253
Create Part	255
Group	256
Ungroup	256
Sheet commands	257
Sheet	258
Move to Sheet	260
Copy to Sheet	260
Symbol commands	261
Define Symbol	264
Make Control Points	265
Replace Symbol References	268
List SymDef	269
Delete SymDef	269
Purge Unused Symbol Definitions	270
Load Part as SYMDEF.	271
Insert>Change All SymDefs>Scale All Defs	272
Insert>Change All SymDefs>Change All Color	273
Insert>Change All SymDefs>Change All Color by Block	274
Insert > Change All SymDefs > Change All Layers	275
Draw Symbol	276
Extract Attributes	278

Insert Picture	279
Specs Commands	284
Select Grid	285
Align Grid	286
Angle Grid	287
Edit Grid	288
Editing Rectangular Grids	288
Editing Circular Grids	289
TriGrid	289
Editing Angular Grids	290
Editing Hexagonal Grids	291
Select Color	294
Select Layer	296
Select Layer	299
Hide	299
Show	299
Hide All	299
Show All	299
Freeze	300
Thaw	300
Freeze All	300
Thaw All	300
List Layers	300
Line Style	301
Line style dialog	302
Fill Style	304
Brush Pattern Fill Style	307
Hatch Fill Style	308
Bitmap Files Fill Style	310
Symbol Fill Style	312
Line Width	313
Pen Thickness	315
Pen Thickness Dialog Box	316
Map Color to Pen Thickness dialog box	318
Load Color Map	319
Save Color Map	320
Useing a Drawing's Color Map	321
Dimension Style	323
Arrowhead Style	327
Text Properties	328
Font	331
Specs > Time and Date	332

Toggle Frames	333
Toggle Crossshairs	333
Attach Mode	334
Installed XPs	336
Screen Tools	337
Loading a Custom .CFG Screen Configuration File	339
Units	340
Distance Display Format	341
Rescale Units	344
Dimension Bearing Angle Distance Format	345
Dimension Angle Width Format	345
Options	346
DWG/DXF Options	349
Info Commands	351
List	352
Extents	353
Count All	353
Count	353
Coordinate	354
Bearing	354
Distance	355
Distance... ..	355
Length Along	356
Area	356
Calculate	356
Macro Commands	357
Quick Primer on Macro Creation	358
Load Macros	360
Edit Macros	360
Save Macros	361
Clear Macros	361
List Variables	361
Save Variables	362
Using Actions	363
Define Action command	364
Show Actions command	365
Hide Actions command	365
Modifiers	366
Endpoint modifier	367
Endpoint of seg modifier	368
Center modifier	369
Midpoint modifier	370
Midpoint of Seg modifier	371

Mid of 2 EPTS modifier	372
Mid of 2 CEN modifier	373
Mid of 2 MIDS modifier	374
Nearest Point On modifier	375
Intersection of modifier	375
Parallel To modifier	376
Perpendicular To modifier	377
Angle To modifier	378
Percent Along modifier	379
Percent Along seg modifier	380
Distance Along modifier	381
Degrees on modifier	382
Bearing Angle modifier	383
Tangent to modifier	384
Change @ Ref Point modifier	385
Same X modifier	385
Same Y modifier	386
Like modifier	387
Keep Like modifier	388
Help Commands	389
Help	389
Current Command Help	389
How to use Help	390
About EasyCAD	390
About our website	390
Guided Tour	390
EasyCAD V7 Command List	391
Index	400

Chapter 1

Introduction

Welcome to EasyCAD v7!

EasyCAD is a general purpose **2D CAD** platform for your **Windows 95/98/98Me/NT/2000 an XP PC**, based on the award-winning software that introduced thousands of users to the world of **CAD**.

EasyCAD was designed with three things in mind: power, speed, and ease of use. Using the product of this unique design philosophy, you'll soon be busy producing professional level **CAD** drawings.

Like our software, this reference manual is a tool—designed to guide you through your design and drafting projects. The user manual is simple, yet thorough enough for both the novice and the experienced **EasyCAD** user.

This manual is divided into two main sections:

The **Introductory Chapters (Chapters 1 through 3)** provide preparatory information about interfacing with **EasyCAD**, and instructional information about general **CAD** concepts. These chapters are especially helpful if you are new to **CAD**.

The **EasyCAD Reference (Chapters 4 through 18)** documents all the commands available to you through the **Menu bar**. Refer to these chapters as questions or situations arise. The online **Help** file mirrors this manual but also has a “**How Do I...?**” and a “**Trouble Shooting**” section that is not contained in this manual. You will find the most up-to-date information on **EasyCAD V7** in the online **Help** file.

The Internet

The Internet offers us unprecedented convenience and flexibility in communicating with users like yourself. We strongly encourage you to regularly visit our World Wide Web site for updates, add-ons, news, etc.

www.fastcad.com

**Read these
Sidebars**

Occasionally you'll see sidebar text such as this. Typically, you'll find tips or background to help you use the associated topics more effectively.


Manual Conventions

Through the course of this manual, we have attempted to adhere to written conventions to make your interpretation of instructions and descriptions clear.

CAPS are used for **COMMANDS**, such as **LINE** or **REDRAW**.

[Menu commands] are referred to in *brackets* [Draw > Lines > Double Lines].

An example of a *nested* menu command is:



Filenames and named components of **EasyCAD**'s drawing screen, such as *named menus*, *named icon bars*, or *named dialog boxes*, are shown in *italics*. Terms of *general emphasis* are also *italicized*.

Boldface is used for *dialog box* items, options, and button labels.

Where appropriate, “**command line prompts**” appear in quotes. “**Items you are instructed to type**” also appear in quotes.

KEYS on your keyboard, such as **SHIFT** or **SPACEBAR**, are typed in **caps**.

The instructive word “**click**” implies pressing the *left* mouse button. This action is sometimes explicitly termed a “**left-click**”. The term “**right-click**” means press the *right* mouse button. The term “**middle-click**” means press the *middle* mouse button which is a *scroll wheel switch* (with the understanding that standard mice may not support the *scroll wheel switch*).

The instructive word “**select**” implies pointing the screen cursor to an item or object and *left-clicking* the mouse.

The instructive word “**pick**” implies pointing the screen's *pick box* cursor to a drawing entity and *left-clicking* the mouse.

The instructive word “**choose**” implies the selection and subsequent clicking of a button on a dialog box.

The term “**entity**” is reserved for anything that appears on the actual drawing screen. Anything you can put on the drawing screen (such as a *line*, *symbol*, *dimension*, *text*, etc.) is an entity.

System Requirements:

- A Pentium II or newer CPU
- **MicroSoft Windows 95, 98, Me, NT 4.0, 2000** or XP Workstation operating system.
- At least 32MB random-access memory (RAM), 64MB recommended.
- 24 or 32 bit display mode capable VGA card.
- CD-ROM drive
- 4 MB available hard-disk space.

(Future add-ons and enhancements may require additional space.)

Installing EasyCAD v7

Before you get started, it's a good idea to return your postage-paid registration card. Registered owners receive some exclusive services, including telephone technical support.

Install the **EasyCAD CD** into your **CD ROM** drive and the installation window will automatically appear. If it does not appera after a few seconds double-click the “**My Computer**” icon on your Windoes Desktop, double-click the **CD ROM** icon and then the “**Autorun.exe**” file displayed in the window that appears. Follow the on-screen instructions to install **EasyCAD V7**, the **Symbol Catalogs** and other options..

Support

Registered users are eligible for free telephone support (local and long-distance phone charges may apply).

In the United States and Canada, call our **Technical Support line between 9:00 AM and 5:00 PM Mountain Standard Time (Arizona does not observe Daylight Savings Time!)**. We prefer that you be close to your computer, if possible. Please have your serial number at hand, *since support is available to registered users only*.

If you purchased your copy of **EasyCAD V7** outside of the U.S. or Canada, please consult your local dealer. He or she is your best source of convenient local support.

In addition, be prepared to provide the following information:

- Your version of **EasyCAD**, always available from [**Help > About EasyCAD**] from the menu, or by typing '**VER**' at the command prompt.
- Computer name and model, as well as the name and model of any relevant peripheral components.
- Whether you are using **Windows 95, 98, 98ME, NT, 2000 or XP**, and what version if applicable.
- Specific instructions to reproduce your problem.

Technical Support Line: (480) 967-6967

Evolution Computing Inc.

7000 North 16th Street

Suite 120 - #514

Phoenix, AZ 85020

www.fastcad.com

On the Internet, visit our website to find the appropriate e-mail addresses to direct correspondence/attachments.

Key Features

If you've used the **DOS** version of **EasyCAD**, you'll notice that this version is designed to integrate itself fully within the Windows environment. **EasyCAD** uses the same video card drivers, printer/plotter drivers, and TrueType fonts as the rest of your Windows applications. Otherwise, **DOS** users will see virtually all of the features and functionality of previous Evolution Computing products and more.

New features include:

- **True 32-bit double precision programming with full Windows 95/98/2000/NT and XP support**, including better file selection support of long file names, and print dialogs that support multiple printer selection.
- **256 Color Support**, with large color selection and definition dialog, custom palettes, etc.
- **Much superior linear dimension insertion and editing.**
- **New Path/Poly 'DYNAMIC EDIT'** command is much more powerful.
- **Dynamic Text Cursor** lets you see actual text before you place it. You may dynamically resize and rotate the text before placing it.
- **New entity selection is much faster.** You are automatically in **each** or **window pick** mode. A right-click opens a popup menu with further selections such as by layer, color, entity type etc.
- **AutoCAD 2000 import/export with support for AutoCAD .SHX fonts.**
- **Multiple UNDO/REDO/FLIP.** up to 10 levels.
- Ability to **specify line widths to geometric sizes** as well as **fixed width pen thicknesses** for printing solid filled lines up to 2.54mm / .1" lines..
- **Define & Extract attributes defined in Symbols.**
- **File Notes.** Embed notes about each drawing that do not display on the drawing.
- **More powerful Convert function.** Convert entire folders of drawings from one format to another (**FCD to FC7 and FS7, DXF/DWG to FC7 etc.**).
- **Template Files.** Create a Template file **.FT7** with all of your custom layer named, text properties, pen thicknesses, line styles etc. that you want when you start a new drawing.
- **Recently Used Files List.** Pick one of the last four files opened.
- **Parts files can be any valid import format (DWG, DXF, FCD, FCW, FC7)**
- **Change Multiple Text entities to read the same.**
- **Single or double pick INTERSECTION** modifier.
- **FRONT, ABOVE, BELOW** and **BACK** Commands.
- **Replace Symbols with other Symbols.** Pick the **Symbol Definition** you want to change the **References** of and then pick the **Symbol Definition** you want to change the **References** to and all **Symbols** in the drawing update to the newly selected Symbol definition. The **Symbol Definitions** are not effected.

- **Purge Unused Symbol Definitions.** Quickly eliminate **Symbol Definitions** that have no **Symbol References** in the drawing. This excess baggage can make your drawing much larger than it needs to be. This is the case with most **AutoCAD DWG** or **DXF** drawing that you import.
- **Tooltips for icons, colors and property status windows.**
- **Adjustable pick cursor aperture.**
- **Old file formats automatically update** on load or part insertion — no longer a two step process. **You may open .FCD v2.72+, ECW v4.55, FCW v5.215.**
- **EXTENTS** info command. Shows the x, y, z dimensions of the active drawing
- **KEEP LIKE** entity modifier to set all properties of a specified entity as current.
- **Sy,bol Catalog viewer** to select **Symbols** thumbnail pictures.
- **Quick access to all properties from on-screen status window drop-down menus.** **If you click the drop-arrow at the right end of a status window,** you may pick the property from a menu. If you click in a status window the full dialog box appears for that property.
- **Customization of icon bars now supports standard Windows .ICO icon files instead of the previously used .BMP format.** This will allow variable size icon selection in future updates of **EasyCAD v7.**
- **Greatly enhanced Macro language** now allows entity selection by entity type as well as the use of hot keys from inside Macros.
- **Each drawing window now has its own set of icons that control its view settings for make active window, move window, minimize/maximize and close..**
- **Dynamic pan and zoom the drawings view using the left mouse button and one keyboard button..** By clicking the center button of a three button mouse or the wheel switch on a wheel mouse, you are in *dynamic pan* and *zoom* mode. Hold the left mouse button down while moving the mouse and the drawing pans in real time. Hold the **SHIFT** button down and *zoom in* or *out* by moving the mouse forward and backward.
- **Scaleable Hatching.** **EasyCAD 32** only had bitmap hatching.
- **XREF file support.** You may select external files and select a location in your drawing and have them appear. If the **XREF** file is modified, these changes will be reflected in the host drawing when you open it.
- **Ordinate and Baseline Dimension**
- Insert the **‘Current Date’, ‘Current Time’** and **‘Current Drawing’** name as **TEXT ITEMS** that **constantly update.**
- **HEXAGONAL GRID SYSTEM** for drawing **ISOMETRICS.**
- **Converts MDE32 Dimensions to v7 DIMENSIONS.** Since there was never an **MDE** for **v7**, you can now convert the **FastCAD 32** and **EasyCAD 32** drawings with **MDE32 DIMENSIONS.** This is due to a **v7** user in **Scotland** that created an **XP module** for use to include.

EasyCAD Command Menus

EasyCAD's commands are grouped in the pull-down menus according to their basic functionality.

File commands manage drawings and files.

Clip commands give you access to undo and the Windows Clipboard.

View commands control what you see in the drawing window.

Draw commands add new entities — like lines and circles — to your drawing.

Dimensions commands to draw linear and angular dimensions of entities.

Edit commands modify existing drawing entities.

Copy commands let you create multiples of existing entities.

Insert commands manage symbols and parts.

Specs commands control your basic drawing environment.

Info commands report on entities and perform calculations and measurements.

Macros commands let you load, edit, and save your own routines.

Mod commands work within drawing or editing commands to precisely select existing points or entities.

Help commands access help files and information for using **FastCAD**.

If you are new to **CAD**, read the introductory chapters, then try the quick start tutorial. When completed, you'll be well equipped with the basic fundamentals to tackle your own, more challenging projects.

If you have experience with other **Evolution Computing CAD** products, or even other **CAD** systems, you may prefer to experiment on your own, using the **EasyCAD** manual as a reference.

Either way, you will soon learn why **EasyCAD** has earned its reputation as the world's fastest and easiest-to-learn precision **CAD** program.

Chapter 2

Communicating with EasyCAD v7

The Interface: Telling EasyCAD v7 what you want it to do

Better than a large drawing board, **EasyCAD** gives you a virtually unlimited canvas to create your drawings. You'll notice that most of your **EasyCAD** screen consists of the drawing window, maximizing your ability to see your work.

You communicate with **EasyCAD** through your mouse and keyboard, and through the numerous screen tools visible around the drawing window. These tools comprise the “**interface**”, or your means of communicating with **EasyCAD**.

Most on-screen drawing tools are in the form of “bars” that contain icons, buttons, or indicators that either provide information or perform actions. Each screen element listed below is described in detail in this chapter.

The **Title bar**, located across the top, is a standard Windows screen component that displays the current drawing name and contains controls to minimize, maximize, or exit the application.

The **Menu bar**, located just beneath the **Title bar**, provides you with access to almost all of **EasyCAD**'s operating commands through the use of pull-down menus.

The **Status bars**, located beneath the **Menu bar**, as parts of the default set up are called: the **Tracking bar**, which provides indicators for cursor tracking, font name, text height, pen thickness and line width; the **Style bar**, providing the current text style, dimension style, coordinate system, and sheet name; and the **Properties bar**, indicate drawing file name, current layer, current line style, and current file style. You can left-click on any indicator to change current modes.

The various **Icon bars** are located along the left and right edges of the screen and contains icons for drawing, editing, zooming, specs, and 3D view control, and more.

The **Color bar**, located along the left edge of the screen, allows you to change the current drawing color with a simple click.

The **Button bar**, located on the bottom edge of your screen, contains the command prompt for keyboard entry of commands, and buttons that allow you to customize the drawing environment.




Screen Tools icon

You can customize your screen by showing or hiding the **Status bars**, **Color bar**, and **Icon bars**. To do so, use the **Screen Tools icon** located on the **Button bar** and check the desired options *on* or *off*.

The EasyCAD v7 Screen

When you start **EasyCAD v7** for the first time, you see a screen with a **Menu bar**, two **Status bar**, a **Color bar**, three **Icon bars** and a **command prompt** surrounding a large drawing window that contains an arrow-shaped cursor.



The **Title bar** runs across the very top of the **EasyCAD** window. It displays the name of the current drawing you are working on, as well as controls to minimize, maximize, or close the program. If the **EasyCAD** application window is not maximized, you can click on the **Title bar** and reposition **EasyCAD** on your Windows desktop.

The **Drawing window** is most important part of your screen. This is where you **view**, **draw**, and **edit** your drawing. **EasyCAD** allows you to open multiple windows for the drawing, and shows you different levels of detail.

The **Menu bar** across the top of the screen contains the titles of the pull-down menus from which you can choose almost every **EasyCAD** command.

Most of the remaining screen elements can be toggled off using the **TOOLS** command [**Specs > Screen Tools**], also accessible by choosing the **Hammer icon** at the bottom of the screen.

The **Tracking bar**, located beneath the **Menu bar**, displays the current **XY Coordinates** of the cursor and up-to-date drawing information such as the current **Font name**, **Text height**, **Pen thickness**, **Line width** and **Sheet name**. You can quickly change these settings by clicking in any indicator window or its drop-arrow on the **Tracking bar**.

The **Styles bar** beneath the **Tracking Bar**, shows **Layer name**, **Line style**, **Fill style**, **Text style** and **Dimension style**.

The **Color bar** on the left shows the colors available on your display. The current color is marked with a heavy black outline. You can use the Color bar to select a different color at any time, even in the middle of drawing or editing.

The **Draw Icons bar**, located next to the Color bar, offers you quick access to the most commonly used drawing commands.

The **Edit Icons bar** offers you quick access to common editing commands.

The **Standard Icon bar**, located to the right, gives you quick access to several useful commands such as *zooms*, *layers*, and *entity properties*.

The **command prompt** along the bottom lets you and **EasyCAD** communicate. Usually, the prompt reads “Command:”. **EasyCAD** is asking, ‘What is your command?’

The **Button bar** is located at the right of the command prompt. These buttons enable you to quickly toggle features **ON** or **OFF**. In some cases, you can edit the properties of the feature by right-clicking on the button to open its appropriate dialog box.

Use the cursor to choose commands from the pull-down menus and to select screen locations. The cursor is a small arrow which changes shape during drawing and editing, usually to the crosshairs, stretching line (rubber band), stretching rectangle, or pick box.

The Command Prompt

Some examples of EasyCAD's prompts:



Select entities [3 picked]:



Diameter [2.000]:



Number of rows [5]:

The **Command prompt** lets you and **EasyCAD** communicate through the keyboard. You can enter commands (telling **EasyCAD** what to do), or enter input during a command (answering questions **EasyCAD** asks). When the **Command prompt** reads ‘**Command:**’, **EasyCAD** is awaiting your next action. All menu commands have text equivalents that may be alternatively typed on the **Command prompt**. The previous command is displayed in **[brackets]**. To auto-repeat the previous command, either click the mouse button, press the **SPACEBAR**, or press **ENTER**.

In mid-command, the **Command prompt** may ask for any additional information (like locations, angles, numeric values, etc.) it needs to complete the current action. You can either type a response, or indicate it visually with the cursor, depending on what is asked. Press **ENTER** or **right-click** after typing the prompt input. Right-clicking without entering a keyboard response will cause **EasyCAD** to accept the default, which is displayed in **[brackets]**. When **[dialog]** is displayed, you have the option of submitting input via a dialog box. Right-click to display the dialog box appropriate to the active command.

Using the menus

EasyCAD's entire command set is accessible through the pull-down menus. The menu is always located at the top of the drawing screen, and it cannot be disabled.

To invoke a menu command, move the arrow cursor to the **Menu** bar. When the cursor is over the title of the menu you want, left-click. A pull-down menu appears with several commands. With the mouse, move the highlight up and down until it is over the command you want, then left-click again. If you pull down the wrong menu, de-select it by left-clicking the menu title, or pressing the **ESC** key.


EasyCAD's menu commands are grouped according to their function type:

- **FILE**—manage drawings and files.
- **CLIP**—undo and Windows clipboard commands.
- **VIEW**—control what you see in the drawing window.
- **DRAW**—add new entities (like lines and circles).
- **DIMENSIONS**—add measurements.
- **EDIT**—modify entities that you have already drawn.
- **COPY**—duplicate existing entities.
- **INSERT**—manage symbols and parts.
- **SPECS**—control your drawing environment.
- **INFO**—perform calculations and measurements.
- **MACROS**—load, edit, and save your own routines.
- **MOD**—work within commands to refer to existing entities.
- **HELP**—access **EasyCAD**'s on-line **Help** facility.

Some menu choices open sub-menus which provide additional command options. **EasyCAD** never nests deeper than this level.

Menus can be modified with any text editors. For more information on menu customization, please consult **EasyCAD**'s on-line **Help** [**Help > Contents**].

The Button Bar



The **Button bar** is located along the bottom edge of the screen. In the course of a typical drawing, you will likely access these buttons on a frequent basis.

Because the **Button bar** provides critical user input and feedback functions, you cannot toggle off its display.

Command [LINE]:

The **Command prompt** is located on the left edge of the **Button bar**. The **Command prompt** lets you and **EasyCAD** communicate through the keyboard.



The **Configure Screen Tools** icon lets you select which screen elements will be displayed. Toggle items on or off using the **Select Screen Tools dialog box**. This button is the same as selecting [Specs > Select Tools] from the menu.




Color shows the **current entity drawing color**, and clicking on it brings up the **256 color selection dialog box**.




Grid turns the grid pattern display on or off. The **Grid** is a drawing aid consisting of nonentity dots displayed at regular, user-defined intervals. Right-click on this button to change **Grid Spacing**.



Ortho limits entity creation or displacement to the horizontal or vertical axes. For example, lines drawn with **Ortho** cannot be drawn diagonally.




CsrSnap (Cursor Snap) works only when the **Snap** button is on. If **Snap** is on, you can only place entities along the subdivisions of an established grid. When **CsrSnap** is on, your cursor will visually **'jump'** to the next **Snap Point** as well.



Snap places entities along the subdivisions of your established **Grid System**. Right-click this button to alter the **Snap Point** intervals.



Attach engages the selected modifier for use in draw and edit commands. Right-click this button to change or inspect the active modifier. When **Attach mode** is on, a pick box cursor is displayed whenever a point is requested. If an entity is picked, the requested point honors the attach modifier. For example, if you are drawing a line with **Attach mode on**, and the current mode is **Endpoint**, the cursor will **attach** to the **endpoint** of any picked entity. For more information on **Attach Mode**, see [Specs > Attach Mode] in **Chapter 13**.



Locked toggles group effects **on** or **off**. When unlocked, the label changes to **'Unlocked'** to show the current state. When groups are **unlocked**, they have no effect and their component entities can be freely edited. Toggle to **'Locked'** to restore group effects.



Icon bars

EasyCAD provides you with several *icon bars* that you can selectively toggle **ON** or **OFF** or *reposition* in any combination:

- *Standard Icon bar*
- *Draw Icon bar*
- *Edit Icon bar*
- *File icons bar*



Configure Screen Tools
Icon on Command Line

To *display* or *hide* the icon bar, use the **TOOLS** command [**Specs > Screen Tools**], and click in the *Control; box*. The position of the *icon bar* can be customized by clicking on the desired control box with the arrow pointing to the side of the screen you want the *icon bar* displayed.

-  Off (Hidden)
-  Left edge
-  Top edge
-  Right edge
-  Bottom edge

To see what function any **Icon** performs, hold the cursor over the **Icon** for a moment. A *tooltip* appears, telling you which command is attached to the button. Move the mouse away from the icon to hide the *tooltip*. To turn *tooltip* display **ON** or **OFF**, use the **OPTIONS** command [**Specs > Options**].

Any of the icon bars can be customized. The *Custom Icon bars* contain no default icons, so you (or third party developers) can use these and still retain use of the *Standard*, *Edit*, and *Draw Icon bars*. For more information on creating your own icons, see the on-line Help topic on 'Customizing Icons' [**Help > Contents**].

Standard Icon Bar

The *Standard Icon bar* gets detailed mention since it contains the most commonly used shortcut icons. It gives you quick access to many drawing properties you might often modify during the course of your work.



Zoom In

Zooms in 2.0 times, showing less of the drawing
[View>Zoom In]



Zoom Out

Zooms out 2.0 times, showing more of the drawing
[View>Zoom Out]



Zoom Center

Select new view center
[View>Zoom Center]



Zoom Window

Zoom into user-defined box
[View>Zoom Window]



Zoom Extents

Recalculate and zoom to extent of drawing
[View>Zoom Extents]



Zoom Text

Zoom to specified text
[View>Zoom Text]



Dynamic Pan

Activate real-time pans and zooms
[middle-click mouse]



Zoom Last

Restore to previous view
[View>Zoom Last]



Layer

Manage your drawing layers
[Specs>Select Layer]



Line Style

Manage the line styles **EasyCAD** uses to draw entities
[Specs>Line Style]



Fill Style

Manage the fill styles **EasyCAD** uses to draw entities
[Specs>Fill Style]



Dimension Style

Manage dimension formatting and options
[Specs>Dimension Styles]



Text Properties

Manage text properties, such as fonts and character styles
[Specs>Text Properties]



Select Color

Access the 256-color palette. Customize or select colors.
[Specs>Select Color]



Edit Properties

Edit entity properties of a single, selected entity.
[Edit>Properties]



Help

Display the FastCAD on-line help file contents
[Help>Contents]



Select Active Window

When multiple windows/files are open, change the active drawing window
[no menu equivalent]



New Window

Create a new drawing window
[no menu equivalent]



Multi-Drawing Control

Manage XREF files.



Sheet

Manage sheets (add, delete, rename, reorder)
[Insert > Sheets]



Keep

Click this icon and then click an entity in the drawing to change your default Layer, Color, Line Style etc. to those of this entity



Select Color icon

Color bar

The active drawing color has a black border. In this illustration, color #1 (green) is the active color.




Color Bar

The **Color bar**, located on the left side of your screen, consists of available colors you can use in your drawing. **EasyCAD** displays as many colors as your screen and resolution will allow. The **Color bar** display is anchored at the bottom (**the color black**). The active color is shown with a heavy black border (the active color is also displayed on the **Status bar**). Any entities you create are drawn with the active color.

All 256 available colors are numbered from **0** to **255**. **Black**, always located at the bottom, is **#0**. **Color #0 (black)** and **#15 (white)** cannot be changed.

Below is the entire palette of **256 colors**. To see the **256 color palette**, select the **[Specs > Select Color]** command, or click the **Select Color icon**. The **Select Color dialog** lets you to choose from **256 colors**, create custom palettes, and create new blended colors.



Status Bars

Tracking bar
Styles and
Properties bar



The two *Status bars* above display current (or active) drawing settings. The two default *Status bars*, are the *Tracking bar*, the *Styles* and *Properties bar*. The individual status boxes that make up the bars can be configured in any order or combination. To custom configure these bars, see “**Customizing EasyCAD.**”


The settings displayed are the active *entity properties* that apply to any entity you draw or create in the drawing. These properties include *sheet name*, *pen thickness*, *line width*, *layer name*, *line style*, *fill style*, *font name*, *text height*, *text style*, and *dimension style*.

In addition to the heads-up information it displays, the *Status bars* provides a very quick means of changing your current settings. Just left-click on any indicator window (even in mid-command) to select new settings through dialog box input. Left-click the *drop arrow* at the right end of most indicators to select from a menu of settings or styles used in the drawing.


Tracking Status

The *Tracking status* window shows you the current coordinates of your cursor. Click on the window to cycle through the three *tracking* modes. The fourth click turns *tracking off*.

Absolute



Relative



Polar



The tracking display continuously updates as you move the mouse. Click on the status indicator to cycle through the various tracking modes: absolute, relative, polar coordinates, and off.

“**Abs**” indicates absolute tracking; “**@**” indicates relative tracking; and “**<**” indicates bearing angle and distance (relative polar tracking). Tracking can also be turned off. To set the display format and decimal places, use the **UNITS** command [**Specs > Units**].

Color Status



The *Color status* button displays the *current color*. All new entities are drawn with the indicated color. This tool is especially helpful if you choose to work with the *Color bar* toggled off. To change the *current color*, click directly on the *Color status button* to display the **256-color Select Color** dialog, then choose the *new color*.

Pen Thickness Status

PThk: 0.30000 mm

The *Pen Thickness status* window displays the *current pen thickness*. *Pen thickness* is the *display* and *printing* of *width* for entities. All new entities are drawn with the specified *pen thickness*. Click the *drop arrow* for a *menu* to quickly choose one of the *last five pen thicknesses used* in the *active drawing*. *Pen Thickness* always *prints* the same *thickness* at any scale factor.

To specify a *new pen thickness*, click directly in the status window to open the *Pen Thickness dialog* and specify a *new pen thickness* in *millimeters* or *inches*. The *maximum* is **2.54 mm** or **1/10"**. You must type **mm** or **"** after the new value or the current value will not change. You may also *map a different pen thickness* for each of **EasyCAD's 256 colors**. The new *thickness* will also appear in the drop down menu.

Line Width Status

LWid: 0.50000

The *Line Width status* window displays the *current line width*. All new entities are drawn with this *width*. Click the *drop arrow* for a *menu* to quickly choose one of the *last five line widths* used in the *active drawing*.

To specify a *new line width*, click directly in the status window to open the *line width dialog* and type a *new line width* value. This value will appear to the drop down menu.

Layer Status

L: Front elevation

The *Layer status* window displays the *active drawing's current layer name*. All new entities are drawn on the displayed *layer name*. Click the *drop arrow* for a *menu* to quickly select one of the *layers* in the *active drawing*.

Click in the window to open the *Layer Management dialog box* to *add, delete, freeze or thaw* layers. There is a *'Hide all but current layer'* check box which allows you to quickly see what entities are on the *current layer*.

Line Style Status

LS: Solid

The *Line Style status* window displays the *current line style*. All new entities are drawn with the *line style*. Click the *drop arrow* for a *menu* to quickly select one of the *line styles* used in the *active drawing*.


To *add a new line style*, click directly in the status window to open the *Line Styles of dialog box*, then select a new *line style*. It will also appear in the drop down menu.

Fill Style Status

FS: Wide left hatch


The *Fill Style status* window displays the *current fill style*. All new entities are drawn on the displayed *fill style*. Click the *drop arrow* for a *menu* to quickly select one of the *fill styles* used in the *active drawing*.

To *add a new fill style*, click directly in the status window to open the *Fill Style dialog box*, then select a *new fill style*. It will also appear in the drop down menu.

**Font Name
Status**

The **Font status** window displays the **current text font**. All new text entities are drawn with the displayed **text font**. Click the **drop arrow** for a **menu** to quickly select one of the **fonts** used in the **active drawing**.

To select a **new text font**, click directly in the status window to open the **Text Properties dialog**. Click the **More Fonts button** and choose one of the install Windows **TrueType fonts**, a **EasyCAD .FNT** vector font or if installed, an **AutoCAD .SHX** vector font. The new font will also appear in the drop down menu.

**Text Height
Status**

The **Text Height status** window displays the **current text height**. All new text entities are drawn in this **text height**. Click the **drop arrow** for a **menu** to quickly select one of the **last five text heights used in the active drawing**.

To **set a new text height**, click directly in the status window to open the **Text Properties dialog box**, then set a **new text height** value. The new **text height** will also appear in the drop down menu.

**Dimension Style
Status**

The **Dimension Style status** window displays the **current dimension style**. All new dimensions are drawn with the selected **dimension style**. Click the **drop arrow** for a **menu** to quickly select an available **dimension style** defined in the **active drawing**.

To **define a new dimension style**, click directly in the status window to open the **Dimension Style dialog box**, then set the desired properties and add a **new dimension style** to the **active drawing**.


**Sheet Name
Status**

The **Current Sheet status** window displays the **active drawing sheet name**. All new entities are drawn using on this **active drawing sheet**. Click the **drop arrow** for a **menu** to quickly select a different **sheet name** defined in the **active drawing**.


To **add, delete, hide, show** or **rename sheets**, click directly in the status window to open the **drawing sheets dialog box**.

All Status, Icon Bars and Symbol Catalog Viewer On


The screen illustration below shows the **Screen Tools** dialog box with all of the **Icon** bars, **Status** bars and the **Symbol Catalog Viewer** turned on.



The screen illustration seen below shows all **Icon** bars, **Status** bars and the **Symbol Catalog Viewer** turned off to maximize the drawing screen area. You may also turn off the **Command Prompt** but it is not recommended. The **Menu** bar may not be turned off.



Multiple Drawing Windows



EasyCAD v7 can split your screen into a any number of windows, displaying different *views* of the drawing,. Each window has its own zoom factor. Each window *zooms* and *pans independently*, but all windows are active for drawing and editing. For example, you can draw a line that starts in one window and ends in another.

Use multiple windows when you need to:

- Work simultaneously in widely separated areas of your drawing.
- Work on details in a zoomed in view while viewing the results in an overall view.

To Add New Drawing Windows

Use the *New Drawing Window* icon on the *Standard Icons* bar. Click the icon and you will be prompted to provide the two corners that define the new window. Alternatively, you can type in **NEWW** at the command line. New windows can be added anywhere on the screen, even on top of one another.



Select Active Window icon in the Standard Icon bar

To Select an Active Window

To make any drawing window *active*, you can either:

- Click the *Make active window* icon in the target window's *title bar*.
- Use the *Select Active Window* icon from the *Standard Icon* bar, then click anywhere on the target window.
- Type **SELAW** at the command line, then click anywhere on the target window.




Make active window icon in upper right corner of each view window

The **active window** is the window affected by **zoom magnification** or **view center** changes. Note that the **active window** for **zooms** is drawn with a 1-pixel width **red border** just inside the main border.

To Name a Window

When a new window is created, it is given the default name '**Unnamed view**'. Sometimes you may wish to give these **views** more descriptive names to facilitate printing, **zoom names**, etc. To give a drawing window a name, or to rename a window, use the **SET VIEW NAME** command [**View > Set View Name**]. This command can be accessed by typing **SVNAME** at the command line or by selecting the command from the **View menu**.



Typical window title bar. The view name in this case is "fWorkshop area".

To Size a Window

To **resize** a window, simply use the standard Windows procedures: Move the cursor to the edge or corner of the window border (the standard cursor changes to a two-headed arrow) and **drag**.

To Move a Window




To **move** a window, click on its **Move window icon** in the window's title bar of the drawing, **hold the left mouse button**, and **drag**. To **minimize** or **maximize** a window, click on the window's **minimize/minimize icon** in its title bar.

To Maximize or Minimize a Window




To Close a Window



To **remove** a window from the screen, click on the title bar's **Close window icon**. If the drawing window had a view name, the name is not deleted. The named view can be recalled in the **active view window** if it was saved with the **SET VIEW NAME** command or when printing the drawing. Once the **view window** is closed you will need to use the **New Drawing Window icon** to create another.






Window Control Bar Icons



A powerful feature that is new in **EasyCAD v7** is the individual drawing window control bar. Every window opened in a drawing has this control bar across its top. Displayed across the bar are the following information and control icons:

View name - current view name

File name - current drawing file name

-  **Make View 2d** - EasyCAD v7 can open **FastCAD 2d** drawings
-  **Make active window** - makes window active for zoom and rendering
-  **Move window** - allows window to be drug to a new screen location
-  **Minimize/Maximize** - toggles between full screen and small window
-  **Close window** - closes current window

Symbol Catalog Viewer

For a more detailed discussion about symbols, please see Chapter 12, Insert commands


EasyCAD's Symbol Catalog viewers

makes **symbol management** and **insertion** very easy. You can create **symbol libraries** and dynamically load and unload them from the viewer. Symbols can be selected from the loaded catalog and inserted into your drawing using a “**drag and drop**” type of interface.

The actual **Symbol Catalog Viewer** may be displayed veretically on the left or right side of the screen. Its display may be toggled **ON** or **OFF** using the **SCREEN TOOL** command [**Specs > Screen Tools**] or its icon equivalent.



SCREEN TOOLS icon located in the button bar.



To insert a symbol from the catalog:

Move the cursor over any **Symbol Catalog viewer**, roll the scroll wheel, if you are using a wheel mouse, or right-click for a full screen of **symbols** and left-click over the desired **symbol** to select it. Move the cursor over the drawing screen and a **ghost image** of the **symbol** will appear. The **command line prompt** reads the following:

(CTRL=scale CTRL+SHIFT=rotate) Origin/Scale [INS=specs]:

At this point you may left-click to place one or more **symbol references** in your drawing, type a **scale factor** to change the size of the next **reference** you place in the drawing, or you may dynamically **scale** or **rotate** the **symbol** prior to placing each **reference** in the drawing. If you press the “**Ins**” key on the keypad, the **Insert Parameters dialog box** opens. You may set a **scale factor** and a **rotation angle** for the next **symbol reference** placement in the drawing. **EasyCAD** allows you to open two **Symbol Catalog viewers** at the same time displaying to different **.FS7 Symbol Catalog** libraries.

At any time you may select a **symbol** for insertion even in the midst of another **symbol** insertion. The new **symbol** will acquire any **scaling** or **rotation** applied to the previous **symbol**.

Symbol Definitions are loaded from the **catalog** to your drawing as soon as you left-click a thumbnail in the **viewer**. You do not need to place a **reference** in the drawing. This is a quick way to make a new **symbol catalog** file from one or more more complex **symbol catalog** files.

To load a different Symbol Catalog in the viewer:

The sample catalog **ELECTRIC.FS7** demonstrates the *Symbol Catalog* functionality. The **EasyCAD** distribution **CD** contains a number of other *catalogs* you may use. To load a different *symbol catalog* click the *Catalog* button at the top of the *viewer* to display the *Load Catalog dialog box*. The file list is automatically filtered to display only **.FS7 symbol catalog** files. Simply select the desired file name and click the *Open* button or double left-click directly on the file name.

At the command prompt you may type **CATALOG** then specify a *catalog file name*. This command is most useful in a *custom menu*, where you can specify a menu entry to load a specified *catalog*.

The last *catalog* used will be the one in use when a new **EasyCAD** session is started.

To toggle between drawing symbols and catalog symbols:

The *Symbol Catalog viewer* can display either the *symbol definitions* in the loaded catalog file or those *definitions* contained within the *active drawing only*. *By default, the viewer displays the symbols in the currently loaded catalog*. To force display of symbols in the *active drawing*, click the *Dwg Syms* button located at the top of the viewer. To switch back to the catalog view, click the *Catalog* button. Only one view can be active at any time.

To create a new symbol catalog file:

A *symbol catalog* is a drawing file that only contains *symbol definitions*. You can create a *symbol catalog file* by creating the *symbol definitions* in a drawing and saving it as an **.FS7** file. *Symbol catalogs* should use *no grouping* and contain nothing but *symbol definitions*. An **EasyCAD .FS7 Catalog** file may be opened from the **OPEN** command from the *Load Drawing dialog box* and saved as a '**EasyCAD 'FS7 Catalog'** file using the **SAVE AS** command from the *Rename & Save dialog box*.

To create symbols that draw in the color active during insertion:

Note that the symbols included in the sample catalog, **ELECTRIC.FS7** change color when you select a new drawing color. To create symbols that draw in the current drawing color active during insertion In your custom **.FS7** catalog file:

1. Draw the entities that will comprise the intended *symbol definition*.
2. Use the **CHGCBB** command [**Edit > Change > to Color of SymRef**], and select the defining entities. You can also use the **PEDIT** command [**Edit > Properties...**] and select entities one at a time. If you use this method, check the "**Color is color of Symbol Reference**" option in the *Entity Properties dialog*.
3. Immediately use the **DEFSYM** command [**Insert > Define Symbol**] to define the *symbol*.

The entities in that *symbol* will be drawn in the *current color* at the time the *symbol reference* is inserted.

Default Values

For many commands, **EasyCAD** displays a prompt followed by a default or prior value in brackets, like this: “**radius [1.50]:**”. This is a *suggested* response based upon the previous value used for the same command. When you start a new drawing, **EasyCAD** suggests a standard or “**normal**” response—like 0.2 units for text height—for each command that uses a default value. After you use each command, most default values change to the prior value you used. For example, each time you draw a circle, the default center is the center of the last circle you drew, making it easy to create concentric circles.

To accept the default or *prior value*, right-click or press the **SPACEBAR** or **ENTER** key. To override the default value, input a new value using the keyboard or screen pointer.

Message Boxes

If you give **EasyCAD** a command it does not understand, or if the program needs to alert you to a potential problem, a mid-screen window or message box appears containing **EasyCAD**'s message. Choose the **OK** button or press **ENTER** to clear the message and go on with your work.

Depending upon the context of their appearance, Message boxes can also be called Alert boxes or Warning boxes.

Dynamic Cursors

For some commands that position or construct entities on the screen, **EasyCAD** displays special *dynamic cursors* that show you exactly how the new entities will look. Dynamic cursors typically appear as moveable “ghost” or white outline copies of your entities.

The command line will display “[**SHIFT=move CTRL=scale CTRL+SHIFT=rotate**]” to let you know that you are in a dynamic cursor mode. Whenever you see the “[**SHIFT=move CTRL=scale CTRL+SHIFT= rotate**]” prompt, you can use the **SHIFT**, **CTRL**, and **ARROW** keys as shortcuts to further modify some of these commands.

For example, draw some text by typing “**TEXT**” at the command line (from the menu, you can alternatively select [**Draw > Text > Single Line**]). Type in anything for text and it appears on the screen as you type. Before placing the text the command line prompt reads “[**SHIFT=move CTRL=scale CTRL+SHIFT= rotate**]”. Try moving the mouse while holding down the following key combinations:

SHIFT: typically lets you dynamically **reposition** text and centers of conic entities like circles, arcs, etc.

CTRL: lets you dynamically **resize** (or scale) entities.

CTRL+SHIFT: lets you dynamically **rotate** entities.

ARROW keys: dynamically rotate at **0°**, **90°**, **180°**, and **270°**.

Selecting Entities

Whenever you invoke an editing command, you first tell **EasyCAD** what you want to do, and then you pick the target objects. This second step is called entity selection.

EasyCAD uses an efficient and flexible method of selecting entities. It requires considerably fewer keystrokes than entity selection methods used in previous versions of **EasyCAD**, yet provides more powerful refinement. Configuration options let you determine the startup behavior.

EasyCAD lets you select entities by directly picking them, or drawing a window around or through them. By holding down the **SHIFT** key, you can de-select entities using the same process.

Importantly, entities are also selectable by their entity properties. In other words, you can select entities by their color, or by their layer, or by almost any other identifiable property that you'd find in an entity's **LIST** window. This feature, and the ability to combine selections, are what make **EasyCAD**'s entity selection process very powerful. For instance, you can select all red circles on the layer named "**PLAT**".

Note again that the selection process follows the command process. First you choose the command, and then you choose the items you wish to apply that command to. This verb-noun sequence works the way you would verbalize it (in English, that is). For instance, if you want to erase a line, you first choose the **ERASE** command, and then select the line you wish to erase.

The General Process

As always, watch **EasyCAD**'s command prompts after you start a new command. The prompts guide you through every procedure you might encounter. After invoking an editing command, **EasyCAD** displays the following prompt:

Select entities (H=help) [0 selected]:

Whenever you see this, **EasyCAD** is asking which entities you want to copy, edit, move, etc. At any time during the selection process, you can press '**H**' to display the selection help screen. Or you can right-click to display the *Entity Selection popup menu*. Both the help screen and the popup menu provide options to complete, quit, or refine your selection.

Notice too that the cursor changes to a '**pick box**'. To specify individual entities for selection, simply click directly on them, making sure that part of the entity is in the pick box aperture. **EasyCAD** provides you with a method to change the *aperture size* from the [**Specs > Options**] dialog box. As entities are selected, they are redrawn in the marking color (**gray be default**). You can continue picking individual entities. The prompt displays a running count of the number of selected entities.

If you select a point that does not contain a valid entity, the cursor changes to a selection window. Like drawing a box, you can pick an opposite corner to define a selection rectangle. Any items within or crossing the selection window get selected.

You can hold down the **SHIFT** key and *de-select entities* by picking or drawing windows around them.

When you right-click, you can confirm, cancel, or refine the selection.

Confirming the selection

When you are done selecting entities, you must let **EasyCAD** know. As soon as you do, **EasyCAD** immediately continues with the requested command, affecting only those entities you have selected.

To confirm your selection, right-click and choose **[Do It]**. The right-click causes display of the *Entity Selection popup menu*, and the **[Do It]** option is located at the top of the menu. Optionally, you can also type ‘**D**’ at the command line.

Refining your selection

This method works fine for visually picking entities on the screen. But how do you refine the selection by specifically including or excluding entities based on their properties (like **color**, **layer**, etc.)? **EasyCAD** provides very powerful selection refinement options.

Entity Selection options

The Default Selection Method

EasyCAD defaults to a *popup menu* selection method. In this mode, you select entities with picks or a selection window, then right-click to confirm (“**Do It**”) or refine the selection via the *popup menu*. In the following ways, the *popup menu* option provides you with the most versatility:

- **Multiple Each** allows you to select entities with consecutive picks.
- It allows you to **de-select entities** if you hold down the **SHIFT** key while selecting a previously selected entity.
- If you do not pick a valid entity, then the pick cursor transforms into a *selection window* picking all entities that cross the window..
- If you toggle **OFF** the “**Enable entity-select right-button popup menus**” option in the *Options dialog box* [**Specs > Options**], you can immediately confirm your selections with a right-click with no further refinement.
- You can refine your selections quicker by using key equivalent intercepts for *popup menu* mode (even when the menu isn’t visible). These work by typing the shortcut key: **A=All**, **P=Prior**, **C=Color**, **L=Layer**, **S=Line Style**, **F=Fill Style**, **T=Entity Type**, **B=And (both)**, **O=Or**, **M=Dimension Style**, and **D** for **Do it** to end the selection with no menus or dialogs.

Automatically “DO IT”

You can configure **EasyCAD** to eliminate the **right click/Do it** sequence altogether. In this mode, you simply pick or window the selected windows (using **SHIFT** to de-select, if necessary), then right-click to confirm selection.

To configure **EasyCAD** in this manner, run the **OPTIONS** command [**Specs > Options**] and uncheck the “**Enable entity-select right button popup menu**” checkbox.

You can still access the advanced selection options by using the keyboard. For instance, if you wish to select all entities, simply press the **A** key at the “**Select entities:**” prompt, and then right-click. You can still combine selections using hot keys, and you can display the entire selection palette by pressing the **H** key.

Deselecting with SHIFT

If you hold down the **SHIFT** key and pick a previously selected entity, it deselects. Holding down the **SHIFT** key temporarily activates the [**Not**] mode. Deselected entities return to their normal color.

Entity Selection color

EasyCAD allows you to change the entity selection (or marking) color. By default, the marking color is set to a light gray, which may be difficult to see when using similar background colors.

To change the marking color, type **MCOLOR** at the command line:

The prompt reads “**Color value [dialog]:**”. To change the color:

- Type in a new color number (**0-255**);
- Pick a color directly from the Color bar, or;
- Right-click and select a color from the **256-color Select Color dialog**.

The next time you use a command requiring entity selection, the selected entities will display in the new marking color.

This setting is saved in the registry, so it persists from one session to the next.

Note: This command is not on the standard menu.

Text equivalent: **MCOLOR**

Changing pick box aperture

When you pick entities, **EasyCAD** provides a pick box cursor. Any entities that are within or cross through the pick box are selected. The default size of the pick box is **4x4 pixels**. You can adjust the aperture size to suit your screen resolution, or the precision level of your work. To do so, use the **OPTIONS** command [**Specs > Options**] and specify a new in the “Pick Aperture size” window. The pick box is always square.

Advanced Entity Selection

EasyCAD provides many powerful options to the entity selection process.

Whenever you invoke an editing command, **EasyCAD** needs to know which entities you want to modify. You accomplish this through entity selection. In basic entity selection, you pick or draw windows around entities, and then right-click and **[Do It]**.

Review basic entity selection

However, **EasyCAD** lets you refine or filter selection so that only a specified range of entities are selected, without even having to actually pick or window entities on the screen. The specified range can be very wide (e.g., all the entities) or very narrow (e.g., yellow circles on layer “Conduit”). Many of these options are based on entity properties, such as color, layer, fill style, etc. You can inspect the properties of any entity using the **LIST** command.

The advanced options are listed in the right-click *Entity Selection popup menu*. These options are explained in more detail in the *Selection Hot Keys help dialog*.

Combine selections with logical operators

You can use the logical operators **Both (And)**, **OR**, and **NOT** to refine your selections until they include only the entities you want to edit.

The use of these operators may initially be confusing. For instance, if you want to select all green entities and all circles, you would use **[Color] green [Or] [Entity Type] 2D Circle**. Contrary to what you might have expected, you use **[Or]** instead of **[Both (And)]**. To understand why, consider how **EasyCAD** selects entities. It scans the entire drawing and looks for entities that are green or circles. If you had used **[Both (And)]** instead, then **EasyCAD** would have selected only the green circles. Anything not **BOTH** green **AND** not a circle is excluded. **EasyCAD** scanned the drawing, searching for entities that were **BOTH** green **AND** circles. **[Not]** works as you would expect. **[Not]** excludes any entities matching the criteria.

Mathematically speaking, logical operators tell **EasyCAD** to apply two (**or more**) tests and compare the results. If you use **[Both (And)]**, entities must pass all the tests to be included in the selection. If you use **[Or]**, entities only need to pass one of the tests. If you use **[Not]**, only entities that do not pass the test are included.

To use the Both/Or/Not operators, select one or more entities using any method, then choose **[Both (And)]**, **[Or]**, or **[Not]** and select using different criteria. To speed things up, you can bypass the popup menu by typing the hotkey equivalents. The hotkey shortcuts are as follows:

B Both (And)

O Or

N Not

Examples:

You might need to erase everything within a selection rectangle (**window**) except for a certain line. During the selection process, first draw the selection window, choose [**Not**], and then pick the line.

You might need to rotate all green text entities on layer “**Standard**”, but not green text on other layers. Select by [**Color**] green, [**Both (And)**], and [**Entity Type**] “**2D Text**”, [**Both (And)**], and [**Layer**] “**Standard**”.

You might want to move all red entities on “**layer1**” and all text on “**layer1**” to another layer. Use the **CHANGE > LAYER** command. Then during the selection process, select by [**Color**] red, [**Or**], [**Entity Type**] “**2D Text**”, [**Both (And)**], [**Layer**] “**layer1**”.

In most cases, you could accomplish these tasks by selecting entities one by one or by repeating the editing command—the logical operators just make your work quicker and easier.

Entity Selection popup menu

During the entity selection process, you can right-click to display the *Entity Selection popup menu*. Use this dialog to refine your selection, either by isolating selection to meet specified criteria, or combining the current selection with other criteria.

You can suppress display of the popup menu by selecting the **OPTIONS** command [**Specs > Options**] and *unchecking* “**Enable entity-select right button popup menu**”. In this mode, a right-click acts as a [**Do It**].

Entity Selection popup

[**Do It**] Ends selection and lets **EasyCAD** proceed with the command, processing the entities you have selected.

[**Cancel**] Cancels both the selection process and the current command. **EasyCAD** returns you to the “**Command:**” prompt.

[**Continue**] Closes the popup menu and continues pick/window selection.

[**Both (And)**] Restricts the selection. Selected entities pass both the first and second criteria. When you choose [**Both (And)**], **EasyCAD** requires another set of selection criteria.

[**Or**] Adds to the selection (**default behavior**). Selected entities pass either the first or second criteria. When you choose [**Or**], **EasyCAD** lets you add another set of selection criteria.

[**Not**] Restricts the selection. Entities selected with [**Not**] are excluded from selection.

[**All**] Select every selectable entity in the drawing, including those *outside the current view*. Entities on *frozen* and *hidden layers* are not affected, unless they are part of

groups that include visible entities. *Because groups cannot be restricted by layer, groups are always selected using All. Entities on hidden sheets are never selectable.*

[Prior] Select the entities used by the last successfully completed drawing, editing, or copying command so you can perform a series of operations on a collection of entities. Previous copy commands do not include the original entity in this selection.

[Window] Forces selection window (overrides pick), even if the first point contains a valid entity pick. Otherwise, draw a selection window as normal.

[Color] Select by primary entity color. The prompt reads “**Color value [dialog]:**”. To specify the selection color: Pick a color from the *Color bar*; type a **color ID #** and press **ENTER**. Right-click to display the **256-color Select Color dialog**. Pick a color, then click **OK**.

[Layer] Select by *layer*. Entities on frozen layers are not selected. To specify the selection layer, type a *layer name* or **ID #** and press **ENTER**. Right-click to display the *Select Layer dialog*. Pick a *layer name*.

[Line Style] Select by *line style*. To specify the selection *line style*, type a *line style name* or **ID #** and press **ENTER**. Right-click to display the *Select Line dialog*. Pick a *line style*.

[Fill Style] Select by *fill style*. To specify the selection *fill style*, type a *fill style name* or **ID #** and press **ENTER**. Right-click to display the *Select Fill Style dialog*. Pick a *fill style*.

[Entity Type] Select by *entity type*. **FastCAD** displays the *Select Entity Types dialog box* listing all available entity types. Click the checkbox next to *entity type* you want to edit and click **OK**.

[(Y) Font] Select text by *font*. Only applies to text entities. To specify a selection font: Type a font name or **ID #** and press **ENTER**. Right-click to display the *Select Font dialog*. Pick a *font*.

[Text Style] Select text by a defined *text style*. Only applies to text entities. To specify a selection font, type a *text style name* or **ID #** and press **ENTER**. Right-click to display the *Select Text Style dialog*. Pick a *text style*.

[Dimension Style] Select by dimension style. To specify the selection dimension style: Type a line style name or **ID #** and press **ENTER**. Right-click to display the *Select Dimension Style dialog*. Pick a *dimension style*.

[Entity Tag #] Select by an entity’s internally generated *tag number*. Tag numbers are transparently assigned to new entities as they are created. Choosing by tag # is usually useful only if you have already determined the target’s **tag #** using the **LIST** command [**Info > List**]. This method of selection can be helpful for choosing otherwise

difficult to select entities. For instance, this is the only way to select one line for erasure if you copied it directly onto itself.

[Entity Type #] Select by *entity type number*. This works similarly to **[Entity Type]** except that the type is specified by the **type #** rather than a dialog. Each entity type (line, circle, etc.) has its own unique type #.

[(Z) Sheet] Select by *sheet name*. To specify the *sheet*, type in the name and press **ENTER**, or right-click and pick a name from the *Select Sheet dialog*. **Entities on hidden sheets are never selected.**

[Help] Display the selection *Help dialog*.

General Concepts

The building blocks to creating CAD drawings...

EasyCAD is one of the easiest **CAD** programs you'll ever have the pleasure of using. Like a good tool, **EasyCAD** is designed to help you get the job done, without forcing you to expend excess time and energy figuring out how to use it.

Admittedly, **EasyCAD** is a bit more complex than a hammer or pair of pliers—maybe *quite* a bit more if you're totally new to **CAD**! But ultimately, it's more forgiving than using a pile of T-squares, triangles, protractors, pencils, and erasers, and it will likely change your whole approach to creating and modifying drawings.

Think of your drawing screen as a sheet of graph paper, with one critical exception: the **EasyCAD** drawing screen is virtually unlimited in size. Until you print your drawing, you never have to worry about scale. If you want to draw a line that's two inches long, draw a two inch line. Do you want to add a three hundred foot line to the same drawing? Go ahead and add it...full size! It all fits because you continually zoom in and zoom out to navigate your drawing. You can peer into the most minute detail, then a moment later see a bird's eye view of everything.

If you can grasp that simple concept, then most of the battle is won.

In the last chapter, you learned about the specific screen components. In this chapter, the concepts are broader and usually applicable to every action you perform in **EasyCAD**. For anyone who is an old hand at **CAD**, this chapter may seem rather fundamental. But if **EasyCAD** represents your first experience with **CAD** software, this primer might help.

- **Entities** are the things you draw, such as **lines**, **circles**, **text**, etc.
- **Units** are the basic measuring unit in your drawing. Appropriate units should be determined and set before any entities are added to your drawing.
- **Coordinates** are how locations in your drawing are addressed.
- **Bearings and angles** can be measured and input using different conventions.
- **Navigating your drawing screen** using zoom commands is a vital **CAD** fundamental.
- **Layers** help organize your entities and what you see.
- **Precision drawing tools** ensure your drawings are accurate yet easy to create.


Entities

Each **EasyCAD** drawing is made up of any number of *entities*. This term refers to anything that is included in your drawing, such as **lines**, **circles**, **text**, and **dimensions**. Usually, your entities are visible, but they could be intentionally hidden from view. Using the pencil and paper analogy, an entity is anything you would draw. Each **EasyCAD** drawing file is basically a sophisticated database of entities.

Just some of the entity types **EasyCAD** makes available to you are:

<i>lines</i>	<i>points</i>	<i>circles</i>	<i>ellipses</i>
<i>arcs</i>	<i>polygons</i>	<i>text</i>	<i>multipolys</i>
<i>paths</i>	<i>splines</i>	<i>arrows</i>	<i>dimensions</i>

EasyCAD allows you to draw these entities with precision and flexibility. For instance, there are six different ways to draw an arc. Don't let this overwhelm you — you may only use two methods 95% of the time, but the other methods are available should you need them.



In this simple example, there are nine entities (not counting the border):

Lines (6) make up the side view on the left.

The front view is made from a regular polygon (1) and circle (1) entity. They have been combined into *multipoly* and filled.

The dimension entity (1) makes nine.

You can combine entities together into **groups**, so they act like a **single entity**. A primary feature of **CAD** is its ability to save groups of entities for use over and over again. **EasyCAD** lets you create **symbols** and **parts** for this purpose.


Compared to the paper method, **dimensioning** is a task made much easier by **CAD**. When you add **dimension entities** to a drawing, **EasyCAD** automatically calculates the length of the selected distance and adds it to your drawing. **Dimensions** can be applied to **length**, **angle**, **radius**, and **diameter**.

You can manipulate, or **edit**, any entity. **EasyCAD** provides a wide arsenal of editing commands for this purpose.

You can easily **scale** and **rotate** your drawing entities with **CAD**. Or, let's say you have drawn the perfect floor plan and want to create a **mirror image**. **EasyCAD** can make use of your original image to eliminate the need to draw the same image again.

Units

EasyCAD measures **coordinates** and **distances** with a user-definable system called **units**. **Unit** is a general name for a type of measurement. **Feet**, **inches**, and **meters** are common examples of **units**, but you can create your own, like **miles**, **microns**, or **parsecs**.



Units dialog box


Determine suitable **units** before you start drawing entities. Think of your drawing as a life-size model. For example, if you design a bridge, you might tell **EasyCAD** that each **unit is equal to one foot** before starting your drawing. For a machine tool, you might set your **units** to **inches** or **millimeters**. Each time you plot the drawing, **EasyCAD** reproduces (**prints/plots**) your design at whatever **scale** you choose when you **print** it.

Dimensions are expressed in the **units** you select.

When you start a **new drawing**, **EasyCAD** assumes that **one unit is equal to one inch**. You can set a different value using the **UNITS** command in the the *Specs menu*. **EasyCAD** also provides a facility for file **templates**, which lets you pre-set almost all new drawing properties, including **units**.

You should always draw at **full scale**. The only time you should be concerned about **scale** is when you **PRINT** your drawing. You will tell **EasyCAD** what distance to **print** on the paper and what distance it represents in the drawing such as **a 1/4" line printed on the paper represents or equals a 1 foot line in the drawing**. This is commonly called **quarter scale** in architecture.

Coordinates



Cartesian coordinate system

Each position in your drawing has its own unique address, composed of an **x** (**horizontal**) and **y** (**vertical**) value. To find specific locations, or coordinates, **EasyCAD** measures the **horizontal** and **vertical** distances from a **common origin**. The coordinate address is written with a comma between the two numbers, like this: **x,y**. Mathematicians call this the “**Cartesian**” **coordinate system**, after **Rene Descartes**, who developed it in the 17th century.

When you create a new drawing, coordinate **(0,0)** is located at the lower left of your screen. Coordinate **(0,0)** is called the **origin**. Coordinate **(1,1)** is **one unit up** and to the **right** of this point, while coordinate **(-1,-1)** is

below and **to the left** of the **(0,0)** point. In the illustration, the point is **three units** in the **x** direction, and **2 units** in the **y** direction: **(3,2)**. As you add to your drawing, it can extend in all directions from the **origin**.

Entering Coordinates

When **EasyCAD** asks you to select a point for a drawing or editing operation, you can do it one of three ways, mixing methods within a single command for maximum efficiency and convenience.

- **Mouse**—Move the cursor to a screen location with the mouse, then left-click.
- **Numeric coordinates**—You can type the exact coordinates at the keyboard, using **absolute**, **relative**, **polar**, or **relative polar** coordinates. To enter numeric coordinates, type a pair of numbers separated by a comma, with no space between the characters.
- **Modifiers**—Select an item from the **Mod menu**, then use the cursor and left button to select an existing entity. **EasyCAD** locks the cursor to a specific point (**center**, **endpoint**, etc.) on the existing entity. See the section on **Mod menu** in Chapter 15.

Four kinds of numeric coordinates give you precise control over where an action takes place in your drawing. **EasyCAD** measures absolute coordinates in units from the **(0,0)** point in your drawing, while the other three kinds are measured from the **reference point (the last point used in drawing an entity, or the last point selected in an editing operation)**.

EasyCAD can display the **current cursor position** on the **Status bar**. This function is called “**tracking**”. Just click on the **Tracking window** to cycle through the four tracking modes.


1. **Absolute coordinates** are simply **Cartesian coordinates**, counted in **FastCAD** units from **(0,0)**. Enter them by typing a pair of numbers separated by a comma (with no spaces between the characters). For example: **6,7**.
2. **Relative coordinates** tell **EasyCAD** to draw from the reference point (last selected point) to a coordinate location a relative x,y distance away. Type the “**at**” sign (**@**), followed by the **x,y distance** to the desired point. For example, start a line at coordinates **(3,2)**. Type “**@3,5**” to finish the line at **(6,7)**. **EasyCAD** draws the second point three units to the right and five units up from the first point. Use negative numbers to indicate movement down or to the left.
3. **Polar coordinates** use a **bearing angle** and **distance** (rather than a pair of x,y coordinates) to select a location in your drawing. To use **polar coordinates**, enter the “**less than**” sign (**<**), **an angle**, **a comma**, and **a distance**. For example, “**<90,2**” tells **EasyCAD** to place a point **90° (direction)** and **two units (distance)** from the last selected point.

Here's a real life example of **polar coordinates**: When you give driving directions to a friend over the telephone, you might say: “At the gas station, turn north and travel two miles.” In **EasyCAD**, the “gas station” is the reference point (last point used in drawing or editing), “north” is **90°**, and two miles could be two units in the polar coordinate **<90,2**.

4. **Relative polar coordinates** are like polar coordinates except that you use a **tilde** (**~**) instead of the “**less than**” sign (**<**), and **the angle you enter is relative to the angle defined by the last two points you used**.

For example, suppose you just drew a line from coordinate **(1,1)** to coordinate **(1,3)** — a vertical line two units high, with an angle of **90°**. If you are still in the **LINE** command and type “**~90,1**” the resulting line has an angle of **180° (horizontal)** and is one unit long.

To continue our real-life example, you might tell your friend to “turn left and go one mile.” If he or she had just driven two miles north, turning left (**~90**) would mean heading west (**180°**).



Using the diagram to the left, we can see how different coordinate systems can refer to the same point.


Absolute: Point A is at (6,7) and Point B is at (3,2).

Relative: Point A is at **@(3,5)** relative to Point B(3,2). To obtain absolute A, add B + @A = (3+3, 2+5) = (6,7)

Polar: The angle from (0,0) is to A 49.4°. The length is 4.61. If we were drawing a line from (0,0) to A, we'd enter the second point as **<49.4,4.61**.

Relative Polar: The angle from (0,0) to B is 33.7°. The angle from B to A is 59.0°. The relative bearing is 59.0-33.7 = 25.3. The distance from B to A is 2.92. So if we drew a line from (0,0) to B, and then to A, we would enter the third point (from B to A) as **~25.3,2.92**.

Bearings and Angles



Measuring angles

In **EasyCAD**, angles range from 0° (zero degrees) to 360° , measured counterclockwise from 0° at “3 o'clock”.

You can use decimal fractions to specify angles precisely. Angles can be negative, in which case they are measured clockwise. In other words, -45° is the same as 315° .

EasyCAD uses this system of angles for many commands, including **ROTATE** and part/symbol insertion.


EasyCAD uses this system of angles (also called bearing angles) for the **ROTATE** command, for inserting Text, Parts, and Clipboard items at an

angle, for polar coordinates and for the **ANGLE TO** and **BEARING** modifiers. Use the **BEARING** command [**Info > Bearing**] to find the angle of an imaginary line between two points.

DMS and Surveyor Bearings

You can also specify **angles** or **bearings** in terms of **degrees/minutes/seconds (dms)**. To do so, use the appropriate unit indicator after the decimal value:

<degrees> <d|D|°> <minutes> <m|M|'> <decimal seconds> <s|S|''>



Measuring dms and surveyor bearings

Examples of degree/minute/seconds.

- 10d3m2s (10 deg, 3 min, 2 sec)
- $10^\circ 3' 2''$ (10 deg, 3 min, 2 sec)
- 10D3M2.75S (10 deg, 3 min, 2.75 sec)

Surveyor bearings are used by architects, cartographers, etc., to express direction. Direction is referenced from the north-south compass axis (positive y-axis is “north”). They are expressed in dms format using a **N/S prefix** and an **E/W suffix**.

To use **surveyor bearings**, use the same format as dms input with the appropriate compass reference:

<N|S><degrees><d|D|°><minutes><m|M|'><decimal seconds><s|S|''><E|W>

Examples of surveyor bearings:

- N10d4m3sE
- S10d4m3sW

Entering Distance Values

Many drawing and editing commands ask you for distance values, such as a **coordinate pair**, **radius**, or **text height**. When you enter a measurement of distance in **EasyCAD**, you can:

1. Type the measurement in **EasyCAD** units, or **decimal fractions** of **units**. Some examples:
 - **Absolute coordinates** **3.5,2**
 - **Text height** **.75**
 - **Radius of a circle** **3.375**
 2. Type the measurement in conventional **fractions** of **units**, using a **plus sign (+)** to separate whole numbers from fractional parts. Do not include spaces in the value or coordinate pair. Some examples:
 - **Absolute coordinates** **3+1/2,2**
 - **Text height** **3/4**
 - **Radius of a circle** **3+3/8**
 3. Type the measurement in **feet-and-inches**. Use an **apostrophe (')** for **feet**, and a **quote (")** for **inches**. Do not include spaces in the value or coordinate pair. Some examples using feet and inches:
 - **Absolute coordinates** **3'6",24"**
 - **Text height** **9"**
 - **Radius of a circle** **3'4+1/2"**
- EasyCAD** automatically converts from **feet** and **inches** to whatever unit system you have defined. For example, if drawing **units** are defined as **FEET** and you type coordinates **(24",18")**, **EasyCAD** converts it to **(2,1.5)**.
4. Single values like **radius** or **offset**: Select distance visually. For example, instead of typing a value for diameter, use the cursor and left button to select a point anywhere on the screen. Now the prompt reads "**Distance to:**". Use the cursor to select another point at the desired distance from the first point. **EasyCAD** measures the distance between the two points and uses that value, just as if you had typed it.

Entering Displacement Values

EasyCAD often asks you to indicate movement through displacement. Commands like **MOVE** and **STRETCH** ask for "**from:**" and "**to:**" points. When prescribed, the reference manual topic for the calling command details the steps and options for entering displacement.

Navigating the Drawing Screen

Think of the computer screen as a camera view of your drawing. You can zoom in, allowing you inspect the tiniest detail. Or you can zoom out, letting you survey the entire drawing. At any zoom level, you can pan your view.

EasyCAD allows two basic mechanisms for panning:


- **Dynamic panning**, which locks screen view to your mouse movements.
- **PAN** or **ZOOM CENTER** commands, which let you displace or center the view about a selected point.

Three other zoom commands will see frequent use in your drawing sessions. **ZOOM EXTENTS** zooms out to include everything visible in the drawing (**entities on hidden layers or sheets are never shown**). The extents view is a good starting point for a **ZOOM WINDOW**. The **ZOOM WINDOW** command lets you draw a zoom box on the screen; the view magnifies to that box. To quickly toggle between two views, you can use the **ZOOM LAST** command. These **zoom** commands have icons on the *Standard Icon* bar for quick access.

For ultimate view control, you can *save named views* and recall them. *Named views* can be handy when you *print* your drawing.

Layers

Layers are like **transparent, overlapping sheets** that you can use to organize your drawings. For example, you could assign one layer of a house blueprint to structural members, another to electrical work, and a third to plumbing details. **EasyCAD** provides an unlimited number of layers that you can descriptively name.



This before-and-after example shows how the furniture items can be quickly hidden from view. The chairs, tables, and plants were drawn on a unique layer. When that layer is hidden, the furniture disappears from view. They still exist though, and can be made to reappear just as easily.

Multiple layers simplify editing of complex drawings. **EasyCAD**'s editing commands let you select or exclude entities by layer. You can also protect layers by hiding or freezing them.

- **Hidden layers** don't show on-screen or when you plot your drawing. In the blueprint example, you could hide all but the second layer to see just the electrical work.
- **Frozen layers** are **write-protected**—you can see and refer to entities on a frozen layer, but you **can't erase them or modify them**.

Use the **LAYER** command to **add, delete, hide, show** or **make current** any layer.

Precision Drawing

While drawing with the mouse or other input device may be a good starting point, eventually you will want some shortcuts to more precise control of the distances in your drawing.

EasyCAD gives you many tools to help with precision:

Grid and Snap **EasyCAD** can display a **grid** of dots to help you keep track of relative distance and size. **EasyCAD** grids can be set on linear or circular patterns. Once you have set up a **grid**, you can choose to have the **cursor snap** to the nearest grid point. **Grid** and **snap** functions can be turned on or off at any point.

Switches give you **on/off** control over certain aspects of your drawings. These are usually manifested in the form of buttons, but they often can be toggled by using commands or key combinations. For instance, you can temporarily force new lines to be **horizontal** or **vertical** by choosing the *Ortho* button on the *Button bar*, or by typing “**orthon**” or “**orthoff**” at the command prompt. Most switches can be activated in the middle of another command. For instance, you could start drawing a line, choose the *Ortho* button, and then finish drawing the line.

Modifiers are issued *within* commands to refer to existing entities, removing any guesswork or approximation. You can select the mathematically exact endpoint of a line, center of a circle, etc. Modifiers help you connect new entities to existing ones and edit with precision. Select **modifiers** from the *Mod menu*, or by using the appropriate key combination. See *Chapter 16: The Mod menu* for more detail.

File Commands

Managing your drawing files

The **File** menu includes general commands for managing drawings and other files.

Use the **OPEN** command to convert single files "on the fly" from other formats into **EasyCAD**. You can import **AutoCAD DXF** or native **DWG** drawing files, as well as **FCW** drawing files created in **FastCAD/EasyCAD 32 v5.215**, and **FCD FastCAD/EasyCAD DOS** drawing files.

You can use the **SAVE AS** command to save your current drawing to any supported format.

If you have many files to import/export, use the **CONVERT** command to convert entire directories from one file format to another.

EasyCAD v7 has multiple file capability. You can open multiple files independently of each other, or as *overlays* or *references*, so that they share the same coordinate space.


In addition to file commands, the File menu also displays the **File History**, which displays the last four files you have saved. Select any file on the list to load it into your current **EasyCAD** session.



*The **NEW DRAWING** command [File > New Drawing] closes the currently loaded drawing, and opens a new, blank drawing named **WORK.FC7**. If the drawing to be closed has been modified, **EasyCAD** asks (with an alert box) if you want to save the current drawing before creating the new one. All drawing properties (like text and dimension specifications) are reset to that of the *current template*.*

Use the **SAVEAS** command [**File > Save As**] to give the new "**WORK.FC7**" drawing a unique name.

*Text equivalent: **NEW***

Open**Open Drawing**

*The **OPEN** command [File > Open] loads a previously saved drawing. FastCAD displays the standard **Load Drawing** dialog box, which lists available drawings of the file type you specify. To load a file, select a drawing filename from the list and click **OK**. If you type a name not listed in the dialog, a new drawing will be created with the specified name.*

Use **OPEN** to perform "**on the fly**" file conversions from other formats to the native **EasyCAD FC7** file format. When a non-fcw file is converted, a new fcw file is created, and the original file remains unmodified. The converted file has the same file name, but takes on the .fcw extension.

EasyCAD v7 can import the following file types:

- **FCD** FastCAD/DOS 2.72+ files.
- **FCW** FastCAD 32/EasyCAD 32 files.
- **FSC** FastCAD 32 Symbol Catalog files.
- **FCT** FastCAD 32 Template files.
- **DXF** AutoCAD Drawing Exchange files up to version 2000
- **DWG** AutoCAD Drawing files, up to version 2000.

To specify a file type to import, click the Files of Type box and select a type from the drop-list. Specify the drive and path as needed. **EasyCAD** filters the list window to display only those filenames that end in the matching extension. Select a name and click **OK**. **EasyCAD** performs "**on the fly**" conversion into the **FC7** format and loads it into your current session.

*Text equivalent: **OPEN** or **LOAD***

*Keyboard Shortcut: **CTRL+O***

Files Icon Bar



The **Files Icon bar**, provides instant access to the most used commands for file manipulation. The icons from left to right are, **New Drawing**, **Open**, **Close**, **Save As**, **Print**, **Open Next** and **Open Prior** as well as five *Bookmark* icons discussed later in this chapter.

Open Next



Open Next Drawing

FastCAD maintains an internal listing of the last 10 files you've opened. You can use the OPEN NEXT icon and OPEN PRIOR icon to respectively load the next or previous drawing file in the list. The file list is maintained in the registry, so it will persist even after closing and restarting **EasyCAD** sessions.

For fastest navigation, enable the **File Icon bar** using the **TOOLS** command, then use the **OPEN NEXT** icon to load the next drawing in the list.

If you use the **OPEN** command to load a file, and it already occupies a position in the file list, your “**current position**” will be set to that file's location. For example, you successively loaded *file1*, *file2*, *file3*, and *file4*. You then load *file2*. If you use the **OPEN NEXT** command, *file3* will automatically load.

Use **bookmarks** if you need more precise or flexible control over file sequencing.

Text equivalent: OPENND

Open Prior



Open Prior Drawing

FastCAD maintains an internal listing of the last 10 files you've opened. You can use the OPEN NEXT icon and OPEN PRIOR icon to respectively load the next or previous drawing file in the list. The file list is maintained in the registry, so it will persist even after closing and restarting **EasyCAD** sessions.

For fastest navigation, enable the **Files Icon bar** using the **TOOLS** command, then use the **OPEN PRIOR** icon to load the previous drawing in the list.

If you use the **OPEN** command to load a file, and it already occupies a position in the file list, your “**current position**” will be set to that file's location. For example, you successively loaded *file1*, *file2*, *file3*, and *file4*. You then load *file2*. If you use the **OPEN PRIOR** command, *file1* will automatically load.

Use **bookmarks** if you need more precise or flexible control over file sequencing.

Text equivalent: OPENPD

Save

*The **SAVE** command saves your current drawing to disk.* Use **SAVE** frequently to protect your work from power failure or computer malfunction. **SAVE** is also the ultimate protection from undesirable changes that you might make.

If you are working with multiple files (*overlays* and/or *separate* files) and wish to save all drawings with one command, use the **SAVEALL** command.

Use this command explicitly when you complete your work. Even though **EasyCAD** provides an **AutoSave** feature, it is not a substitute for the **SAVE** command. **AUTO SAVE** only saves the *active* drawing in a file named '**AUTOSAVE.FC7**' in the **\EasyCAD7** home directory. If you have a power failure or a system crash, you must immediately restart **EasyCAD** and use **OPEN** to open the **AUTOSAVE.FC7** file. Use the **SAVE AS** command and save it over the original file name.

You cannot perform any **REDO** or **REDOA** operation after a **SAVE** or **SAVE AS**.

You can enable automatic file compression using the **OPTIONS** command.

Features and Functions that are attached to each drawing file when saved:

- Portrait/Landscape printer orientation**
- Crosshairs ON/OFF**
- Layer names and their HIDE/FREEZE status**
- Grid patterns and Grid names**
- Line styles and names**
- Fill styles and names**
- Dimension styles and names**
- View sets and names**
- Button bar settings**

*Text equivalent: **SAVE** or **CTRL+S***

Save As



Save As

*The **SAVE AS** command saves a copy of your active drawing file under a new name or format. The new drawing file becomes your active drawing. Also, use **SAVE AS** to convert the active drawing to a different format (DWG, DXF, EMF, BMP.).*

When you invoke **SAVE AS**, **EasyCAD** displays the *Rename & Save dialog* box listing existing drawings. Select an existing drawing name with the cursor, or type a new name, then click the **OK** button. If you select an existing drawing, **EasyCAD** will prompt for confirmation before replacing it.

To save the *active drawing* to a different file format, click the *drop-arrow* at the right end of the *Save as type* window and choose the desired output format from the list. **EasyCAD** will automatically attach the appropriate file name extension.

You can use **SAVE AS** to preserve progressive versions of a drawing as separate files on disk. For example, if you start **EasyCAD** with a drawing named plan1, you could use **SAVE AS** to make a copy with the name plan2 and then work on it.

*Text equivalent: **SAVEAS** or **CTRL+A***

Restore

*The **RESTORE** command restores your drawing to the last version saved.*

Before committing, **EasyCAD** asks you "Is it **OK** to discard the changes to this drawing?". If you click **Yes**, **EasyCAD** restores the drawing to its state at its last **SAVE** or **LOAD**. If you click **No**, **EasyCAD** cancels the **RESTORE** command and returns you to the drawing screen without making any changes.

You can also use **RESTORE** to reverse the effects of a **DISCARD** command, provided that you did not **SAVE** the drawing after the **DISCARD**.

Discard

*The **DISCARD** command clears all entities from the active drawing.*

When you run **DISCARD**, **EasyCAD** warns you: "This command will erase all entities in the current drawing and reset everything to the **NEW** drawing template, keeping only the drawing name. Is this what you want to do?" To confirm, click the **Yes** button. If you click **No**, **EasyCAD** cancels the command.

Until your next **SAVE** of the drawing, **RESTORE** can be used to recover the previous drawing state.


Print Setup

*The **PRINT SETUP** command enables you to configure a printer before printing a **EasyCAD** drawing.* This command is similar to the Windows **Control Panel>Printers** option. Before you *print* a drawing, you must be sure the proper driver for your printer is installed. See your Windows documentation for information about installing printer drivers and setting up your printer. Parameters such as paper size, orientation, print resolution, and others (**depending on your printer**) can be specified here.

*Text equivalent: **PRINTSU***

Text Page Setup

TEXT PAGE SETUP lets you change page set up options for printing from text windows. Make your configuration choices in the *Text Page Setup* dialog.



EasyCAD displays text windows for the following commands:

- **NOTES** [File > File Notes].
- **EXTRACT attributes** [Insert > Extract Attributes];
- **LIST** [Info > List];
- **COUNT ALL** [Info > Count All];
- **COUNT** [Info > Count];
- **LIST VARIABLES** [Macros > List Variables].

Text Page Setup dialog options

Text size This controls the size of the font when printing. Choose from small/normal/medium/large. Actual font sizes may vary from one printer to the next. All text from a text window prints in one font at one size.

Line number Prints line numbers in the left margin space.

Header Prints printing information at the top of the page, such as the drawing filename, page number, and date/time stamp.

Page frame Prints a line border around the entire page (and line numbers and header if those are configured on).

Shade pg. 1 The header section of the first page is printed in a grayscale so the first page can be readily identified.

Print




Print Drawing

The **PRINT** command displays the *Print Drawing dialog box* enabling you to control how your drawing is printed. After you confirm your options and choose **OK**, EasyCAD sends your print file to the Windows print spooler, and you will be able to continue your work before the print is finished.

Note: The terms “**print**” and “**plot**” are used interchangeably.

Text equivalent: **PRINT** or **CTRL+P**

Print Drawing dialog box options



Choosing a new printer Click on the *Name* control to display a drop list of printers installed in your Windows system. Select the desired printer.

Setting up the printer Choose the *Properties* button to access the printer driver settings. The exact appearance and available options of the printer property sheet will vary for each printer model and its associated driver software.

Seeing a print preview Choose the *Preview* button to see an accurate representation of your drawing as it will appear on your paper. EasyCAD interrogates the Windows Printer Driver for information on the capabilities of the printer. Not all printers (and/or printer drivers) have the same ability to reproduce colors, fill patterns, and/or TrueType fonts.

Printing to a file Check the **Print to File** control to send output to a file. **FastCAD** displays the *Print to File dialog*, requesting a filename and destination.

Setting number of copies Type the number of copies you want to print into the **Copies** box.

Choosing the view to print You can choose to print all or a specified part of your drawing. Choose **Everything** to print the entire drawing. This includes space occupied by entities on hidden layers. (It's the same view you would see if you selected the **ZOOM EXTENTS** command or icon.) Hidden entities will not show in the printed drawing, but they do affect the print size and placement. Or choose **Active Window** to print the current view in the active drawing window. Or select a **Named View** from the drop list. The list displays all views that were named using the **SET VIEW NAME** command [**View > Set View Name**].

Scaling the printout You can choose one of two methods to size your drawing onto the page. **Fit to page** automatically scales the selected view for a best fit on your paper. Remember to set the proper paper orientation in the **Options** section of the dialog box. **Scale Factor** uses the relationship between paper distance and drawing distance to print a scaled version of the selected view, centered on the center of the view. For example, to print at “1/8th scale”, many ways to describe it exist:

- **Paper distance** = 1/8" and **Drawing distance** = 1'
- **Paper distance** = 1/8 and **Drawing distance** = 12
- **Paper distance** = 1' and **Drawing distance** = 96

Printing large drawings on multiple sheets Use the **Tiling** option to print large drawings over multiple sheets of paper. To specify the number of sheets, enter the values for **# Horiz** and **# Vert** (the total number of sheets = # Horiz x # Vert). The portrait/landscape orientation setting is honored. You can also specify the **Overlap %**. Having a small amount of overlap can help align your sheets during assembly. Use **Preview** to inspect your settings before you print. The entire print will be displayed with red lines demarcating each page's unique print elements.

Sheet Choose a sheet option for printing. Drawings constructed with **SHEETS** allow you to perform batch printing operations.

- **COMMON only (standard drawing)**
Prints one page containing only entities on the **COMMON** sheet.
- **All visible sheets as overlays (single page)**
Prints one page containing all entities on visible sheets.
- **All visible sheets as separate pages**
Prints multiple pages, each visible sheet as a page.
- **All sheets as separate pages**
Prints multiple pages, each sheet as a page regardless of hidden/visible status.

- The currently selected sheet
Prints one page, only the *current sheet*.

COMMON prints on all Choose if you wish entities on the **COMMON sheet** to be printed no matter what Sheet option you select.

Printing white colored entities Check the **Print white as black** option if your printer does not print white entities.

Printing everything black Check the **Print everything black** option to suppress color information. The drawing will print out only in black, even on color printers.

Setting Page Orientation Select the printing orientation either as **Portrait** or **Landscape**.

Bookmark commands

Bookmarks are file management aids that help you efficiently organize and navigate your drawing files. This is accomplished through the use of *bookmark files*. A *bookmark file* is simply an editable list of files that work with the **Next/Current/Prior Bookmark** navigation icons that reside on the *File Icons Icon bar*.

Additionally, *bookmarks* can be specifically created and distributed along with drawing files you send to other users. This is especially useful in conjunction with **View7**, which completely supports all **EasyCAD bookmark** features. *Bookmarks* help you control what the person viewing the drawing sees—not only which files, but also the order in which those files are viewed.


Files loaded with the *bookmark* commands replace the current drawing in memory. For example, if six files are viewed in succession using the *bookmark* commands, each load replaces the previous. In other words, **EasyCAD** will *not* open six separate files simultaneously in memory. This keeps **EasyCAD bookmark** behavior consistent with **CADView7** (which does not support multiple files).

Bookmark files are saved as **.BKM** files. They are regular text files that can be viewed, created, or modified with any regular text editor.

EasyCAD v7 contains commands needed to either use or create *bookmark files*.

To Use Bookmarks

To simplify *bookmark* navigation, use the **TOOLS** command [**Specs > Screen Tools...**] to activate the *File Icons Icon bar* by clicking the desired placement arrow box. There, you will find *icons* that let you navigate and manage your *bookmarks*.



To Create or Edit Bookmarks


Use the **BOOKMARK** command (or choose the *Bookmarks* icon) to display the *Bookmarks dialog*. This permits creation or modification. You can manually *order* the files in the *bookmark* list, or you can *add* or *delete* files.

Edit Bookmarks

To *create* or *modify* a *bookmark* file, start the **BOOKMARK** command from either the **Menu bar** [**File > Bookmarks > Edit Bookmarks...**] or the **Files Icons Icon bar**. Doing so will display the *Bookmarks dialog box*. Use the *Bookmarks* dialog to perform all modifications to your *bookmark file(s)*.

Bookmark files are saved with a *.bkm* extension. A **.BKM bookmark file** is a regular text file that simply consists of a list of files (exactly as shown in the *Bookmark dialog* when **Show file paths** is toggled on). Therefore, you can use a regular text editor, such as **NED**, to create or edit a *bookmark file*.

Also use this command to quickly jump to a selected *bookmark file*, or to view the *bookmark* list.



Bookmark dialog box

Current bookmark file This displays the active *bookmark* list as displayed in the list window. You can load a new *bookmark file* by choosing the *New* button.

Show file paths When checked, the full path for each file, including the drive letter, is displayed in the list window. When unchecked, only the file names are displayed.

Add Current Adds the currently loaded drawing to the end position on the *bookmark* list. A file can be added more than once to the *bookmark* list.

Add Select Adds a file you select from the *Load Bookmark dialog*. You can change drives or directories and select a new drawing to be added to the end of the list. A file can be added more than once. A file you select using this method will not load into the viewer.

Add Search Lets you select files that meet matching criteria using the **SEARCH** command. Files that match the criteria are displayed in a dialog box, where they can be individually added to the end of the *bookmark* list.

Move Up Manually moves the highlighted file up one position on the list. In the illustration, doing so would move **TRAIN.FC7** between **LOGIC.FC7** and **PULLEY.FC7**

Move Down Manually moves the highlighted file down one position on the list. In the illustration, doing so would move *train.fc7* between *cmhouse.fc7* and *carlsbad.fc7*.

Delete Removes the highlighted file from the *bookmark* list. Note that deleting here only removes the filename from the *bookmark* list; it does not erase the actual drawing file from its source.

New Clears the current *bookmark file* from memory. You can then create a new *bookmark file*, or load one from disk.

Open Loads a selected *bookmark file* (ending with a .bkm extension). Select the new *bookmark file* from the *Load Bookmark File dialog*.

Save Saves the current *bookmark file* to disk, using the name shown in the *Current Bookmark* file field.

Save As Lets you save the listed *bookmark* to a different name or path.

Restore Reverts the list to its condition as it was immediately after your last *save*. It basically undoes any unsaved modifications you may have made to the *bookmark* list.

Open Selected Entry Choose to load the highlighted drawing into your **EasyCAD** drawing window. When new files are loaded via *bookmark* functions, the previous loaded file will automatically close (unless you modified the drawing, in which case you will be asked to confirm first).

Whenever a file is loaded in this manner, the *bookmark* pointer is set to the file position that you selected. The *bookmark* navigation buttons will operate from this position.

Text equivalent: **BOOKMARK**


Search Files

The **SEARCH FILES** command lets you search for text matches in drawing files without loading them first. The search can be configured to search EasyCAD v7 .FC7 drawing files in a specified directory (and in subdirectories, if desired). You can configure the search to look in any combination of *file notes*, *text entities*, and *text entities on frozen layers*.

Files that match the *search* criteria are displayed in a *Bookmark* dialog. You can *edit* and *save* the *bookmark* file.

The speed of the *search* depends upon several factors, such as the number of searched files, the size of the files, the speed of your processor, and the speed of your drives. *It is highly recommended that searches be performed only on files residing on hard disks or drives similar in performance.* Searching a floppy disk will take many times longer than searching the same files on a hard disk.

The five most recent search paths and pattern strings are saved in the registry. When the '*Search Files for Text*' dialog appears, it is initialized to the latest settings.



Search Files for Text dialog box

Search Path Enter the drive, folders, and file filters you wish to search. Use the # character (**number sign**) as shorthand for the **EasyCAD** working directory.

Search Subdirectories Check if you wish to search files contained in directories nested below the level specified in Search Path.

Search for this text Enter the text string you wish to search for.

File Notes/Text Entities/Frozen Layers Check these in combination to direct the text search. **File Notes** and **Text Entities** are actual items that are searched, while **Frozen Layers** is a refinement of **Text Entities**. If **File Notes** and **Text Entities** are both unchecked, the search will yield zero results.

Also: And/Or You can further refine your search by adding an additional search string. To do so, check the **Also** box, then specify whether the additional criteria is **And** or **Or**. If **And** is selected, *a search will yield results that contain both the first text*

and the second text. If 'Or' is selected, a search will yield results that contain either the first text or the second text.

Text equivalent: **SEARCH**

Index

The INDEX command can dramatically speed up SEARCH operations. This command creates an *index file*, *index.idx*, which can be specified as the file path in a later **SEARCH** command. The *index file* contains the information that the **SEARCH** command uses each time it is run; specifically, all text information in the targeted drawings.

When text entities are added or deleted from drawings, a new index file should be generated to keep it synchronized. The matching index file(s) for a drawing will not automatically update.

To generate an *index file*, type "**INDEX**" at the command line and press ENTER:

1. The prompt reads "**Index drive:path*.fcw:**".

Type in the drive and path specification. For instance, if you wish to index **EasyCAD** drawings on your **D:** drive, in a folder named '**job4074**', enter "**D:\job4074*.fc7**". **EasyCAD** will also process any folders contained in the target folder (subdirectories).

EasyCAD does not provide or accept default entries for this prompt.

2. **EasyCAD** generates the *index file*.

This stage can take a while if you are processing many files. The Status bar displays the progress of the indexing. The *index file* is created in the specified drive and path, with the file name *index.idx*. If this file already exists, it will be automatically overwritten.

After an *index file* is created, you may manually rename *index.idx* (it should end with an .idx extension).

File references contained in the *index* file are relative to the path of the *index* file, so it and its directory and subdirectory structure may be moved to other locations, such as a **CD-ROM** drive. You should not *index files* directly off of a **read-only** drive, as **EasyCAD** will be unable to write the *index file* to that location.

Using an index file

An *index file* is used with the **SEARCH** command. In the *Search Files for Text dialog*, the *index* file should be specified in the **Search Path** option. The **SEARCH** command then processes the *index* file, which can be much faster than processing each drawing file "on the fly".

File Notes

FILE NOTES give you the ability to attach informational notes to any drawing. Each note has a name, and more than one note can be contained in any drawing. Each set of named *notes* is saved with the drawing and can be viewed or edited after the drawing is loaded.

List Window Existing *notes* are listed alphabetically by name. To *open*, *edit*, or *delete* an existing *note*, pick a *note name* and click the appropriate button.

OK Displays the contents of the selected *note*. The *note* contents are displayed in a standard text window. From the text window, the *note* can be printed or saved to a text file. If you do not first highlight an existing *note*, **EasyCAD** will return you to the drawing screen.

Cancel Ignores changes you have made, returning to the **FastCAD** drawing screen.


Help Displays the on-line help topic.

New Creates a *new note*. First, enter a name for the *new note*. Then enter the *note* text in the standard *Edit Text dialog box*. When you click **OK**, the note is created and the dialogs close, returning you to the drawing screen.

Edit Modifies the selected *note*. The existing text is displayed in the standard *Edit Text dialog box*.

Delete Deletes the selected *note*. **EasyCAD** then closes the dialog and returns you to the drawing screen. **Note:** **UNDO** will not work with this command. A deleted *note* cannot be recovered past your last **SAVE**.


Delete All Deletes **All Notes** from the drawing at one time. **EasyCAD** then closes the dialog and returns you to the drawing screen. **Note:** **UNDO** will not work with this command. A deleted *note* cannot be recovered past your last **SAVE**.



Text equivalent: **NOTES**

Convert Files

CONVERT FILES allows you to perform batch file conversions. All files that match the file filter you choose in the **Source File Type** list will be converted to the **Destination File Type**. Choose the **Path:** button to redirect the location of either the *Source* or *Destination* files.



Convert Multiple Files dialog

If you only need to convert a single file to **.FC7**, use the **[FILE > OPEN]** command and choose the appropriate source file type.

If you only need to convert a single file from **.FC7** to another format, **OPEN** the **FC7** file, then use the **[FILE > SAVE AS]** command and choose the desired destination file type.

Text Equivalent: **CONVF**

Menu

*The **MENU** command loads a custom menu file for use with current drawing.* EasyCAD's standard *menu* file is called **ECW7.MNU**.

EasyCAD lets you select a *new menu* using the standard *Select menu dialog*. When used with the **MENU** command, the dialog displays files ending with the **.MNU** extension.

If you want to load a *new menu* for use during the entire current session (i.e., even after you load new drawings), use the **MENUD** command [**File > Set Menu**] instead.

Creating *custom menus* can greatly increase your productivity by tailoring **EasyCAD** for the way you work. If, for example, you use many circles and arcs in your work, you could build a *custom menu* file with a *menu* item for each of the seven circle and six arc commands to bypass the **CIRCLE** and **ARC** sub-menus. Another *custom menu* could call some or all of the **CHANGE** commands directly, bypassing the **CHANGE** sub-menu. If you wish, you can add these menu items to the standard **ECW7.MNU** menu file, or to a customized menu with a different name.

You can also build alternate *menus*, *scripts*, and *macros* for complex or repetitive tasks, loading them instantly. The first addition you might make to a *custom menu* (**MYMENU.MNU**) could be a line (**or menu item**) that loads another *menu*. As an example, we'll add a *menu* command to open a sample *custom menu* included with the installation, *solar.mnu*. Add the new line between **Menu** and **Set Menu** under the "**File:**" heading:

```
Menu :|MENU;  
Solar Menu :|MENU solar.mnu;  
Set Menu :|MENUD;
```

After this *menu* is saved and loaded, a click on the new *menu* item, "**Solar Menu**", will instruct **EasyCAD** to load the menu named *solar.mnu* (bypassing the dialog box).

Auto-loading menus

Any drawing can have its own custom *menu*! A *menu* file with the same name as a drawing file will automatically load with the drawing, provided the **.MNU** file is located in the same directory as the **.FC7** file. For a working example of this, open the drawing *solar.fc7* using the **OPEN** command [**File > Open**]. Note that the standard **EasyCAD menu** has been replaced by a *custom menu* named *solar.mnu* that facilitates the exploration of our solar system.

Text equivalent: **MENU**

Set Menu

*The [File > Set Menu] command loads a menu file and makes it the default for the current session. Loading new drawings will not reset the menu back to the EasyCAD standard menu (the menu file named ECW7.MNU). If you close EasyCAD, and then re-start it, the standard menu ECW7.MNU loads, not the menu specified with **MENUD**.*

The regular **MENU** command loads a *new menu* as well, but loading any new drawing resets to the *standard menu*. **MENUD** persists for the session.

*Text equivalent: **MENUD***

Script

*The **SCRIPT** command loads and runs a script file (a series of EasyCAD commands saved in a plain ASCII text file). EasyCAD displays the **Load script to run** dialog listing available *script* files (those with the type extension **.SCR**). Select a *script* with the cursor or type a *script* file name.*

Use a script to automate repetitive tasks. Scripts can include ordinary EasyCAD commands (text equivalents of the ones in the standard menu) or special programming commands.

Scripts and macros

Scripts are very closely related to *macros*. In fact, almost all *scripts* can be converted into *macros* by inserting them between the **MACRO-ENDM** block. All rules that apply to creating *macros* apply to *scripts*.

Scripts differ from *macros* in only a few ways. Each *script* resides as a separate file, while many *macros* can be consolidated into one or more *macro* files. *Scripts* run as soon as they are loaded, while *macros* run only when a *macro* name is invoked. Because *macros* can be much more easily "**bundled**," they facilitate complex tasks much easier than *scripts*, especially with regards to subroutines and other conditional branching.

For rules governing *script* creation, please see the **Macro Command Reference**.

Running scripts

To use a *script*, invoke the **SCRIPT** command. Type the name of a *script* file, or select a file with the mouse. EasyCAD reads and executes the text in the *script* file just as if you had typed it all at the keyboard.

You can use a *script* file to execute a series of EasyCAD commands, but not to define *macros*. Unlike **LOADMAC**, running a *script* does not clear existing *macros*, although it does redefine any **MACROS**, **VARIABLES**, or **LABELS** with the same names.

Automatically running scripts

After **OPEN/LOAD** or **LOADM** commands, or after loading a drawing from the **FILE** menu's recently used file list, a *script* file present with the same name as the drawing *will autorun. Autorun is disabled in View7, and does not occur when multiple files are loaded* (as *references* or *overlays*).

Text equivalent: **SCRIPT**

Macro equivalent (bypass dialog box): **SCRIPTM**

Template

EasyCAD TEMPLATE files are used as a starting point for new drawings that use units that are different from EasyCAD's default units (inches). Template files behave exactly the same as regular EasyCAD drawing files, except that they have a different extension (.FT7) that renders them less susceptible to accidental overwriting.

EasyCAD uses many scaleable properties, such as *line styles* and *fill styles*, which are dependent on the current drawing units. Switching units from **feet** to **millimeters** can drastically alter their appearance. That is why **EasyCAD** ships with two standard *templates: English (for inches) and Metric (for millimeters).*

You can store many startup conditions in a *template*, such as all your *custom style properties* (line, fill, text, dims, etc.), *screen tools options* (scroll bars, tracking, icon bars, etc.), and *multiple windows*. A *template* can contain **symbols** or a *pre-drawn border*. Basically, whatever you can store in a regular drawing, you can store in a *template*.

Using a Template

Templates are not intended to be applied to a drawing after the drawing has already been created. *Templates should be used before the file is created.*

1. To use a *template*, select [**File > Template**] and choose a *template*.
2. Immediately choose [**File > New Drawing**]. The new drawing uses the *template* as its starting point.

Creating a Template

EasyCAD ships with two default *templates: English* and *Metric*, named after the units they are based on. But you can create your own *templates* from any **EasyCAD** drawing.

1. **OPEN** the **EasyCAD** drawing you want to use as a *template* source.
2. **ERASE** any entities you do not wish to appear in your *template*.
3. Select [**File > Save As**], then select file type '**EasyCAD V7 FT7 Template**'. The only way to save a *template file* is with **SAVE AS** (the regular **SAVE** command saves only **.FC7**, not **.FT7** files), therefore, the chances of inadvertently overwriting an existing *template* are slim.

Text equivalent: TEMPLATE

AutoSave

AUTOSAVE automatically creates a backup of your active drawing in a file named **AUTOSAVE.FC7** in the \EasyCAD7 home directory. Several options are provided to adjust the timing increments and the appearance of on-screen prompts.


Usage

Important: *You must still use the SAVE command while you are working and when you end your drawing session. AUTOSAVE is a precautionary feature that in no way replaces the SAVE command. The Automatic backup is saved in a file named AUTOSAVE.FC7. AutoSave does not modify or update your original .FC7 file.*

Use the *AutoSave* menu command [**File > AutoSave**] to access the *AutoSave Options* dialog box. From the dialog, you can turn *AutoSave* on or off and adjust other options.

In order to prevent interference with running *macros* or *scripts*, *AutoSave* occurs immediately and only after user input through keyboard entries or mouse clicks. If no direct user input occurs for the duration of an *AutoSave* interval, the *AutoSave* will take place immediately after the first subsequent keyboard entry or mouse-click.

AutoSave Options dialog box



Enable AutoSave to file 'AUTOSAVE.FCW' Check this option to enable the **AutoSave** feature. The drawing in memory is saved to a file named '**AUTOSAVE.FC7**'. The original drawing is never overwritten. When this option is checked, the menu entry [**File > Autosave**] displays a check mark to remind you that it is active.

Save every *n* minutes Specify the *AutoSave* interval.

If busy, ask again after n minutes Specify the interval **EasyCAD** will wait before asking again when instructed to **Ask Later** (in the *Time to Save Your Work dialog box*).

- **Save Now**
- **Ask Later**
- **Disable AutoSave**

Prompt before saving

If you find this reminder prompt annoying, you can toggle off its appearance with this option. *AutoSave* will then operate completely in the background.

Recovering a Drawing

In the event your current drawing session unexpectedly terminates (**due to a crash, power failure, etc.**), you can recover your entire drawing up to the most recent *AutoSave*.


To recover, restart EasyCAD and IMMEDIATELY open the file AUTOSAVE.FC7 from the \EasyCAD7 home folder. Then use the SAVE AS command to save the recovered drawing with its original filename or a new filename.

*Text equivalent: **ASAVE***

Exit

*The **EXIT** command closes EasyCAD and returns you to the Windows desktop.*

If you have made any changes since the last **SAVE** of your drawing, **EasyCAD** displays the *Save Changes dialog box*:



If you do want to quit without saving, choose **NO** or type 'N'. Choose **Cancel** to return to **EasyCAD** or press **ENTER**, click the *Yes button* or type a 'Y'.

*Text equivalent: **EXIT** or **QUIT** or **END***

Clip Commands

Undo errors, and cut and paste with the Windows clipboard

EasyCAD's Clip menu contains commands commonly found in the “**Edit**” menu of most Windows programs (**EasyCAD** uses the term “**Edit**” to denote entity modification). Such commands include the undo and clipboard functions.

Undo Functions

EasyCAD includes an efficient multiple undo facility, allowing you to backtrack draws and edits up to your last ten commands, or your last save, whichever occurred last.

Clipboard Functions

The clipboard commands let you **COPY** or **CUT** all or part of your drawing to **PASTE** into other Windows applications. For instance, you can insert your drawing as clip-art into a word processing or desktop publishing program. You can use the **PASTE** command to import text you may have composed, spell-checked, and grammar-checked in a word processing application.

Undo

The Last Ten Steps

Why does EasyCAD only allow you to undo the last ten commands?

The answer lies in your computer's memory, or RAM. As you perform operations, entity modifications are buffered. For instance, if you arrayed 10,000 circles, and then erased them, EasyCAD could restore them with UNDO because the circles' properties were retained.

As you can see, if EasyCAD allowed unlimited UNDO, you could rapidly use up your computer's available memory, especially if you performed multi-entity operations on a very large drawing. If Windows runs out of system memory, a lock-up results.

EasyCAD provides a multiple level undo facility. At almost any point in your drawing, you can backtrack your steps until you reach the point of your last **SAVE**. Using the auto-repeat feature (mouse-click to repeat commands), you can sequentially see the effect of each undo.

UNDO will work successively for the previous ten (**10**) commands, or the last save, whichever is encountered first.

UNDO works on changes made to the drawing database. That is, drawing and editing operations that affect entities. As a general rule, **UNDO** does not affect changes made to the drawing environment, such as the current color and layer.

To redo an **UNDO** (undo the **UNDO**), select **REDO**. Doing so will redo the last step undone. You can continue to redo until you reach the last draw/edit you performed. The **REDO** command only works if it immediately follows an **UNDO** command. For instance, if you **UNDO**, draw a line, and then attempt a **REDO**, the **REDO** will have no effect. (In this case, the drawing database has changed since the prior **UNDO**.)

To redo a series of undo commands, use the **REDOA** command. As long as the **UNDO** commands were performed sequentially, the original commands can all be restored with **REDOA**. Like the regular **REDO** command, there cannot be an intervening command.

If you wish to toggle between the original and undone states, use the **FLIP** command. After invoking **FLIP**, you can auto-repeat by mouse clicking anywhere on the drawing. Each click will flip back and forth between the "**before**" and "**after**" versions of your drawing.

After you are satisfied with the **UNDO** or **REDO**, you can **SAVE** your drawing to compress it, permanently removing the unused versions of the entities. This is important if you've performed many drawing or editing commands that involved large numbers of entities. The database compression that automatically occurs with a **SAVE** command can free up useful chunks of memory.

Text equivalent: **UNDO**

Keyboard Shortcut: **CTRL+Z**

Redo

REDO will reverse the last command that was **UNDO**ed. If a series of **UNDOS** have occurred, you may continue to redo commands up to the initial **UNDO** by repeating the command.

Note: **REDO** only works if it is applied immediately after one or more **UNDO** commands. If another command besides **REDO** is invoked after an **UNDO**, a subsequent **REDO** will have no effect.

To undo a **REDO**, select **UNDO**. You can also select the **FLIP** command to toggle between the **UNDO/REDO** drawing states.

*Text equivalent: **REDO***

*Keyboard Shortcut: **CTRL+Y***

Redo All

Use the **REDO ALL** command to redo a series of undo commands in one step. As long as the **UNDO** commands were performed sequentially, the original commands can all be restored with **REDO ALL**. Like the regular **REDO** command, there cannot be any other intervening commands.

If **REDO ALL** was used to restore multiple **UNDO** commands, to then return to the pre-**REDO ALL** state you must invoke that number of **UNDOS**.

*Text equivalent: **REDOA***

Flip

The **FLIP** command acts as a toggle between the last **UNDO** or **REDO** command. After invoking **FLIP**, you can auto-repeat by mouse clicking anywhere on the drawing. Each click will *flip* back and forth between the "**before**" and "**after**" versions of your drawing. This action is similar to the **EasyCAD/DOS** style of single-level **undo/redo**.

*Text equivalent: **FLIP***

Copy

The **COPY** command works with the Windows clipboard. It places selected entities temporarily on the clipboard. You can then paste the selected entities into any other Windows application. Original entities remain unchanged.

EasyCAD makes three versions of data file formats available on the clipboard:

- **EasyCAD** format (**.FC7**)
- Windows Enhanced MetaFile format (**.EMF**)
- Windows Bitmap format (**.BMP**)

Don't confuse this command with the **COPY** command found in the **COPY** menu.

*Text equivalent: **CLIPCOPY** or **CTRL+C***

Cut

CUT places entities on the clipboard and then removes them from the drawing, just like **ERASE** (*Edit* menu). You can then paste the selected entities into any other Windows application.

*Text equivalent: **CLIPCUT** or **CTRL+X***

Paste

PASTE copies valid clipboard content from the Windows clipboard into the current drawing.

If the *clipboard* data consists of **EasyCAD** entities, then it will *paste* in as a **EasyCAD** *part*, using the clip data *origin* as its insertion point. *Parts* are discussed in **Chapter 12**.

If the clipboard data is *text* from a *word processing program*, for instance, **EasyCAD** converts it to a text entity, using the current text specifications. Text formatting information governing original formatting, fonts, etc., is ignored.

EasyCAD cannot import raster images from the clipboard. Raster images include file formats such as **.BMP**, **.GIF**, **.JPG**, **.TIF**, etc. Instead, use the **[Insert > Picture]** command to display **Windows .BMP** file images in your drawing.

The **CTRL+V** keyboard shortcut **PASTES** entities if the clipboard contains a drawing file, but pastes text *into the input stream* if it contains text. In other words, clipboard text will be entered at the command prompt, not as a text entity.

*Text equivalent: **PASTE** or **CTRL+V***

Clip Options

When you select **OPTIONS**, **EasyCAD** displays the *Clipboard Specifications dialog box*. You can select parameters for sizing either **bitmap** (.BMP) or **enhanced metafile** (.EMF) images. You can force output to either one of the formats.

The **bitmap** and **enhanced metafile** size parameters have relevance when using the **PASTE** command to insert your entities into other Windows applications. Some target applications have a 'Paste Special' command that allows explicit determination of the paste format (.BMP or .EMF).



Clipboard Specifications dialog box

Bitmaps **Horizontal Pixels** Sets the horizontal bitmap size. **EasyCAD** offers a default value of 200 pixels in the **X**-direction (horizontal). A value of 1 to 999 may be specified.

Vertical Pixels Sets the vertical bitmap size. **EasyCAD** offers a default value of 200 pixels in the **Y**-direction (vertical). A value of 1 to 999 may be specified.

Enhanced Metafiles **X Size** Sets the **horizontal Enhanced MetaFile size**. **EasyCAD** offers a default value of 3.0 Inches for the horizontal dimension. Note that the largest value you select for either the **X** size or **Y** size will be the size your clip entities fit into. The aspect ratio of the selected entities is never altered (that is, the entities will never appear stretched or squashed).

Y Size Sets the vertical enhanced metafile size. **EasyCAD** offers a default value of 2.0 Inches for the vertical dimension.

Inches / Cm Sets the units of measurement for the metafile only.

Options **Paint background color** Copies the opaque background color as seen in **EasyCAD**. If not checked, the copied entities will be on a white background.


Allow EMF format for CUT/COPY Forces clip output to the **Enhanced MetaFile** format. If not checked, clip output will be in the bitmap (.bmp) format. Bitmap output provides greater compatibility, particularly with older or 16-bit Windows applications. However, unless a high bitmap resolution is specified, bitmaps may appear blocky when resized.

Text equivalent: **CLIPOPT**

Chapter 6

View Commands

Controlling what you see on the screen



Use Zooms to inspect or edit large or complex drawings.

Keep your drawing in perspective

One common mistake newcomers to CAD make is drawing too much detail, because suddenly you can see something 100 times its normal size without straining your eyes.

Be aware of what will really be seen on the printout. Use the ZOOM ALL or ZOOM EXTENTS command to keep your drawing in perspective.

The **View** commands control what you see in the active drawing window. Because they allow you to navigate, survey, and see detail in your drawing, you will use these commands often in the course of a typical **EasyCAD** session.

The **Zoom** commands are especially important since they determine the relationship between the drawing and the drawing window. Like the zoom lens of a camera, the zoom commands are used to move your view closer or further away from the drawing. Although the objects appear to get bigger or smaller, their actual size does not change. This ability lets you see areas beyond your drawing's boundaries, or magnify in and see the finest details.

EasyCAD permits *dynamic panning*. This feature lets you pan or zoom your drawing view in real time, following the movements of your mouse.

A powerful feature to remember is the “**nestable**” nature of **EasyCAD**'s zoom commands. A zoom command can be activated in the middle of another command. For instance, if you start a line command and realize you need to see more detail, you may invoke a zoom command and still finish your line.

Redraw

REDRAW recalculates your drawing from the database, then redraws the screen.

When you use editing commands, **EasyCAD** erases affected entities by drawing over them in the background color before drawing the changed versions of the entities. This can leave apparent holes in other entities and in the grid. **REDRAW** cleans these holes up.

Redraws also occur automatically when you zoom, pan, resize the drawing window, change layer states, etc.

If you have a large or complex drawing that results in lengthy redraws, try using layers or sheets. Entities on **hidden layers** or **sheets** do not redraw.

Text equivalent: **REDRAW**

Customizing Working Colors

EasyCAD's default background color is black (#0). If you decide to use a new color, keep in mind that the default entity selection (marking) color is light gray (#16). If you choose a gray background color, use the **MCOLOR** command (type at command prompt) to change the marking color. Otherwise, selected entities will be difficult to see.

If you go with a light-colored background, you may want to then customize your palette so that more darker colors are available on the *Color bar*. Colors like yellow (#4) or cyan(#5) are difficult to see on a white background.

Background

BACKGROUND changes the background color for the current drawing. The new background applies only to the current drawing. Separate drawings in other drawing windows are not affected by this command. If the current drawing is visible in multiple drawing windows, all windows are updated to display the new background color.

After invoking the **BACKGROUND** command, the prompt reads "**Color value [dialog]:**". Type a **color ID#**, pick a color from the *Color bar*, or right-click to pick a color from the **256-color Select Color dialog**. **EasyCAD** then redraws the drawing window in the new color.

Typically, this command affects screen display only—**EasyCAD** leaves the background blank when you plot. Exception: if you check the **Paint background color** option in the *Clipboard Specifications dialog box* [**Clip > Options**], the background color will be retained when the selected entities are pasted into other applications.

When drawings are opened as a reference or overlay drawings, or inserted as **XREFs**, the background color of the host drawing is honored.

Text equivalent: **BKGND**

Change Origin

CHANGE ORIGIN redefines the location of coordinate **(0,0)** in the current drawing. Use **CHANGE ORIGIN** before saving a drawing for use as a part. **EasyCAD** uses the **(0,0)** point as a handle to align with the insertion point when you later add the part to another drawing with **INSERT PART**, **PART ARRAY**, or **CIRC PART ARRAY** commands in the **INSERT** menu.

When you select **ORIGIN**, **EasyCAD** displays a crosshairs cursor and the prompt reads "**Origin:**". Pick a point or by type numeric coordinates. (The center or lower-left corner of the part is usually a good choice.) **EasyCAD** moves everything in your drawing so that the specified point is at coordinates **(0,0)**.

UNDO does *not* work after the **CHANGE ORIGIN** command has been invoked.

Text equivalent: **ORIGIN**


View Names

VIEW NAMES are a drawing navigation aid that allows you to quickly display a stored *view* of your drawing. A *view name* is for a single window. Creating a *view name* is akin to taking a *snapshot* of the drawing screen, yet you retain complete drawing and editing functionality when the *view* is recalled. Note: Layer properties (hidden, frozen, etc.) are not saved or altered when using *view name*.

Each *view name* window retains its *size*, *name*, and *zoom factor* at the time it was saved, even if they are subsequently modified. If a *named view* window is closed, it will re-open when you select the [View > Zoom Named] command and you either type in the *view name* or select it from the '*Named Views*' dialog.

VIEW NAMES cannot be printed as such. However, named drawing window view can be printed by selecting the '*Named View*' in the '*Print Drawing*' dialog.

When you select the **VIEW NAMES**, command the '*Named Views*' dialog appears.



To display a view Name Simply highlight the *view name* and click **ZOOM**.

To create a view name **Zoom** to the desired view in the active drawing window. Click the *New button* and type the *view name* in the '*Rename View*' dialog. The view name can be up to 31 characters long and can contain spaces and punctuation marks. Press **OK** The *view name* will appear in the *Title bar* of the *active drawing window*.

To rename a view Select a *view name* from the *Named Views* dialog and click the *Rename button*. Type a new *view name* in the *Rename View* dialog. The default *view name* appears in the *Rename View* dialog.

To remove a view name Select a *view name* and click the *Delete button*.

Text equivalent: **VNAMES**


Set View Name

SET VIEW NAME allows you to give a name to any drawing window. The view's center, height, and width are stored with the name and can be recalled at any time using the **ZOOM NAMED** command [**View > Zoom Named**].

View names are also helpful when used in conjunction with the **PRINT** command.

To name a drawing window,

1. If more than one window is open, use the mouse and click the **Make Active Window icon** at the right end of the desired window you wish to name (or rename).



A red border appears around the *active* window. Zoom to the desired view. If only one drawing window is open it is the *active* window by default..

2. Select the [**View > Set View Name**] command. The prompt reads “**View name:**”
3. Type in a new *view name* and press **ENTER**. The *view name* can consist of up to 32 characters and contain spaces and punctuation. The *view name* appears in the *Title bar* of the *active* window.

To *delete a view name* use the **ZOOM NAMED** command, select the *view name* in the *Named Views dialog*, then click the *Delete button*.

Text Equivalent: **SVNAME**




Dynamic Pan

DYNAMIC PAN allows you to navigate your drawing in real time. When **DYNAMIC PAN** is active, the entire drawing window responds to your pointer movements. You can scroll in any direction, and by holding down certain keys, you can dynamically zoom.

To start the *dynamic pan* mode, choose the *Dynamic Pan icon* on the *Standard Icons bar*.

If you have a *three-button mouse* or a *wheel mouse*, clicking the center button or the wheel switch will activate **DYNAMIC PAN** mode. If your mouse's third button or wheel switch is configured for another option (for example, double-click or the Start menu), you must re-configure it to its "default" behavior. **EasyCAD** will not override the driver-configured function.

After you invoke the dynamic pan mode, **EasyCAD** displays a pointing  cursor. Just click and hold the left mouse button and move the mouse to drag the view within the *active* window. You can continuously specify the pan origin, which can be useful when panning across multiple screens. To re-specify the pan origin, release the mouse button and reposition the cursor. Then click-hold the left button and move the mouse again.

Remember that when you are using this command, you are never changing entity positions or sizes! The only changing element is your view of the drawing.

To end the Dynamic Pan/Zoom mode Right-click to finish dynamic panning. To cancel any view changes, **press ESC** or the "U" key before you right-click.

Other Dynamic Pan Options

EasyCAD also lets you *Zoom in* or *Zoom out* in **DYNAMIC PAN** mode.

If you press the "H" key anytime during *dynamic pan*, **EasyCAD** displays a popup Help window that describes the keystrokes required for each action:

During left-click-hold and drag:

Key down	Action
none	Pan view
SHIFT	Zoom in/out
CTRL+SHIFT	Rotate
H or ?	Help
ESC or U	Cancels this view change

Text equivalent: **DYNPAN**

Pan View

PAN VIEW shifts your drawing under the drawing window.

To pan the view, select [**View > Pan View**]:

1. The prompt reads "**Pan from [displacement]:**". The "**Pan from**" point is used in conjunction with a second point you specify to move your view. You can:
 - Pick a start point in the drawing window, or type numeric coordinates.
EasyCAD displays a rubber-band cursor anchored at the specified point.
 - Right-click to enter a displacement value. The prompt reads "**X,Y Displacement:**" Enter in a numeric coordinates. The view will change by this displacement relative to the origin and the command will terminate.
2. The prompt reads "**Pan to:**". Pick the second point in a drawing window, using the stretching cursor as a visual guide.

EasyCAD moves your drawing so that the "**Pan from:**" point appears at the "**Pan to:**" point in the drawing window.

Text equivalent: **PAN**



Zoom Window

ZOOM WINDOW lets you draw a selection rectangle or "**window**" to view part of your display in the drawing window. The specified zoom is always displayed in the current drawing window, even though you can specify the zoom box in another drawing window. The two corner points can even be in different drawing windows; the stretching cursor will show you if any pick is valid.

To zoom into a window, select [**View > Zoom Window**]:

1. The prompt reads "**First corner:**". To specify the first corner of the desired view, pick a point in the drawing window or by type in numeric coordinates.

EasyCAD changes the cursor to a stretching rectangle.
2. The prompt reads "**Opposite corner:**". To specify the opposite corner of the zoom window, use the stretching rectangular cursor as a visual guide and pick a point.

EasyCAD redraws your screen to show the part of your drawing that fits within the rectangle you drew.

Text equivalent: **ZWIN**



Zoom Center

ZOOM CENTER moves the *center* of the drawing window to a new spot in the drawing. This command has only one prompt, so it's often more convenient than **PAN**. The specified zoom is always displayed in the current drawing window, even though you can specify the view center in another drawing window.

This command does not magnify the view.

To **ZOOM CENTER**, select [**View > Zoom Center**]:

1. The prompt reads "**View center:**". To specify the center point of the new zoom, pick a point in a window, or type numeric coordinates. (**Tip:** Use numeric coordinates to shift the view center to an off-screen point.)

EasyCAD moves your drawing view to center it on the point you selected, without changing the zoom factor.

Text equivalent: **ZCEN**



Zoom In

ZOOM IN magnifies the view in the drawing window. (Entities in the drawing window appear larger, and you see less of your drawing.) As the view magnifies, the center view stays fixed.

Like *all zoom commands*, **ZOOM IN** changes the view within the current drawing window. It *does not resize the drawing window*, nor does it change the view in other drawing windows.

To **ZOOM IN**, select [**View > Zoom In**]:

The prompt reads "**Scale factor [n]:**". Type a number to indicate how much to magnify the view and press ENTER.

EasyCAD multiplies the current view dimensions by the supplied factor and zooms accordingly.

Text equivalent: **ZIN**



Zoom Out

ZOOM OUT widens the view in the drawing window. (Entities in the drawing window appear smaller, and you see more of your drawing.)

Like all zoom commands, **ZOOM OUT** changes the view within the current drawing window. It does not resize the drawing window, nor does it change the view in other drawing windows.

To **ZOOM OUT**, select [**View > Zoom Out**]:

- . The prompt reads "**Scale factor [n]:**". Type a number to indicate how much to widen the view and press ENTER.

FastCAD multiplies the current view dimensions by the supplied factor and zooms accordingly.

*Text equivalent: **ZOUT***

Zoom Width

ZOOM WIDTH tells **EasyCAD** how much of your drawing to display in the drawing window, using the specified horizontal width.

- . The prompt reads "**New view width:**". Enter a value in current drawing units (you can include decimal or conventional fractions).

EasyCAD redraws the drawing window, horizontally sized to the specified number of units.

When you create a new drawing, **EasyCAD** uses a default view width of 10.5 units, centered on coordinates (5,5).

*Text equivalent: **ZWID***

Zoom Height

ZOOM HEIGHT tells **FastCAD** how much of your drawing to display in the drawing window, using the specified vertical height.

- . The prompt reads "**New view height:**". Enter a value in current drawing units (you can include decimal or conventional fractions).

EasyCAD redraws the drawing window, vertically sized to the specified number of units.

*Text equivalent: **ZHGT***



Zoom Extents

ZOOM EXTENTS displays your entire visible drawing in the current window, shrinking or enlarging the view to fit. Entities on hidden layers are ignored.

This command is one of the most useful zoom commands available. To quickly **ZOOM EXTENTS**, click the *Zoom Extents icon* on the *Standard icon bar*.

TIP: When working with **EasyCAD**, it is easy to get caught up in unnecessary details. Sometimes it is a good idea to take a step back and view the entire drawing. This command will also show if you have inadvertently drawn or moved something out of your expected drawing area.

Text equivalent: **ZEXT**

Zoom Named

ZOOMED NAMED displays a named view you previously created using the **SET VIEW NAME** command [**View > Set View Name**]. When you invoke the command, **EasyCAD** asks you to type in the name of the saved view, or you can right-click to display the *Named Views dialog box*. Select a name and click **OK**. **EasyCAD** replaces the current view with that of the named view.

Text equivalent: **ZNAME**



Zoom Last

ZOOM LAST redraws the drawing window with the *previous zoom magnification* and position, even if you have used other commands since the *last zoom*. If you repeat this command, it will *toggle between the last two views*.

Text equivalent: **ZLAST**



Zoom Text

ZOOM TEXT command zooms the view to center on drawing text that matches the text string you specify. The actual scale of the zoom depends on the height and length of the found text entity. **EasyCAD** determines the extents of the text, then zooms to four times (4x) those values, centering on the extents.

1. The prompt reads “**Zoom to text pattern [prior]:**”. Type in a text string to search, or right-click/press ENTER to accept the previous search string.

If **EasyCAD** finds only a single match, it will zoom to center that text in the view. If more than one instance of the search string is found, **EasyCAD** displays a dialog displaying the matching text entities. Select the desired target, or click **Cancel** to abort.

Use the **ZTEXTD** variant of this command to display the *Zoom to Text dialog*. The operation sequence is exactly the same as **ZTEXT**, except that the string is entered in the dialog and confirmed by clicking **OK**.

Note that the pattern match is case insensitive. Also, there are implied wildcards at the beginning and end of the search text you enter. For instance, “Street” matches “103rd Street NW” and “A street” and “STREETS”.

The = character (equal sign) forces the search string to be an exact match of the entire text entity (not case sensitive). For instance “=street” matches “Street” or “STREET”, but it does not match “3rd street” or “streetsweeper”.

The ? character (question mark) matches anything except end-of-string (there must be a character to match). For instance, “103?C” matches “aa103xc”.

Text equivalent: **ZTEXT**

Draw Commands

Adding entities and objects to your drawing

The **Draw** commands add entities to your drawing. As you might guess, these commands provide the essential building blocks of **EasyCAD**. For most of the **Draw** commands, this chapter contains a step-by-step look at how to construct these entities using mouse or keyboard entry.

Keep in mind that when you create new entities, they acquire the *entity properties* you have specified as current. Entity properties include color, layer, line width, line style, and fill style. The current state of these is always displayed on the *Status bar*. Text and Dimension entities also have their respective current settings. These settings can be changed at any time, even in the middle of a draw command.

Don't fret if you draw some complex entities with the wrong properties. The edit commands in the next chapter tell you how to adjust those. For instance, you can draw a complex component all in green, then later change the colors of the entities using the proper edit commands.

EasyCAD lets you create just about all the entities you might ever need to produce professional-level **CAD** drawings:

Lines Regular lines, double lines, and three types of constrained lines.

Circles Seven methods to draw circles, plus a donut command.

Arcs Four methods to draw arcs, plus chained arcs and a wedge command.

Text You can enter text or import it from a text file.

Wall Networks Intelligent **Wall Networks** that auto-heal intersections

Paths and Polys Box, path, polygon, and regular polygon.

Splines and SPolys Complex curves and polygons using Bezier, cubic B-, and parabolic methods.

Ellipses Three methods, plus an elliptical arc command.


Point One simple method.

Filleets/Chamfers/Offsets Powerful cornering and duplicating methods.

Arrows Create arrowed or double-arrowed lines, paths, arcs, and splines.

Multipolys Collects existing entities and turns them into a new single entity.

Line




Lines sub-menu

When you select [Draw > Lines], a sidebar menu appears with five ways to draw lines. Use the cursor and left button to select the method you want to use.

When you see the "Command:" prompt after leaving a **LINES** command, you can either left/right-click or press **ENTER** to draw more lines of the same type, bypassing the sub-menu. To change to a different type of line, re-select [Draw > Lines] from the menu and select the desired type.



Line icon



LINE lets you add line entities to your drawing. You can draw a single line, or you can add a chain of lines that are connected endpoint to endpoint.

The **LINE** command is listed both by itself and in the [Draw > Lines] sub-menu.

To draw a **line**, select [Draw > Line].

1. The prompt reads



To specify the line's starting point, pick a point, or type numeric coordinates.

2. The prompt reads

The cursor becomes a rubber-band (stretching) line anchored to the first point you selected. To specify the line's end point, pick a point in the drawing window or type coordinates. **EasyCAD** draws a line entity to replace the cursor, then stays in the **LINE** command so you can draw a series of connected lines. Right-click to end the command.

Text equivalent: **LINE**

Lines > Double Lines



LINES > DOUBLE LINES adds parallel lines to your drawing. These parallel lines are separated (or offset) by a specified distance.

To draw a **double line**, select [**Draw > Lines > Double Lines**].

1. The prompt reads

Separation [1.00000]:

Separation is the distance between the double lines. To specify the separation:

- Right-click or press **ENTER** to accept the default.
- Type a numerical value in drawing units.
- Pick two points in the drawing window.

2. The prompt reads

First point:

To specify the starting point of the double line, pick a point or type numeric coordinates. The starting point remains fixed, even if you change handles (see next step).



3. The prompt reads

Next point [SHIFT = Change handle]:

You can change the line to which the cursor is anchored by pressing the **SHIFT** key, moving the mouse nearest the line you want to be the anchor, then releasing the **SHIFT** key. Specify the next point, using the new anchor as the "rubber-band cursor". Right-click to complete or end the command.

Text equivalent: **DBLN**

Lines > Perpendicular



Perpendicular Line icon

LINES > PERPENDICULAR adds a line that is perpendicular to a selected reference entity.

To draw a **perpendicular line**, select **[Draw > Lines > Perpendicular]**:

1. The prompt reads

Reference entity:

Pick a reference entity in your drawing. Lines you draw will be perpendicular to this reference entity; the reference entity is not changed in any way.

If you pick a nonlinear entity such as an arc or ellipse, your lines will be tangentially perpendicular to the curve.

2. The prompt reads

Perpendicular point:



This is the endpoint of the perpendicular line. Pick a point in the drawing window, using the dynamic cursors as an aid.

EasyCAD draws a **perpendicular line** entity from the **endpoint** to the **reference entity** (attaching at the nearest point). If the specified endpoint generates a perpendicular line that does not attach to reference entity, it is still drawn (it attaches to a projection of the reference entity).

If you wish, continue to specify points that describe other perpendicular lines. Right-click to end the command.

Text equivalent: **LNPRP**

Lines > Perpendicular at Length



LINES > PERPENDICULAR AT LENGTH draws a line of specified length perpendicular to a selected reference entity. To draw a perpendicular line without a pre-specified length, use the **LINE > PERPENDICULAR** command.

To draw a line (perpendicular at length), select [**Draw > Lines > Perpendicular at length**]:

1. The prompt reads

This value is the length of the line(s) that will be drawn during this command sequence. To specify the line length, you may:

- Type a new length in drawing units, and press **ENTER**.
- Pick two points on the screen to specify a distance value.
- Right-click to accept the default or prior length.

2. The prompt reads



Pick a reference entity. Lines you draw will be perpendicular to this reference entity; the reference entity is not changed in any way.

3. The prompt reads

Using the dynamic cursors as a visual aid, pick a point anywhere along the line you are about to draw. The line is automatically drawn with the prescribed length, perpendicular to the reference entity. Continue selecting points, if desired. Right-click to end the command.

Text equivalent: **LNPRPL**

Lines > Tangent to Two Entities



LINES > TANGENT TO TWO ENTITIES draws a line tangent to other entities. You can even draw a line tangent to two points on the same entity (like a spline).


Note: This command is not the same as the **TANGENT TO** modifier, which draws a line from any point tangent to another entity.

1. The prompt reads



. Use the pick cursor to select a **circle**, **arc**, **spline**, or other circular entity.

2. The prompt reads





Again use the pick cursor to select a **circle**, **arc**, **spline**, or other circular entity.

The selection points determine how the tangent line will be drawn. For example, there are four possible tangents between any two circles or arcs: two on the outside and two that cross in the middle. **EasyCAD** lets you draw all four — just select the circles or arcs on the sides you want to use for the tangent.

EasyCAD draws the *tangent line*.

Text equivalent: **TANGENT**

Circles > Center and Point On



Circles sub-menu

When you select [Draw > Circles], a sub-menu appears with eight ways to draw circles. Use the cursor and left button to select the method you want. Use the auto-repeat feature to repeat a command.

EasyCAD remembers the center and radius of each circle or arc you draw and offers them as default (prior) values the next time you draw a circle during the same work session. This feature lets you draw *concentric* circles. Right-click or press ENTER to accept the default, or enter a different value as explained under the individual circle commands.

CIRCLES > CENTER AND POINT ON draws a circle using a specified center point and circumference point.

To draw a **center** and **point on circle**, select [Draw > Circles > Center and Point On]:

1. The prompt reads

Center point[2.55882,5.94118]:

To specify the center point:

- Right-click or press **ENTER** to accept the *default center*;
- Pick a new center point, or;
- Type **2d** numeric coordinates and press **ENTER**.

2. The prompt reads

Point on circle:



Use the dynamic cursor as a visual aid to pick a point on the screen. You can optionally combine the pick point with modifiers. When you pick a point, **EasyCAD** draws the **circle** and the command terminates.

Text equivalent: CIRP



Circle icon

Circles > Diameter and Center



Editing Circles

Each circle can be filled with any type of fill pattern.

To select a fill pattern for new circles, use **FILL STYLES** [Specs > Fill Styles].

Keep in mind that if you want a filled circle, it must have a **LINE WIDTH** of 0.0.

To change the pattern of existing circles, use **CHANGE-FILL STYLE** or **EDIT** in the *Edit menu*.

To change a circle's radius, use **EDIT**, **DYNAMIC EDIT**, or **STRETCH** in the *Edit menu*.

To turn a circle into an arc, use **BREAK** [Edit > Break].

CIRCLES > DIAMETER AND CENTER draws a circle using a specified diameter measurement and center point.

To draw a **diameter** and **center circle**, select [**Draw > Circles > Diameter and Center**]:

1. *The prompt reads*




To specify the diameter:

- Right-click or press **ENTER** to accept the default diameter;
- Pick two points on the screen to specify a distance, or;
- Type a new value for the diameter and press **ENTER**. For example, to draw a circle with a diameter of 4 units, type "4" and press **ENTER**.

EasyCAD displays a circular cursor with the specified diameter.

2. *The prompt reads*



Pick the desired center point or type numeric coordinates. **EasyCAD** draws the *circle* with the specified *diameter*.



3. *The prompt reads*



Continue drawing *circles* with the same diameter by specifying new center points, or right-click to end the command.

Text equivalent: CIRD

Circles > Radius and Center



CIRCLES > RADIUS AND CENTER draws a circle using a specified radius measurement and center point.

To draw a **radius** and **center** circle, select [**Draw > Circles > Radius and Center**]:

1. *The prompt reads*

To specify the radius:

- Right-click or press **ENTER** to accept the *default radius*;
- Pick two points on the screen to specify a distance, or;
- Type a new value for the radius and press **ENTER**. For example, draw a circle with a radius of 2 units, type "2" and press **ENTER**.

EasyCAD displays a circular cursor with the specified radius.



2. *The prompt reads*

Pick the desired center point or type numeric coordinates. **EasyCAD** draws the circle with the specified radius.

3. You are again prompted for "**Center:**". Continue drawing circles with the same radius by picking new center points, or right-click to end the command.

Text equivalent: **CIRR**

Circles > 2 Point Circle



CIRCLES > 2 POINT CIRCLE draws a circle using two specified points that define its diameter.

To draw a **2 point circle** select [**Draw > Circles > 2 Point Circles**]:

1. *The prompt reads*

Pick a point or type numeric coordinates.

EasyCAD displays a stretching circular cursor, anchored at the 1st point you selected.



2. *The prompt reads*

To specify the opposite point, pick a point or type numeric coordinates. The two points specify the diameter of the **circle**, centered about the midpoint distance between the two points.

EasyCAD draws the **Circle** and terminates the command.

Text equivalent: **CIR2**

Circles > 3 Point Circle



CIRCLES > 3 POINT CIRCLE draws a circle using three specified points on its circumference.

To draw a **3 point circle**, select [**Draw > Circles > 3 Point Circle**]:

1. *The prompt reads*
Pick a point or type **2d** numeric coordinates.
2. *The prompt reads*
Specify the **2nd point** as you did the 1st point.
3. *The prompt reads*
Specify the **3rd point**.

EasyCAD draws a **Circle** through the three points and terminates the command.



Note: If you specify three points in a straight line, a circle would be mathematically impossible, so **EasyCAD** displays a message box: "**Can't create entity because: Three points are in a straight line.**" Click **OK** or press ENTER to clear the message.

Text equivalent: **CIR3**

Circles > Tangent to 2 entities



TANGENT TO 2 ENTITIES draws a circle tangent to two other entities.

To draw a circle tangent to 2, select [**Draw > Circles > Tangent to 2 entities**]:

1. *The prompt reads* 
Pick the target section (where you want the tangent circle to appear) of a circle or arc.
- 2.. *The prompt reads* 
Select another non-linear entity. **EasyCAD** draws a circle in between the entities you picked.



Text equivalent: **CIRTAN2**

Circles > Tangent to 3 entities



TANGENT TO 3 ENTITIES draws a circle tangent to three circles or arcs.



To draw a circle tangent to 3, select [**Draw > Circles > Tangent to 3 entities**]:

1. *The prompt reads* 
Pick the 1st entity with the mouse.
2. *The prompt reads* 
Select the 2nd and 3rd entities and **FastCAD** draws a *circle tangent* to the three entities.

Often, multiple circles could be drawn, given three entities. You can help **EasyCAD** draw the one you want by selecting the entities near their expected points of tangency.

Text equivalent: **CIRTAN3**

Circles > Donut



CIRCLES > DONUT automatically builds a multipoly consisting of two concentric circles. The multipoly automatically fills with the current fill style, creating a donut-type shape.

To draw a **donut** select [**Draw > Circles > Donut**]:

1. The prompt reads

Inner diameter [0.50000]:

To specify the *diameter* of the *inner circle* (**donut hole**), right-click to accept the default, or type a numeric value and press **ENTER**.

2. The prompt reads

Outer diameter [1.00000]:



To specify the *diameter* of the *outside circle* of the donut, right-click to accept the default, or type a numeric value and press **ENTER**.

3. The prompt reads "**Donut center:**". To specify the donut center, pick a point or type numeric coordinates.

EasyCAD draws the **Donut**, hatching it with the *current fill style*, and then terminates the command.

Text equivalent: **DONUT**

Arcs > Center, Start, End



Arcs sub-menu

When you select Arcs, a sub-menu appears with six ways to draw arcs. Use the cursor and left button to select the method you want.

EasyCAD remembers the center and radius of the last circle or arc you drew and offers them as default or prior (suggested) values the next time you draw an arc during the same work session. This feature lets you draw *concentric arcs*. Right-click to accept the default or prior value or enter a different value as explained under the individual arc commands.

ARCS > CENTER, START, END draws an arc from a specified center point, start point (which defines both the radius and the starting angle), and end point.

To draw a **center, start, end arc**, select [Draw > Arcs > Center, Start, End]:

1. The prompt reads "**Center point [x,y]:**", where x,y is the prior or *default center* coordinate. To specify the *arc center*:
 - Right-click or press **ENTER** to accept the default center;
 - Pick a new center point , or;
 - Type numeric coordinates and press **ENTER**.



EasyCAD displays a *circular* dynamic cursor.

2. The prompt reads "**Arc starting point:**". The starting point tells FastCAD both the arc radius and its starting angle. To specify the starting point:
 - Pick a point using the stretching circular cursor, or;
 - Type numeric coordinates and press **ENTER**.
3. The prompt reads "**Arc ending point:**". To specify the ending angle, pick a point along the radial dynamic cursor, using the stretching arc cursor as a visual aid.

EasyCAD draws the arc counterclockwise from the starting point to the ending point, and the command terminates.

Text equivalent: **ARCS**

Arcs > Center and Radius



ARCS > CENTER AND RADIUS draws an arc from a center, radius measurement, starting angle, and ending angle. Use this command when you want precise control over arc angles with a fixed radius. For example, you could enter a radius of 1.5" and start an arc at exactly -30°, and end it at 45°.

To draw a center and radius arc, select [**Draw > Arcs > Center and Radius**]:

1. The prompt reads "**Center point [x,y]:**", where x,y is the prior or *default center* coordinate. To define the *arc center*:
 - Right-click or press **ENTER** to accept the default center;
 - Pick a new center point, or;
 - Type **2d** numeric coordinates and press **ENTER**.

EasyCAD displays a circular dynamic cursor.

2. The prompt reads "**Radius [n]:**", where n is the prior or default radius distance. To specify the arc radius:
 - Right-click or press **ENTER** to accept the default radius;
 - Pick two points to specify a new radius distance, or;
 - Type a new value for the radius and press **ENTER**. For example, draw a circle with a radius of 2 units, type "2" and press **ENTER**.

EasyCAD displays a rubber-band cursor anchored at the *center point*.

3. The prompt reads "**Starting Angle [x°]:**", where **x** is the prior or *default starting angle*. The *starting angle* determines the first point of the arc. To specify the *starting angle*:
 - Right-click or press **ENTER** to accept the default angle;
 - Pick a point, or;
 - Type a new value for the angle and press **ENTER**.



EasyCAD displays a dynamic *arc* cursor, anchored at the *starting point*.

4. The prompt reads "**Ending angle [x°]**", where **x** is the prior or default ending angle. The ending angle tells **EasyCAD** where the arc ends. Note that you need to specify the angle bearing, relative to the arc center, not the arc width. To specify the ending angle:
 - Right-click or press **ENTER** to accept the default angle;
 - Pick a point, or;
 - Type a new value for the angle and press **ENTER**.

EasyCAD draws the arc counterclockwise from the starting angle to the ending angle, and the command terminates.

Text equivalent: **ARCR**

Arcs > Start, Middle and End



ARCS > START, MIDDLE AND END draws an arc from a specified starting point, point on the arc, and ending point.

To draw a **start, middle and end arc**, select [**Draw > Arcs > Start, Middle and End**]:

1. The prompt reads "**1st point:**". This point locks down the starting endpoint. To specify the first point, pick a point or by type numeric coordinates.
2. The prompt reads "**2nd point:**". This point locks down an intermediate point on the arc. To specify the second point, pick a point or by type numeric coordinates.

The stretching arc cursor now passes through the second point, anchored at the first.



3. The prompt reads "**3rd point:**". This point locks down the endpoint the arc, and determines the arc size and shape. The stretching cursor previews the final arc form. To specify the third point, pick a point or type numeric coordinates.

EasyCAD draws the final arc from the first point, through the second, and to the third point.

Note: If you select three points in a straight line, an arc would be mathematically impossible, so **EasyCAD** displays a message box: "Can't create entity because: Three points are in a straight line." Click **OK** or press ENTER to clear the message.

Text equivalent: **ARC3**

Arcs > Start, End and Bulge



ARCS START, END AND BULGE by specifying the *arc's start and end points first*, and then *a point on the arc*.

To draw a **start, end, and bulge arc**, select [**Draw > Arcs > Start, End and Bulge**]:

1. The prompt reads "**1st point:**". This point locks down the starting endpoint. To specify the first point, pick a point or type numeric coordinates.
2. The prompt reads "**2nd point:**". This point locks down the opposite arc endpoint. To specify the second point, pick a point or type numeric coordinates.

The stretching arc cursor is anchored at the first and second points.



3. The prompt reads "**3rd point:**". This point locks down an intermediate point on the arc, and determines the arc size and shape (the "**bulge**"). The stretching cursor previews the final arc form. To specify the third point, pick a point or type numeric coordinates.

EasyCAD draws the final **Arc** from the first point, through the second, and to the third point.

Please note: If you select three points in a straight line, an arc would be mathematically impossible, so **EasyCAD** displays a message box: "**Can't create entity because: Three points are in a straight line.**" Click **OK** or press ENTER to clear the message.

Text equivalent: **ARCB**

Arcs > Chained Arcs



ARCS > CHAINED ARCS draws a series of *connected arcs*. The first point begins the *first arc*. The second point determines a direction that is the tangent of the first point on the *arc*. The next point sets the end of the first *arc* and defines the tangent and starting point of the next *arc*.

To draw a series of **chained arcs**, select [**Draw > Arcs > Chained**]:

1. The prompt reads "**First arc start point:**". To specify the 1st point, pick a point or type numeric coordinates. **EasyCAD** draws a rubber-band cursor anchored at the point you selected.
2. The prompt still reads "**First arc start point:**". The line defined by the 1st point and next point determines the direction (or tangent vector) for the first arc. To specify the nextpoint, pick a point or type numeric coordinates.

EasyCAD displays a dynamic *arc* cursor, anchored at the 1st point.

3. The prompt reads "**Next arc end point:**". This point determines the end of the first arc and the starting point of the next *arc*. To specify this point, pick a point or type numeric coordinates.



EasyCAD draws the first arc from the 1st point, constrained by the tangent vector, to the point just selected.

4. The prompt reads "**Next arc end point:**". You may continue drawing chained two-point arcs. Right-click to end the command.

Please note: If you select two arc endpoints whose bearing angle matches the direction vector, an arc would be mathematically impossible, so **EasyCAD** draws a line between the two endpoints.

Text equivalent: **CARCD**

Arcs > Wedge (Pie Section)



ARCS > WEDGE (PIE SECTION) is used to facilitate *pie chart creation*. It does this by drawing *filled arcs* similarly to the **ARC** command and providing means to quickly complete the *circle*.

To draw a **Wedge**, select [**Draw > Arcs > Wedge (Pie section)**]:

1. The prompt reads "**Center point [x,y]:**", where **x,y** is the *prior* or *default center* coordinate. To define the *arc center*:
 - Right-click or press **ENTER** to accept the default center;
 - Pick a new center point, or;
 - Type numeric coordinates and press **ENTER**.

EasyCAD displays a circular dynamic cursor.

2. The prompt reads "**Radius [n]:**", where **n** is the prior or *default radius* distance. To specify the *arc radius*:
 - Right-click or press **ENTER** to accept the *default radius*;
 - Pick two points to specify a *new radius* distance, or;
 - Type a new value for the *radius* and press **ENTER**. For example, draw a *circle* with a *radius* of 2 units, type "2" and press **ENTER**.

EasyCAD displays a rubber-band cursor anchored at the *center point*.

3. The prompt reads "**Starting angle: [prior end, ESC=quit]**". Type an angle or select a point at the desired *angle* from the *center*. If you right-click, the last *ending*

angle of the preceding arc will be used. Pressing the **ESC** key will cancel the command.


EasyCAD displays a stretching arc-shaped cursor, anchored at the starting point.

4. The prompt reads "**Ending angle [1st start, ESC=quit]:**". The *ending angle* determines the *arc length of the wedge*. Type an *angle* or select a point when the arc looks the way you want. If you right-click, the *wedge* will be drawn in order to close the *circle*. Do not accept this default on the first *wedge* unless you intend to draw a *circle*.

EasyCAD draws the wedge counterclockwise from the starting angle to the ending angle

5. **EasyCAD** allows you to continue *adding wedges*, prompting again for "**Starting angle:**" and "**Ending angle:**". Continue to draw a series of wedges with the same center and *radius*. Note that the right button defaults allow you to easily draw adjacent *wedges*. Press the **ESC** key to end the command.

Text equivalent: **ARCW**



Typing Special Characters

There may be occasions when you need to insert non-alphanumeric characters. In most cases, you can enter these by holding down the **ALT** key and typing the appropriate three- or four-digit code.

In most font sets, the **degree sign** (°) can be entered by typing **ALT+248**. The **Greek phi** (Ø), often used to denote diameters, can be entered by typing **ALT+0216**. **Be sure to use the keyboard's number pad, not the top row number keys.**

You can determine the **ALT** key code combination for any character in a font set by using the **Character Map** program that's bundled with every copy of Windows.

Single Line Text

SINGLE LINE TEXT adds a single line of lettering (for labels, notes, etc.) to your drawing. The text draws using the *current font and text metrics as specified in Text Properties dialog box*.

To add **Single Line Text**, select [**Draw > Text > Single Line**]:

1. The prompt reads "(CTRL=scale CTRL+SHIFT =rotate) Text:". Start typing your text. The *text* appears both on the *command line* and on-screen at the *cursor location*. As you type you can move the mouse to reposition the *text*.

This method of text input is intended for immediate text placement so it is unnecessary to press the ENTER key when you are done typing the line of text.

2. To insert your text, pick a point on the screen with a left-click

In this mode you may NOT use the Zoom icons or dynamic zoom or pan to reposition the current view prior to TEXT placement..

If you need to zoom in or out before you place the line of TEXT, press ENTER. Now use the Zoom icons or dynamic zoom or pan to reposition the current view then place the TEXT with a left-click.

Typing a second single line of text and pressing ENTER twice the text automatically drops directly below the previous line of text you placed.

Note You may *stretch* or *shrink* the text prior to placement by pressing the **CTRL** key and *move the mouse slowly up or down*. This feature makes it very easy to *fit text to existing objects without setting text height in advance*.

Stretching text this way does not reset **EasyCAD's** *height* value for new text - the next *text* entity you draw will still have the *original current height*.


This *dynamic cursor* also allows you to *rotate the text prior to placement*.

Simultaneously hold down the **CTRL+SHIFT** keys and slowly move the mouse. *The text rotates with your mouse movements*. This feature makes it very easy to *align text without setting the text angle in advance*.

After placing the line of **TEXT**, you may use the **DYNEDIT** command by selecting [**Edit > Dynamic Edit**] and pick the **TEXT** at its *baseline* to *reposition it, dynamically rotate, stretch* or *shrink* it.

You can draw **Single Line Text** at any *height* and *angle*.

Text equivalent: **TEXT**



Typing Special Characters

There may be occasions when you need to insert non-alphanumeric characters. In most cases, you can enter these by holding down the **ALT** key and typing the appropriate three- or four-digit code.

In most font sets, the **degree sign** (°) can be entered by typing **ALT+248**. The **Greek phi** (Ø), often used to denote diameters, can be entered by typing **ALT+0216**. **Be sure to use the keyboard's number pad, not the top row number keys.**

You can determine the **ALT** key code combination for any character in a font set by using the **Character Map** program that's bundled with every copy of Windows.

Text > Multi Line Text

MULTILINE TEXT lets you add multiple lines of text at one time. Because multiple lines will not fit on the command line (as in the **SINGLE LINE TEXT** command), **MLTI-LINE TEXT** require you to enter text in the *Edit Text* dialog.

To add **Multi-line Text** select [**Draw > Text > Multi Line**]:

1. **EasyCAD** displays the *Edit Text* dialog. Enter your *text* in the *Eext Text* window. To start a new line, press the **ENTER** key.

While typing, you can:

- Use the keyboard *arrow keys*, **HOME**, and **END** to move the cursor within the editing window;
- Press **DELETE** to delete the character under the cursor;
- Press **BACKSPACE** to delete characters to the left of the cursor;
- Type special characters using the **ALT** key and the appropriate numbers from the key pad as explained in the side bar in this and the previous page.

Click the *Properties* button if you wish to change any of the *standard text properties*, such as *height*, *font*, or *justification*.

2. When you are finished entering text, click **OK**.
3. The prompt reads "**Text origin:**". Your *typed text* is displayed on screen with a dynamic cursor. To position the text, pick a point on the screen, or type in numeric coordinates and press **ENTER**.

Note You may *stretch* or *shrink* the *text prior to placemen* by pressing the **CTRL** key and *move the mouse slowly up or down*. This feature makes it very easy to *fit text to existing objects without setting text height in advance*.

Stretching text this way does not reset **EasyCAD**'s height value for new text - the next *text* entity you draw will still have the *original current height*.

This *dynamic cursor* also allows you to *rotate the text prior to placement*.

Simultaneously hold down the **CTRL+SHIFT** keys and slowly move the mouse. *The text rotates with your mouse movements*. This feature makes it very easy to *align text without setting the text angle in advance*.

After placing the line of **TEXT**, you may use the **DYNEDIT** command by selecting [**Edit > Dynamic Edit**] and pick the **TEXT at its baseline** to *reposition it, dynamically rotate, stretch* or *shrink* it.

Text equivalent: **MLTEXT**

Edit Text dialog

The *Edit Text dialog* is displayed when **EasyCAD** requests you to *enter* or *edit text*.

Editing Text

Commands for editing text can be found in the chapter dealing with the *Edit menu*. But here's a summary of commands applicable to text:

To set properties for new text, use **TEXT PROPERTIES** [Specs > Text Properties].


To change the properties of existing text, use **EDIT** or **CHANGE > TEXT PROPERTIES** in the *Edit menu*.

To insert text from an **ANSI** text file, use the **FILE TEXT** command [Draw > Text > File Text].

To modify the text value of a single text entity, use the **EDIT** command [Edit > Edit].

To change multiple, existing text entities to the same value, use the **CHANGE > TEXT** command [Edit > Change > Text].

To reposition existing text, use the **DYNAMIC EDIT** command [Edit > Dynamic Edit]. You can also use the dynamic cursor capabilities to **re-size** and **rotate** the text.



EasyCAD displays *Edit Text* window into which you can type up to 256 characters on one line.


Edit window Type your *text* here. To create a new line, press the **ENTER** key.

While typing, you can:

- Use the keyboard **arrow keys**, **HOME** and **END** to move the cursor within the editing window;
- Press **DEL** to *delete the character to the right of the cursor*;
- Press **BACKSPACE** to *delete characters to the left of the cursor*;
- Type special characters using the **ALT** key and the appropriate numbers from the **number key pad** such as **ALT+0248** for the **lowercase PHI DIAMETER** symbol.

Click **OK** when you are done entering text. **EasyCAD** returns you to the drawing screen and continues with the current command.

Properties button Opens the *Text Properties dialog*, where you can change any of the standard *text properties*, such as *height*, *font*, or *justification*. Depending on the command calling this dialog, this button may not always appear.



Text > File Text

FILE TEXT inserts an ANSI text file into the *active drawing*, using the *current Text Properties*. When you start this command, EasyCAD displays the *Text from file dialog box*. This dialog is a variant of the standard *Load File dialog*, filtered to display only **.TXT** files. Though only **.TXT** files appear in the *file list window*, the source file is not required to have a **.txt** extension.

To insert *text from a text file*, select [Draw > Text > File Text]:


1. EasyCAD displays the *Text from file: dialog*. Navigate to the appropriate folder containing the desired *text file*, and then select the *text file*. You can either double-click on the *file name*, or select the *file name* and click **OK**.

EasyCAD displays a *dynamic text cursor*.

2. The prompt reads "**Text origin:**". To specify the *insertion point*, pick a point on the drawing window, or type numeric coordinates and press **ENTER**.

EasyCAD draws the **Text**.


Text equivalent: **TFILE**



Text > Current Date

The [Draw > Text > Current Date] command retrieves the **CURRENT DATE** from your computer's system **CALENDAR** and allows you to place it in the current drawing as a piece of **TEXT**. It is a special entity called a **TEXT ITEM**. Title blocks are the usual place for placing the **CURRENT DATE** but it may be placed anywhere in the current drawing.

Setting the Date Format



To set the desired **DATE FORMAT**, select the **TIME AND DATE** command from the **SPECS** menu. You may also type **TDFMT** to open this dialog box. Click the button of the desired **DATE** and **TIME** format you want to use.


Text equivalent: **TDATE**

The Current Date Automatically Updates

Each time you open the drawing the **CURRENT DATE** will automatically be updated. If you use a command such **DRAG** or **MOVE** to change the location of the **CURRENT DATE** text it will also be updated.

When you **PRINT** your drawing the **CURRENT DATE** text item will be updated so you may easily look at a printed drawing and know the **DATE IT WAS PRINTED**.


NOTE: The **CURRENT DATE** text item **MAY BE EXPLODED** into a normal piece of **TEXT**. If you use the [**Edit>Explode**] command and select the **CURRENT DATE** text item and **EXPLODE** it, it **WILL NOT UPDATE**. Use the [**Draw > Text > Current Date**] command again to place it as an updating **TEXT ITEM** in the drawing



Text > Current Time

The [**Draw > Text > Current Time**] command retrieves the **CURRENT TIME** from your computers system **CLOCK** and allows you to place it in the current drawing as a piece of **TEXT**. It is a special entity called a **TEXT ITEM**. Title blocks are the usual place for placing the **CURRENT TIME** but it may be placed anywhere in the current drawing.

Setting the Time Format



To set the desired **TIME FORMAT**, select the **TIME AND DATE** command from the **SPECS** menu. You may also type **TDFMT** to open this dialog box. Click the button of the desired **DATE** and **TIME** format you want to use.

The Current Time Automatically Updates


Each time you open the drawing the **CURRENT TIME** will automatically be updated. If you use a command such **DRAG** or **MOVE** to change the location of the **CURRENT TIME** text it will also be updated.

When you **PRINT** your drawing the **CURRENT TIME** text item will be updated so you may easily look at a printed drawing and know the **TIME IT WAS PRINTED**.

NOTE: The **CURRENT TIME** text item **MAY BE EXPLODED** into a normal piece of **TEXT**. If you use the [**Edit > Explode**] command and select the **CURRENT TIME** text item and **EXPLODE** it, it **WILL NOT UPDATE**. Use the [**Draw > Text > Current Time**] command again to place it as an updating **TEXT ITEM** in the drawing.

The **CURRENT DATE**, **CURRENT TIME** and **CURRENT DRAWING** text items will be exploded to standard text when the drawing is exported to AutoCAD® .DWG or .DXF file format.

*Text equivalent: **TTIME***



Text > Current Drawing

The [**Draw > Text > Current Drawing**] command retrieves the **CURRENT DRAWING NAME** complete with the **DRIVE** and **DIRECTORY PATH** where it is located and allows you to place it in the current drawing as a piece of **TEXT**. Title blocks are the usual place for placing the *current drawing name* but it may be placed anywhere in the current drawing.

NOTE: If you use the [**File > Save As**] command and save it with a different filename on a different drive, the **TEXT** will update to that new **DRIVE**, **DIRECTORY PATH** and **FILENAME** automatically as seen in the example below.


C:\EasyCAD7\My_Drawing.FC7

Drive, Directory Path and Filename Automatically Update

If you use the [**File > Save As**] command and save it with a different filename on a different drive, the **TEXT** will update to that new **DRIVE**, **DIRECTORY PATH** and **FILENAME** automatically.

NOTE: The **CURRENT DRAWING** text item **MAY BE EXPLODED** into a normal piece of **TEXT**. If you use the [**Edit > Explode**] command and select the **CURRENT DRAWING** text item and **EXPLODE** it, it **WILL NOT UPDATE** when you save it to another drive or folder. Use the [**Draw > Text > Current Drawing**] command again to place it as an updating **TEXT ITEM**.

*Text equivalent: **TFILENAME***



Text > Keep Text Height and Angle

Use **KEEP TEXT HIEGHT AND ANGLE** to *copy the height and angle specifications of the last text entered into the current text specs. You do not need to select the text-it automatically uses the most recently created text entity*. New text you draw will use those settings until you change them again. This works even if the last inserted text was manipulated using dynamic cursors.


For instance, if you invoke the **TEXT** command and place the *text* using the **CTRL** and **CTRL+SHIFT** keys to *dynamically scale* and *rotate* the text, using the **KEEPTHA** command would *copy the text's height and angle into the current settings*. You can verify that by invoking the **TSPEC** command and looking at the *Text Properties* dialog box by clicking the *Text Properties* icon.

KEEPTHA works similarly to the **KEEP LIKE** command, except that the **KEEP LIKE** command *copies all text and entity specifications to the current settings*. **KEEPTHA** *copies only the text height and angle*, leaving other properties such as layer, color, font, and justification unchanged.

The macro commands **TSPECH** and **TSPECA** let you explicitly set the text height and angle, respectively.

Text equivalent: **KEEPTHA**

Paths and Polys > Box




Paths and Polys sub-menu

Paths and **Polygons** share the common characteristics of being singular entities that are composed of multiple connected segments. **Polygons** have closure and **Paths** do not. **Polygons** can be filled. Boundaries created with simple **Draw** commands can be filled.

BOX and **REGULAR POLYGON** make it easy to draw these types of **Polygons**.

FastCAD stores the same information for all entities of this type. **Paths**, **Polygons**, **Smooth Polygons**, **Splines**, **Arrows** and **Double Arrows** are all defined by a series of nodes and can be edited in similar ways—for example, with **STRETCH** or **DYNAMIC EDIT** in the **Edit** menu.



BOX is a shortcut command that enters a rectangular polygon entity. **FastCAD** constructs the box using two corner points you specify.

When you use the **BOX** command, the order in which you specify the corner points is disregarded. Certain *modifiers*, such as **EPT**, **MID**, and **%**, utilize overall entity lengths. For **BOX polygons**, the *starting node is always the lower-left point*, and the *midpoint is always the upper-right point*. For instance, the **EPT** (endpoint) of a non-rotated **BOX polygon** is always the lower-left node.

Use **EPTS** (F5 Endpoint of segment) and **MIDS** (F3 Midpoint of segment) *modifiers* for the **ENDPOINTS** and **MIDPOINTS** of **POLYGON** sides and **PATH** segments.



To draw a **Box**, select [Draw > Paths and Polys > Box]:

1. The prompt reads "**First corner:**" To specify the *first corner* of the box, pick a point, or type numeric coordinates.
The cursor changes to a stretching rectangle anchored at the *first corner*.
2. The prompt reads "**Opposite corner:**". To specify the *opposite corner*, stretch the cursor and pick a point when the rectangle is the size and shape you want, or you type numeric coordinates.

EasyCAD draws a **Box**-shaped *polygon* entity.

Text equivalent: **BOX**

Paths and Polys > Path



PATH draws a routed connection between two end points. A *path* looks like a series of connected lines but is more like an open-ended polygon with at least 2 node points. *Paths* are useful in mapping and other applications where connections are important.



Use **EPTS** (F5 Endpoint of segment) and **MIDS** (F3 Midpoint of segment) *modifiers* for the **ENDPOINTS** and **MIDPOINTS** of **POLYGON** sides and **PATH** segments.

To draw a **Path**, select [**Draw > Paths and Polys > Path**]:

1. The prompt reads "**1st point**:". Pick a point, or type numeric coordinates.
EasyCAD displays a rubber-band cursor anchored at the *first point*.
2. The prompt reads "**Next point [done]**:". Pick the next node point on the path.
EasyCAD draws one segment of the *path* (in gray).
3. The prompt reads "**Next point [done]**:". If desired, continue to specify nodes. After placing the ending point of the *path*, right-click to end the command.

Text equivalent: **PATH**

Paths and Polys > Polygon



POLYGON draws a closed shape, optionally filled or crosshatched, with at least 3 sides.

Use **EPTS** (F5 Endpoint of segment) and **MIDS** (F3 Midpoint of segment) modifiers for the **ENDPOINTS** and **MIDPOINTS** of **POLYGON** sides and **PATH** segments.

To draw a **polygon**, select [**Draw > Paths and Polys > Polygon**]:

1. The prompt reads "**1st point**:". When drawing *polygons*, the 1st point is again used at the end of the command as the *closing point*. To specify the *first node* (*corner*) of the *polygon*, pick a point, or type numeric coordinates.
EasyCAD displays a rubber-band cursor, anchored at the *1st point*.
2. The prompt reads "**Next point [done]**:". Specify the *next point*.
EasyCAD draws one side of the *polygon* (in gray). A new rubber-cursor is displayed, anchored at the point just specified.
3. The prompt reads "**Next point [done]**:". Continue specifying nodes (each additional node forms another polygon side). If you are done adding nodes (**you must have at least three nodes**), *right-click to finish the polygon*.



EasyCAD draws the final line segment from the last point back to the first point, automatically closing the polygon. The command terminates.

To draw a **box** (rectangle) polygon: **BOX**

To draw a **Regular Polygon**, such as a *hexagon* or *octagon* use **RPOLY**

Text equivalent: **POLY**

Paths and Polys > Regular Polygon



REGULAR POLYGON is a shortcut command for entering *regular polygon* entities like *equilateral triangles*, *squares*, or *hexagons*. You define the *center* and *a corner of the polygon* (the corner is a point on an imaginary circle that encloses the polygon).

Use **EPTS (F5 Endpoint of segment)** and **MIDS (F3 Midpoint of segment)** *modifiers* for the **ENDPOINTS** and **MIDPOINTS** of **POLYGON** sides and **PATH** segments.

To draw a **regular polygon**, select [**Draw > Paths and Polys > Regular Polygon**]:

1. The prompt reads "**Number of nodes [n]:**". This determines the *number of corners on the polygon*. Right-click to accept the default or *prior number of sides*, or type a *whole number value* (for example, type "4" and press ENTER to draw a *square*).
2. The prompt reads "**Center [x,y]:**". To determine the center point for the polygon:
 - Right-click or press **ENTER** to accept the default or prior center;
 - Pick a new center point, or;
 - Type numeric coordinates and press **ENTER**.



EasyCAD displays a dynamic cursor anchored to the *center* of the entity. A radial cursor marks the 1st corner.

3. The prompt reads "**Starting corner:**". This determines the *final position of the regular polygon*. To specify the location of the 1st corner, pick a point, or by type numeric coordinates.

EasyCAD draws the **Regular Polygon** and terminates the command.

*Text equivalent: **RPOLY***

Curves > Bezier Curve

**Curves
sub-menu**

Splines are smooth curves, kind of like the French curve template in EasyCAD's toolbox. Bezier Curve, Cubic B-, and Parabolic type curves can be drawn. Smooth polygons (SPolys) are closed entities that can be hatched with a desired fill style.

The supporting mathematics behind the construction of these curves is well beyond the scope of this manual. However, quick experimentation will help determine which method works best for the type of complex curve you wish to create.

CURVES > BEZIER CURVE draws an *open smooth curve*, determined by a *first point*, a *last point*, and *two control points* called a *frame*. The curve touches the first and last points and follows an average path among the other two nodes. *A Bezier Curve must have exactly 4 nodes.*



To draw a **Bezier curve**, select [**Draw > 2d Curvess > Bezier Curve**]:

1. The prompt reads "**1st point:**". The **Bezier** starts exactly at this point. To specify the starting point, pick a point, or type numeric coordinates.
EasyCAD displays a rubber-band cursor, anchored at the *first point*.
2. The prompt reads "**Last Point:**". The **Bezier** ends exactly at this point. Specify the last point of the Bezier using the same manner as the 1st point.
EasyCAD displays a dynamic cursor showing the **Bezier Curve** and the frame (both in gray).
3. Specify the two control nodes ("**1st middle point:**" and "**2nd middle point [optional]:**") to finish the command. The **Bezier** does not pass through these points, but these points do control the shape of the *spline*. You may right-click at the "**2nd middle point [optional]:**" prompt or pick a point.

EasyCAD draws the **Bezier Curve** and terminates the command.

Text equivalent: **BEZ**

Curves > Cubic B-Spline



Frames

In **EasyCAD**, frames apply exclusively to the supporting node network of a spline or SPoly. The frame is shown as connected line segments.

You can toggle frame display on or off using the TOGGLE FRAMES command [Specs > Toggle Frames] or by typing CTRL+F.

Frames also display when you use DYNAMIC EDIT to move, insert, or delete nodes from a spline or SPoly.

CURVES > CUBIC B-SPLINE (smooth polyline) draws an open smooth curve defined by a series of node points called a frame. The curve touches the first and last points and follows an average path among the other nodes. A spline must have at least 3 nodes.

To draw a **Cubic B-Spline**, select [Draw > Curves > Cubic B-Spline]:

1. The prompt reads "**1st point:**". To specify the first spline node, pick a point, or type numeric coordinates.

EasyCAD displays a rubber-band cursor, anchored at the 1st point.

2. The prompt reads "**Next point [done]:**". Specify the second node in the spline.



EasyCAD displays a dynamic cursor showing both the curve and the frame.

3. The prompt reads "**Next point [done]:**". Continue to specify nodes as desired. Right-click to end node selection.

EasyCAD draws the **Cubic B-Spline** and terminates the command.

Text equivalent: **SPLINE**

Curves > Cubic B-SPoly



CURVES > CUBIC B-SPOLY (smooth polygon) *draws a closed, curved shape defined by a series of node points called a frame.* The curve doesn't touch the nodes. A smooth polygon must have at least 3 nodes. Each **SPoly** can be filled or crosshatched.


To draw a **Cubic B-SPoly**, select [**Draw > 2d Curves > Cubic B-SPoly**]:

1. The prompt reads "**1st point:**". To specify the first point, pick a point or type numeric coordinates.
EasyCAD displays a rubber-band cursor, anchored at the 1st point.
2. The prompt reads "**Next point [done]:**". Specify the next node in the spoly.
EasyCAD displays a dynamic cursor showing both the curve and the frame.
3. The prompt reads "**Next point [done]:**". Continue specifying nodes as desired.
Right-click to end node selection.

EasyCAD draws the **SPoly** by constructing the final frame segment from the last point back to the first point, automatically closing the smooth polygon. The command terminates.

Text equivalent: **SPOLY**

Curves > Parabolic Spline



CURVES > PARABOLIC SPLINE (smooth polyline) draws an open, curved shape defined by a series of node points called a frame. The curve draws through all the nodes. A parabolic spline must have at least 3 nodes.


To draw a **Parabolic Spline**, select [**Draw > Curves > Parabolic Spline**]:

1. The prompt reads "**1st point:**". To specify the first spline node, pick a point or type numeric coordinates.
EasyCAD displays a rubber-band cursor, anchored at the 1st point.
2. The prompt reads "**Next point [done]:**". Specify the second node in the spline.
EasyCAD displays a dynamic cursor showing both the curve and the frame.
3. The prompt reads "**Next point [done]:**". Continue to specify nodes as desired.
Right-click to end node selection.

EasyCAD draws the **Parabolic Spline** and terminates the command.

Text equivalent: **PSPLINE**

Curves > Parabolic SPoly



CURVES > PARABOLIC SPOLY (*smooth polygon*) *draws a closed, curved shape defined by a series of node points called a frame.* The curve draws through all the nodes, using the same mathematical definition as a parabolic spline. A *smooth polygon* must have at least 3 nodes. Each smooth polygon can be solid filled or crosshatched.



To draw a **Parabolic SPoly**, select [**Draw > 2d Curves > Parabolic SPoly**]:

1. The prompt reads "**1st point:**". To specify the first point, pick a point or type numeric coordinates.
EasyCAD displays a rubber-band cursor, anchored at the 1st point.
2. The prompt reads "**Next point [done]:**". Specify the next node in the **SPoly**.
EasyCAD displays a dynamic cursor showing both the curve and the frame.
3. The prompt reads "**Next point [done]:**". Continue specifying nodes as desired.
Right-click to end node selection.

EasyCAD draws the **Parabolic SPoly** by constructing the final frame segment from the last point back to the first point, *automatically closing the smooth polygon*. The command terminates.

Text equivalent: **PSPOLY**

Ellipses > Center and Axis Points



CENTER AND AXIS POINTS draws an ellipse using a specified center point and two special points on its circumference – the ends of its minor and major axes. Of all possible points on the circumference, the ends of the major axis are farthest from the center, while the ends of the minor axis are closest.

Ellipses sub-menu

When you select **ELLIPSES**, a sub-menu appears with four ways to draw ellipses and elliptical arcs. Select the desired method.

An ellipse has a **major axis** and a **minor axis**. The **major axis** is the longer diameter of an **ellipse**. The minor axis is the shorter diameter.

You can draw ellipses at any angle. The angle of the **major axis** is called the inclination of the **ellipse**.

To draw a **center and axis point ellipse**, select [Draw > Ellipses > Center and Axis Points]:

1. The prompt reads

Center point[2.55882,5.94118]:

To specify the ellipse center:

- Right-click or press **ENTER** to accept the default center;
- Pick a point , or;
- Type numeric coordinates and press **ENTER**.

EasyCAD displays a rubber-band cursor, anchored at the center.

2. The prompt reads

Major axis endpoint:

Specify a point that defines an axis endpoint. The point you select can describe either the major or minor axis.

EasyCAD displays a stretching ellipse cursor.

3. The prompt reads



Minor axis point:

Pick a point when the dynamic cursor displays the size and shape you want.

EasyCAD draws the **ellipse** and terminates the command.

Text equivalent: **ELIPP**

Ellipses > Circle at Angle to Window



ELLIPSES > CIRCLE AT ANGLE TO WINDOW draws an *ellipse* as if it were a circle at an angle to the plane of your screen. The greater the angle, the more squashed the *ellipse*. For example, an *ellipse* at 0° to the screen looks exactly like a *circle*, and its major and minor axes are the same. An *ellipse* at 90° looks like a straight line. In an *ellipse* angled 60°, the major axis is exactly twice as long as the *minor axis*.

Note: Don't confuse angle to the screen with the inclination of the *ellipse*.

To draw a **circle at angle to window**, select [**Draw > Ellipses > Circle at Angle to Window**]:

1. The prompt reads "**Center point [x,y]:**". To specify the center of the ellipse:

- Right-click or press **ENTER** to accept the default or prior center;
- Pick a point, or;
- Type numeric coordinates and press **ENTER**.

EasyCAD displays a dynamic circular cursor, anchored at the center.



2. The prompt reads "**Major axis endpoint:**". The axis endpoint determines the ellipse's inclination. Specify a point that defines an axis endpoint.

3. The prompt reads "**Angle to screen:**". Specify the "*angle to window*" by typing an angle from 0 to 90 degrees, then press **ENTER**.

EasyCAD draws the *ellipse* and terminates the command.

Text equivalent: **ELIPC**

Ellipses > Center and Inclination



ELLIPSES > CENTER AND INCLINATION *draws an ellipse using numeric values for its inclination and its major and minor diameters.*

To draw a **center and inclination ellipse**, select [**Draw > Ellipses > Center and Inclination**]:

1. The prompt reads "**Center point [x,y]:**". To specify the center of the *ellipse*:
 - Right-click or press **ENTER** to accept the default or prior center;
 - Pick a point, or;
 - Type numeric coordinates and press **ENTER**.



EasyCAD displays a rubber-band cursor, anchored at the center.

2. The prompt reads "**Inclination angle/to point :**". Inclination determines the angle of the major axis of the ellipse. Using the rubber-band cursor, pick a point that specifies a bearing.
3. The prompt reads "**First axis diameter:**". This can be the length for either the major or minor axis diameters. The order doesn't matter, as **EasyCAD** will automatically utilize the larger value for the major axis. To specify the axis length, either type a value and press **ENTER**, or visually specify the diameter by picking points in the drawing window.
4. The prompt reads "**Second axis diameter:**". This is the length of the other axis diameter. To specify the axis length, either type a value and press **ENTER**, or visually specify the diameter by picking points in the drawing window.

EasyCAD draws the **ellipse** and terminates the command.

Text equivalent: **ELIPI**

Ellipses > Elliptical Arc



ELLIPSES > ELLIPTICAL ARC draws an *elliptical arc*. The procedure for drawing an elliptical arc is much like the **ELLIPSE:CENTER AND AXIS POINTS** command, except that the starting and ending angle of the arc segment need to be defined.

To draw an **elliptical arc**, select [**Draw > Ellipses > Elliptical Arc**]:

1. *The prompt reads*

Center point[2.55882,5.94118]:

To specify the *ellipse center*:

- Right-click or press **ENTER** to accept the default or *prior center*;
- Pick a point, or;
- Type numeric coordinates and press **ENTER**.

EasyCAD displays a rubber-band cursor, anchored at the center.

2. *The prompt reads*

Major axis endpoint

Pick a point that defines an *axis endpoint*. The point you select can describe either the major or minor axis.

EasyCAD displays a stretching *ellipse cursor*.

3. *The prompt reads*

Minor axis point:

Pick a point when the dynamic cursor displays the size and shape you want.

FastCAD draws a ghost *ellipse* and a rubber-band cursor anchored at the *ellipse's* center.

4. *The prompt reads*

Starting angle/point:

This point defines the *arc* segment based on the defined *ellipse*. Pick a point at the desired angle from the center, or type a *bearing value* and press **ENTER**.

EasyCAD displays a stretching *elliptical arc* that follows the rubber-band cursor.

5. *The prompt reads*


Ending angle/point: 

Pick a point when the *arc* looks the way you want, or type an *bearing value* and press ENTER.

EasyCAD draws the *elliptical arc* and terminates the command.


Text equivalent: **ELIPA**

Draw > Point




POINT draws a single dot (one pixel). Points are usually used as temporary reference markers that you hide or remove when your drawing is complete.

To draw a point, select [Draw > Point]:

1. The prompt reads . To specify the position of each point, pick points in the drawing window, or type numeric coordinates.
2. After drawing a point, **EasyCAD** lets you draw a series of points without re-selecting the command. Right-click to stop drawing points.

Note: On some high-resolution displays, a single pixel is very small and may be difficult to see using certain background color and entity color combinations.


Text equivalent: **POINT**



Draw > Walls

See *Chapter 8* for details on drawing **Intelligent Wall Networks**.

Fillets/Chamfer/Offset > Fillet Only



FILLETS / CHAMFER / OFFSET > FILLET ONLY draws an arc entity at the intersection of lines, circles, arcs, ellipses, and splines for a smoothly rounded corner. It does not change the selected entities in any way; it only draws the *fillet* between them. If you want the selected entities to be trimmed to the *fillet*, use the **FILLET & TRIM** command instead.

Note: do not specify fillets of zero radius. A zero-radius fillet cannot exist. Use the **TRIM TO INTERSECTION** [Edit > Trims > Trim to intersection] command instead.


To draw a **fillet**, select [Draw > Fillets/Chamfer/Offset > Fillet Only]:

1. The prompt reads "1st entity:". Pick a valid entity. **EasyCAD** highlights the selected entity.
2. The prompt reads "2nd entity:". Pick another valid entity (it must be neither parallel nor concentric to the first entity). **EasyCAD** highlights the selected entity.
3. The prompt reads "Fillet radius [x]:", where x is the prior or *default radius* value. To specify a *radius*, right-click to accept the default value, or type a new value and press **ENTER**.

EasyCAD draws the **fillet arc** without modifying the picked entities.

Text equivalent: **FIL** or **FILLET**

Fillets/Chamfer/Offset > Fillet & Trim



FILLETS / CHAMFER / OFFSET > FILLET & TRIM draws an arc entity at the intersection of lines, circles, arcs, ellipses and splines for a smoothly rounded corner. This command will trim or extend the selected lines or arcs to meet the ends of the *fillet arc*. If you want to add a *fillet* but do not want to change the selected entities in any way, use the **FILLET ONLY** command instead.

Note: do not specify fillets of zero radius. A zero-radius fillet can not exist. Use **TRIM TO INTERSECTION** [Edit > Trims > Trim to intersection] instead.


To draw a **fillet**, select [Draw > Fillets/Chamfer/Offset > Fillet & Trim]:

1. The prompt reads "**1st entity:**". Pick a valid entity. **EasyCAD** highlights the selected entity.
2. The prompt reads "**2nd entity:**". Pick another valid entity (it must be neither parallel nor concentric to the first entity). **EasyCAD** highlights the selected entity.
3. The prompt reads "**Fillet radius [n]:**". To specify a *radius*, right-click to accept the default or prior value, or type a new value and press **ENTER**.

EasyCAD draws the **fillet arc** and automatically trims or extends the selected entities to meet the ends of the *fillet arc*.

Text equivalent: **TFIL**

Fillets/Chamfer/Offset > Chamfer Only



FILLETS / CHAMFER / OFFSET > CHAMFER ONLY draws a line entity near the intersection of two entities for a beveled corner. You can add a **chamfer** to entities that cross, entities that are already connected at their endpoints, or entities that do not meet (as long as they are not parallel). **CHAMFER** does not change the selected entities in any way; it only draws the **chamfer** between them. If you want the selected entities to be trimmed to the chamfer, use the **TCHAM** command instead.

Note: Do not specify chamfers of zero length. There will be no apparent change in the drawing, but a zero-length chamfer line entity will be drawn at the intersection point. Instead, use the **TRIM TO INTERSECTION** command [Edit > Trims > Trim to intersection].


To draw a **non-trimming chamfer**, select [Draw > Fillets/Chamfer/Offset > Chamfer Only]:

1. The prompt reads "**1st entity:**". Pick a valid entity. **EasyCAD** highlights the selected entity.
2. The prompt reads "**2nd entity:**". Pick another valid entity (it must be not be parallel to the first entity). **EasyCAD** highlights the selected entity.
3. The prompt reads "**Chamfer distance [n]:**". The chamfer distance specifies how far from the intersection of the selected entities to put the chamfer line (not the length of the chamfer line). To specify the chamfer distance, right-click to accept the default or prior value, or type a new value and press **ENTER**.

EasyCAD draws the **chamfer line** without modifying the picked entities.

Text equivalent: **CHAM** or **CHAMFER**

Fillets/Chamfer/Offset > Chamfer & Trim



FILLETS / CHAMFER / OFFSETS > CAMFER & TRIM draws a line entity near the intersection of two entities for a beveled corner. You can add a **chamfer** to entities that cross, entities that are already connected at their endpoints, or entities that do not meet (as long as they are not parallel). If you do not want **EasyCAD** to trim the entities, use the command **CHAMFER**.

Note: do not specify chamfers of zero length. If you specify a **chamfer** distance of 0 (zero), **EasyCAD** will extend or trim the two lines to their intersection point. However, a zero-length line entity will be created at the intersection. Instead, use the **TRIM TO INTERSECTION** command [Edit > Trims > Trim to intersection].


To draw a **trimmed chamfer**, select [Draw > Fillets/Chamfer/Offset > Chamfer & Trim]:

1. The prompt reads "**1st entity:**". Pick a valid entity. **EasyCAD** highlights the selected entity.
2. The prompt reads "**2nd entity:**". Pick another valid entity (it must be not be parallel to the first entity). **EasyCAD** highlights the selected entity.
3. The prompt reads "**Chamfer distance [n]:**". The chamfer distance specifies how far from the intersection of the selected entities to put the **chamfer line** (not the length of the **chamfer line**). To specify the chamfer distance, right-click to accept the default or prior value, or type a new value and press **ENTER**.

EasyCAD draws the **chamfer line**, and automatically trims or extends the picked entities to meet the ends of the **chamfer line**.

Text equivalent: **TCHAM**

Fillets/Chamfer/Offset > Offset Chain



Offsets

An offset is a parallel copy of an entity.

Entities that can be offset include lines, circles, arcs, ellipses, elliptical arcs, paths, splines, and polygons.

Offsets of splines and ellipses become parallel paths of their originals.

You may use **OFFSET** or entities belonging to a **group**, even while **Lock** is on. The new offset entities will not be included in the group.

FILLETS / CHAMFER / OFFSETS > Offset Chain creates a parallel copy of a selected entity chain at a specified offset distance. **OFFSET** works with "connected" lines, circles, arcs, ellipses, elliptical arcs, paths, polygons, and splines. Entities must share endpoints to continue the sequence or "chain". If more than two entities share the same endpoint, **EasyCAD** makes a best guess as to what direction the chain is to take.

The newly created offset entities acquire the current entity properties (color, layer, line width, line style, fill style) as specified on the **Status bar**. If you wish the offset entities to have the same properties as the originals, use the **OFFSETCPY** command [**Draw > Fillets/Chamfer/Offset > Offset Copy**].

Offset copies of splines and ellipses are path entities parallel to the originals.

You may use **OFFSET** on entities belonging to a **GROUP**. The new offset entities will not be included in the group.


To create an **offset chain**, select [**Draw > Fillets/Chamfer/Offset > Offset Chain**]:

1. The prompt reads "**Distance [n]:**". To specify an offset distance:
 - Right-click or press **ENTER** to accept the default or prior distance;
 - Visually pick two points the desired distance apart, or;
 - Type a new value for the offset distance and press **ENTER**.
2. The prompt reads "**Entity:**". Pick an entity whose endpoint is shared with at least one other entity.
3. The prompt reads "**Pick a side:**". To indicate which side of the entity chain you wish the offset to be drawn, pick a point.

EasyCAD draws the **offset copy** and terminates the command.

Text equivalent: **OFFSET**

Fillets/Chamfer/Offset > Offset One



FILLETS / CHAMFER / OFFSETS > OFFSET ONE creates a parallel copy of a selected entity at a specified offset distance.

The newly created offset entities acquire the current entity properties (color, layer, line width, line style, fill style) as specified on the *Status bar*. If you wish the *offset* entities to have the same properties as the originals, use the **OFFSETCPY** command [**Draw > Fillets/Chamfer/Offset > Offset Copy**].

OFFSET1 works with *lines, circles, arcs, ellipses, elliptical arcs, paths, polygons, and splines*. *Offset copies of splines and ellipses are paths parallel to the originals.*

You may use **OFFSET1** on entities belonging to a **GROUP**. *The new offset entities will not be included in the group.*


To create an **offset chain**, select [**Draw > Fillets/Chamfer/Offset > Offset One**]:

1. The prompt reads "**Distance [n]:**". To specify an offset distance:
 - Right-click or press **ENTER** to accept the default or prior distance;
 - Visually pick two points the desired distance apart, or;
 - Type a new value for the offset distance and press **ENTER**.
2. The prompt reads "**Entity:**". Pick the entity you wish to create an *offset copy*.
3. The prompt reads "**Pick a side:**". To indicate which side of the entity *chain* you wish the offset to be drawn, pick a point.

EasyCAD draws the **offset copy**.
4. The prompt reads "**Entity:**". You may continue to select entities and *offset* directions at the distance already specified. Right-click to end the command.

Text equivalent: **OFFSET1**

Fillets/Chamfer/Offset > Offset Copy



FILLETS / CHAMFER / OFFSETS > OFFSET COPY creates a parallel copy of a selected entity chain at a specified offset distance. It works just like the **OFFSET** command *except that the new offset copies retain the same entity properties* (such as color, layer, line style, line width, etc.) as the originals.

OFFSET COPY works with "connected" lines, circles, arcs, ellipses, elliptical arcs, paths, polygons, and splines. Entities must share endpoints to continue the sequence or "chain". If more than two entities share the same endpoint, **EasyCAD** must make a best guess as to which direction the chain is to take. Otherwise, you may use **OFFSET COPY** with single unconnected entities.

Offset copies of *splines* and *ellipses* are *path* entities that are parallel to the originals.

You may use **OFFSET COPY** on entities belonging to a **GROUP**. The new *offset* entities will not be included in the group.

To create an **offset chain**, select [**Draw > Fillets/Chamfer/Offset > Offset Copy**]:

1. The prompt reads "**Distance [n]:**". To specify an offset distance:
 - Right-click or press ENTER to accept the default or prior distance;
 - Visually pick two points the desired distance apart, or;
 - Type a new value for the offset distance and press ENTER.
2. The prompt reads "**Entity:**". Pick an entity whose endpoint is shared with at least one other entity. If an unconnected entity is chosen, only that entity will be selected.
3. The prompt reads "**Pick a side:**". To indicate on which side of the entity chain you wish the offset to be drawn, pick a point.

EasyCAD draws the **offset copy** and terminates the command.



Text equivalent: **OFFSETCOPY**

Arrows

The **ARROWS** commands *draw entities* (paths, arcs, or splines) *with an arrowhead at the first node point*. Please keep in mind the following:

- The arrowhead shape and size are determined by **ARROWHEAD STYLE** [Specs > Arrowhead Style];
- The *arrowhead style* is independent from *arrowheads used in dimensions*.
- You can create notes by combining **ARROW** entities with text entities.

Path Arrow (bends)





PATHA draws connected line segments with an arrowhead placed at the first point.

1. Select the first point. Use the crosshairs and left button, or type numeric coordinates. The arrow will point here.
2. Select the next node point on the arrow. Continue selecting nodes until you press the right button to end the line.

Text equivalent: **PATHA**

Line Arrow (single)





LINEA draws lines, each with arrowheads at the first generating point. If connected lines are drawn, each segment will begin with an arrowhead.

1. Once you've selected the first point, use the crosshairs or type numeric coordinates.
2. Select the next point to draw the line. You can continue to draw a series of connected line arrows until you press the right button to end the line.

Text equivalent: **LINEA**

Arc Arrows (arrow to end)





ARCA draws an arrow to the end of the arc segment you define. The **arc radius** (r) is determined by the distance between the center (1.) and the arc begin point (2.).

1. Select the **center point**. Pick the point, or type numeric coordinates.
2. Select the 2nd and 3rd points of the **arc**. The arrow will appear on the 3rd point, at the end of the arc.

Text equivalent: **ARCA**

Arc Arrow (arrow from start)





ARCAS draws an arrow pointing to the start of the arc segment you define. The arc radius (r) is determined by the distance between the center (1.) and the arc begin point (2.).

1. Select the **center point**. Pick the point, or type numeric coordinates.
2. Select the 2nd and 3rd points of the arc in the same manner as you selected the 1st point. The arrow will appear on the 2nd point, at the start of the arc.

Text equivalent: **ARCAS**

Spline Arrow




SPLINEA draws a parabolic spline and places an arrowhead at the starting point.

1. Select the first point. Pick the point, or type numeric coordinates.
2. Select the next point. Continue selecting nodes until you right-click to end the arrow.

Text equivalent: **SPLINEA**

Double Arrows


DOUBLE ARROW commands draw entities just like the **ARROW** commands, except with arrowheads on both ends of each entity. The arrowhead shape and size are determined by **DIMSTYLE** [Specs > **Dimension Styles**]. You can create notes by combining **DOUBLE ARROW** entities with text entities. If you use **BREAK** to insert a gap in the double arrow, **EasyCAD** replaces it with two single arrows.



Path Double Arrow (bends)

1. Select the first point. Pick the point, or type numeric coordinates.
2. Select the next node point on the arrow. Continue selecting nodes, or right-click to end the arrow.


*Text equivalent: **PATHDA***



Line Double Arrow (single)

1. Select the first point. Pick the point, or type numeric coordinates.
2. Select the next point to draw the line. You can continue to draw a series of connected line arrows, or right-click to end the arrow.


*Text equivalent: **LINEDA***



Arc Double Arrow

1. Select the first point. Pick the point, or type numeric coordinates.
2. Select the 2nd and 3rd points of the arc in the same manner as you selected the 1st point.


*Text equivalent: **ARCD A***




Spline Double Arrow

1. Select the first point. Pick the point, or type numeric coordinates.
2. Select the next point. Continue selecting nodes, or right-click to end the arrow.

*Text equivalent: **SPLINED A***



Draw > Multipoly



MULTIPOLY (Multiple Polygons) *collects existing entities and turns them into a new single entity. This entity can then be hatched with a fill pattern.* For instance, a triangle you may have drawn with lines instead of with the polygon command can be “multipolied” and then hatched with a *fill style*.

An enclosed entity inside a filled area will leave a hole, or unfilled area. The entities that can be included in a *multipoly* are *lines, arcs, circles, ellipses, paths, polygons, splines, text*, and *existing multipolys*.


MULTIPOLY works differently from most others because it requires that the entities you want to *multipoly* must already exist before selecting the **MULTIPOLY** command.

In order for an applied fill style to be contained, the bounding entities must share endpoints. Otherwise, the fill pattern may leak out. When a *multipoly* is created, all affected entities are changed to the current color, layer, and style. **DONUT** and **WEDGE** are examples of *multipolys* that **EasyCAD** builds “on-the-fly”. *Multipolys* can also be used to group entities together, although it does affect the *layer, color*, and *style* of those entities.

To use, select the desired entities. **EasyCAD** replaces the selected entities with a *multipoly* entity, giving it the *current layer, color, line style*, and *fill style*.


To “un-multipoly”, use the **EXPLODE** command. An exploded *multipoly* reduces to its component entities (as if they were never multipolied). Any *fill styles* applied to an exploded *multipoly* are lost.

Text equivalent: MPOLY2



Draw > Insert Part

See *Chapter 12 Insert* for details on the **INSERT PART** command.




Draw > Draw Symbol

See *Chapter 12 Insert* for details on the **DRAW SYMBOL** command.

Drawing with Wall Networks

Architectural Drawings made easy



WALLS are a type of EasyCAD entity incorporated as a *node network*, in which each wall span has an intelligent relationship with other related walls. They also interact intelligently with symbols that have been designed to work with walls.

These abilities can make the construction of architectural drawings extremely fast and easy.

Understanding Wall Networks

In some ways, a **wall** is like a *smart path*. A **path** is a series of *connected nodes*, and so is a **wall**. But whereas a **path** is a sequence of otherwise unrelated nodes, a **wall** is a *network of related points*. All spans in a wall have awareness of the others. Additional **wall spans** can be added to a **wall network** in almost any *direction* or *length*, and attached at almost any point. **Openings or gaps** can be *cut* or *removed* from any **wall span**.

The great advantage of walls is that intersections are automatically cleaned up. When you create corners, T-intersections, or four-way intersections, no tedious or repetitive breaking or trimming is required. EasyCAD's brain does it all for you.

Note too that *walls*, of course, *have width*. The *width* is assigned to each *span at each of its two nodes*. This allows *wall segments within the same network to have different thickness*. Also, *a wall segment can have a different thickness at each end of its span*.

Since a *wall network is a homogenous entity*, it can be assigned *only one line style and fill style*. Other entity properties, such as *pen thickness for its edges, color, layer*, etc., follow suit.

Drawing Walls

Wall networks contain only one type of entity: *walls*. There are three basic methods of creating *spans* within the *network*:

1. New Walls, using the WALL command

Each use of the *wall* command creates a *new wall network*. You can draw *spans* individually, or in a connected series.

2. Added Walls, using the ADD TO command

Use the **ADD TO** command to *add new spans* to an existing *wall network*. Added *spans* will associate themselves to the selected *wall network*, *so all intersection and corner cleanups will occur automatically*.

3. Rooms, using the ROOM command

Rooms are a special constructive subset of *walls*. When you select a *room* command, you use a command similar to the **BOX** command to *create a rectangular, ortho-locked, 4-node closed wall with two diagonal corner picks*.. *Rooms* can be added to an existing *wall network*, or drawn separately.

Editing Walls

An *existing wall network* can be manipulated using the following actions:

- Add new spans
- Remove spans
- Cut gaps in spans
- Change the width of a span—either for the entire network, a single span, or any one end of any span.

Nodes

Each span in a wall network is defined by two nodes, or endpoints. Nodes exist at every endpoint, corner, or intersection. When you work with *walls*, you never directly manipulate nodes. However, everything is indirectly performed at this level.

Understanding the *node network* will help your understanding of *walls*.

You can make *nodes visible* by switching on *frames*. To switch on *frames*, type CTRL+F or select [Specs > Toggle Frames] so a checkmark appears by that menu command.


With *frames* on, *each node* appears as a gray **DOT** where present. You'll see that nodes are automatically created when you *cut* a *gap* into a *span*, or when you *intersect spans*.

Working with Smart Symbols

Smart symbols add a level of automated intelligence to *symbol* placement. If you are drawing with wall networks, you certainly want to consider using *smart symbols*.

Smart symbols, when inserted, automatically align themselves with the *span* into which they are inserted. Also, they can automatically “*cut*” and trim off the *wall* upon insertion.

Smart symbols can be easily created with the simple addition of *control points* to the *symbol definition*. Not only does this permit easy *symbol* creation, but existing *symbols* can also be converted rapidly into ready-to-use *smart symbols*.



Use the **WALL** command to create a new wall network. Walls you draw will use the width specified with the **SET WIDTH** command.


To draw a new wall network, type **WALL** at the command prompt, or select [**Draw > Walls > Wall**] from the menu:

1. The prompt reads “**1st corner:**”. Select the first point using the crosshairs, or type numeric coordinates.
EasyCAD displays a rubber-band cursor anchored at the first point.
2. The prompt reads “**Next corner:**”. Select a node point on the wall to create a span.
EasyCAD draws one span, using the current wall width. Note how the end of the wall is automatically capped. If you continue adding wall segments, the intersections are automatically cleaned up, even if you eventually return to the first point.
3. The prompt reads “**Next corner:**”. If desired, continue to select nodes. After placing the last point of the path, right-click and choose **Done** from the *Walls popup menu*.

Notice that anytime during the wall drawing process, a right-click will display the *Walls popup menu*. This control lets you quickly select the next action to take.

Text equivalent: **WALL**

Walls > Room



*The ROOM command lets you add new rooms to your drawing. A room is exactly the same construct as a **regular wall** entity, except that it is created differently. In the same way that the **BOX** command draws a **rectangular polygon** entity, **ROOM** draws a **rectangular wall** shape by *picking two diagonal corners*.*

*Rooms can be added to an **existing wall network**, or as a **new separate wall network**. When you **add a room** to an existing **wall network**, it works similarly to the **ADD TO** command. Added **rooms** will merge themselves to the existing **wall network**, so that **intersections are automatically cleaned up**. Walls added as “new” are not associated with any existing wall network.*

Once a **room** is drawn, it can be edited the same as any other **wall** entity.

To draw a **new room**, select [**Draw > Walls > Room**] from the menu:

1. The prompt reads “**Pick existing wall [new]:**”. With the pick cursor, select an existing wall network you wish to expand.

If no network currently exists, or if you wish to create a new wall network starting with a room, you may instead right-click. A right-click starts a new **ROOM** command.
2. The prompt reads “**Corner:**”. Use the mouse to select one corner of the **wall**. If you picked an existing **wall** in the first step, select a point on the selected network. If you “**eyeball**” the point, **EasyCAD** automatically snaps to the nearest point within the pick box.


3. The prompt reads “**Opposite corner:**”. Use the mouse to select the next point, completing the *room*. *A room added to an existing wall network will automatically clean up at all intersections.*

EXAMPLE: For the diagonal corner of the *room* you may use a *relative x,y length* for an exact size *room*. If you want to draw a **14’x12’ room**, place the 1st corner with a left-click and for the opposite corner type **@14’,12’** and press **ENTER**. You now have a **14’ horizontal** by **12’ vertical** rectangular *wall network*. You may now use the **CUT FROM** command to cut doorways and window openings. This is a quick way to lay out a floor plan.

4. The prompt reads “**Corner:**” again. You can continue drawing additional *rooms*. *Rooms* added in this manner will be associated with the current wall network.

When you are done adding *rooms*, right-click and select **Done** from the *Walls* popup menu .

Adding rooms to existing networks



Adding *new rooms* to existing *wall networks* is easy. In the first step, select an existing *wall network* by picking a point on any edge. To seamlessly attach the added *room*, be sure to pick one corner point along an *existing wall's centerline*. To help pick this point, you can turn on frames (**CTRL+F**) . If you pick close to a *wall node*, **EasyCAD** will automatically snap you to the precise point.

Text equivalent: **ROOM**

Walls > Offset



WALLS > OFFSET creates a parallel copy of the existing wall network, offset by the specified distance. The offset copy determines its shape from the outside edge of the selected wall. The offset distance is added to the existing wall to determine the width of the new wall. For example, if the existing wall's width is 5.0, and you specify an offset of 3.0, the *width* of the offset wall network will be 8.0.

The offset copy draws with the same entity properties as the original. However, the offset wall is a different network, so you can separately change its *line style*, *color*, etc., as you would any other entity.

Note that the standard **OFFSET** commands, found in the **Draw** menu's **FILLETS/CHAMFERS/OFFSETS** sub menu, *will not work on wall network entities*.

To *offset and existing wall network*, select [**Draw > Walls > Offset**] from the menu:

1. The prompt reads "**Wall to change:**". With the pick cursor, select the *existing wall network* you wish to *offset*.
2. The prompt reads "**Offset distance:**". To specify an offset distance:
 - Use the mouse to visually pick two points the desired distance apart, or
 - Type a new value for the *offset* distance and press **ENTER**.


As soon as you enter the value, the offset wall entity is created.

3. The prompt reads "**Offset distance:**". You can continue creating *offset copies*, or right-click for the **Walls** popup menu and left-click the **Done** command.

If you continue, the value you specify will be added to the *width* of the last *offset wall network*, not to the originally selected *wall network*.

Text equivalent: **WLOFST**

Walls > Add to



The ADD TO command lets you add new spans to an existing wall network. Any span added to a wall network becomes part of that network.


To *add a wall* to an existing network, type **ADD TO** or select [**Draw > Walls > Add to**]:

1. The prompt reads “**Pick existing wall [new]:**”. With the pick cursor, select the existing wall network you wish to expand.
If no network currently exists, or if you wish to create a new wall network, you may instead right-click. A right-click will cause the command to continue as the regular **WALL** command.
2. The prompt reads “**1st corner:**”. Use the mouse to select the point on the network. If you “eyeball” the point, **EasyCAD** snaps to the nearest node within the pick box.
3. The prompt reads “**Corner:**”. Use the mouse to select the next point, completing the span. When you do, note that the *new wall breaks* and *trims* as necessary to form a clean intersection with the existing *wall network*.
4. The prompt reads “**Corner:**”. You can continue drawing additional spans. Because the *spans* are part of the *existing network*, all intersections with the selected network are *automatically cleaned up*. Whenever you are done adding walls, right-click and select **Done** from the *Walls popup menu*.

Because you are adding to an existing wall network, the *new walls* will disregard your current property setting and instead use those of the selected network. Such properties include *color*, *pen thickness*, *line style*, *fill style*, *layer*, etc.


Text equivalent: WLADD

Walls > Cut from



The CUT FROM command lets you remove linear segments from existing spans.

This command does not affect the resulting *spans*' associations with the original network. For example, if you have a network that consists of *one span*, then use the **CUT FROM** to separate the *span* in the middle, the resulting two *walls* are still part of the same network.



The wall cut between points A-A is valid. However, the B-B cut is not valid because the two cut points cross the node present at the wall intersection.

The two points that define a *cut* must be made on the *same span*. Remember that a *span* is the length between any two nodes. At every point where *walls* intersect, even at T-intersections, there is a network node. Therefore, *cuts must be made between intersections*.

To *cut a span segment*, type **CUT FROM** at the command prompt, or select [**Draw > Walls > Cut from**] from the menu:

1. The prompt reads “**Wall to change:**”. Select the *wall network* you wish to *cut*. You can select any point on the network; you do not have to specifically select the target *span*.
2. The prompt reads “**First corner:**”. Use the mouse to select the *first cut point* on the target *span*.

EasyCAD displays a rubber band cursor from the first point.

3. The prompt reads “**Next corner:**”. Define the length of *span to cut*. Use the mouse to select the *second cut point* on the *target span*.


EasyCAD removes the defined segment from the *span*.

If the selected point is not valid, **EasyCAD** displays an alert box telling you so. Re-select the point, ensuring that the selection point is within the *wall* boundary, and on the *same span*.

4. The prompt reads “**First corner:**” again. If you are finished, right-click and choose **Done** from the *Walls popup menu*. You can instead choose to continue, as long as the cuts are on the *wall network*. If you wish to continue cuts on different *wall network*, you must right-click for the *walls* popup menu and left-click on the **Done** command to finish the *current cut operation* and repeat the **CUT FROM** command with a right or left mouse click.

Text equivalent: WLCUT

Walls > Remove Side



*The **REMOVE SIDE** command lets you remove entire spans from an existing wall network. Remember that a span is the length between each node. Nodes occur at all endpoints and/or intersections.*

To *remove a span*, type **WLRMV** at the command prompt, or select [**Draw > Walls > Remove side**] from the menu:

1. The prompt reads “**Wall to change:**”. Select the actual *span* you wish to *remove*.
EasyCAD automatically removes the selected span and squares off the ends of the remaining segments in the network.
2. The prompt reads “**Wall to change:**”. You may continue selecting spans to remove, or right-click for the *walls* popup menu and left-click on the **Done** command to finish.

*Text equivalent: **WLRMV***

Walls > Set Width



The **SET WIDTH** command lets you set the width for all new spans drawn with the **WALL**, **ROOM**, or **ADD TO** command. After a new width is entered, the **SET WIDTH** command defaults directly into the **ADD TO** command to allow immediate wall construction.

To set a new wall width, type **SET WIDTH** at the command prompt, or select [**Draw > Walls > Set Width**] from the menu:

1. The prompt reads “**Wall width [n]:**”. Type in a new wall width in drawing units and press **ENTER**; or specify a distance on the screen, using the mouse. At this point if you do not enter a different width than the default displayed between the brackets and right-click or press **ENTER**, the command is terminated.
2. The prompt reads “**Pick existing wall [new]:**”. At this point, the command switches to the **ADD TO** command [**Draw > Walls > Add to**]. Any spans you draw now will use the new width. If you wish to end the command at any point, right-click and choose **Done** from the *Walls popup menu*.

Text equivalent: **WLWID**

Walls > Chg Wid All



*The **CHANGE WIDTH ALL** command lets you change the width of an entire wall network. Every span in the network will have its width reset to the width you specify.*

Be careful when using this command with *wall* systems where you have created *spans* of varying *widths*. **CHANGE WIDTH ALL** will instantly reset those *widths* to the new value. If this happens, use the **UNDO** command to restore your drawing.

To set a *wall network* to specified *new width*, select [**Draw > Walls > Chg Wid All**] from the menu:

1. The prompt reads “**Change width to [n]:**”. Type in a *new width* in drawing units and press **ENTER**; or specify a distance on the screen using the mouse. At this point if you do not enter a different *width* than the default displayed between the brackets and right-click or press **ENTER**, the command is terminated.
2. The prompt reads “**Wall to change:**”. Using the pick box, select any point on a *wall network*.
FastCAD immediately redraws the network using the specified *width*.
3. The prompt reads “**1st corner:**”. At this point, the command switches to the **ADD TO** command [**Draw > Walls > Add to**]. Any new spans you draw now use the *width* last specified with the **SET WIDTH** command.

If you wish to quit at any time, right-click for the *walls* popup menu and left-click on the **Done** command.

Text equivalent: **WCWIDA**

Walls > Chg Wid Span



The **CHANGE WIDTH SPAN** command lets you change the width of a single span in a wall network.


To change the **width** of an existing **span**, select [**Draw > Walls > Chg Wid Span**] for the menu:

1. The prompt reads “**Change width to [n]:**”. Type in a **new width** in drawing units and press ENTER; or specify a distance on the screen, using the mouse. At this point if you do not enter a different **width** than the default displayed between the brackets and right-click or press **ENTER**, the command is terminated.
2. The prompt reads “**Wall to change:**”. Using the pick box, select the specific **span** you wish to modify.

EasyCAD immediately redraws the network, re-specifying the **width** of the targeted **span**.

3. The prompt still reads “**Wall to change:**”. Using the pick box, you can continue to select **spans** set to the **new width**. Or to finish, right-click and select **Done** from the **Walls popup menu**.

Span widths and Left/Right edge locking



This illustration shows the effects of wall widths when walls are drawn with left or right edge locking. Note the location of the nodes.

Draw walls with edge locking by selecting Left or Right from the **Walls popup menu** (to display, right-click when drawing walls). "Left" or "right" corresponds with "inside" or "outside" depending upon orientation.

When **walls** are drawn with left or right edge locking, those edges remain fixed when **new widths** are applied to **spans** (or to the entire wall network). This ability lets you change the thickness of a **wall** without changing the inside or outside perimeter (whichever is fixed). In default center-locking mode, **spans widen** or **narrow** about the **span** centerline(s).

Text equivalent: **WCWIDS**

Walls > Chg Wid End



The **CHANGE WALL WIDTH END** command lets you change the width at a single span's endpoint. A span can have different widths at each node, enabling you to create walls with a taper. The end width is the length measured at the endpoint, perpendicular to the direction of the span.

To change the end width of an existing span, select [**Draw > Walls > Chg Wid End**] from the menu:

1. The prompt reads “**Change width to [n]:**”. Type in a new width in drawing units and press ENTER; or specify a distance on the screen, using the mouse. At this point if you do not enter a different width than the default displayed between the brackets and right-click or press **ENTER**, the command is terminated.
2. The prompt reads “**Wall to change:**”. Using the pick box, select the specific span near the endpoint you wish to modify.

EasyCAD immediately redraws the network, re-specifying the end width of the targeted span.

3. The prompt still reads “**Wall to change:**”. Using the pick box, you can continue to select spans, modifying their chosen endpoint widths. Or to finish, right-click and select **Done** from the *Walls popup menu*.

Text equivalent: **WCWIDE**

Walls popup menu



Walls popup menu

Notice that anytime during the wall drawing process, a right-click will display the **Walls popup menu**. This control lets you quickly select the next action to take. Most drawing operations require that you select **‘Done’** from this menu to complete the command.

Next Corner Returns to the “**Next point:**” prompt, allowing you to add more wall segments.

Break Allows you to interrupt the current wall path, and draw a *new wall path* that is still part of the *same network*. Walls that are drawn using break will intersect cleanly with the active network.

add Room This is a shortcut to the **ROOM** command, except that it defaults into add mode and auto-selects the wall you are currently drawing or editing.

Done Finishes drawing the current wall network. If you wish to add to the finished network, you must use the **WALL>ADD TO** command. The regular **WALL** command starts a new network that is independent of the existing network.

Cancel Selecting this will cancel the active draw/edit operation. Note that a **Cancel** is not the same as an **UNDO**. A cancelled operation cannot be recovered.

Remove This works identically to the **REMOVE SIDE** command. To erase a span, select a span from any network. The wall segment will be deleted without affecting the remaining network, even if it has been separated into separate networks that share no common nodes.


Cut This is a shortcut to the **WLCUT** command, to work on the *wall network* you are currently constructing. **WLCUT** removes a specified section from a span. When invoked, **EasyCAD** prompts you to enter the two endpoints of the cut. Both cut points must be selected on the same span. **EasyCAD** then removes that section from the network.

Offset This is a shortcut to the **WLOFST** command, to work on the wall network you are currently constructing. **WLOFST** creates a parallel copy of the existing *wall network*, *offset* from the *outer edge* by the specified distance. The *offset copy* draws with the same entity properties as the original. However, it is a different network, so you can separately change its line style, color, etc., as you would any other entity.

Left/Center/Right Select during wall construction to set the “**locking**” edge. When **Center** is selected, the nodes defined during the draw process define the centerline of each span. When **Left** or **Right** is selected, the nodes define the wall perimeter (inside or outside edge, depending on the orientation). Setting **Left** or **Right**

is helpful when the wall-to-wall distance is known. When wall widths are modified, the left/right wall edge will remain fixed; the wall reflects the new thickness by displacing the opposite edge.

Width > Child Menu



Width > Width This is a shortcut to the **WLWID** command [**Draw > Walls > Width**]. This command interrupts the current drawing process, and allows you to specify a new uniform wall width for walls drawn from that point. At the “**Wall width [n]:**” prompt, you can type in a new width or specify a new distance with the mouse. **EasyCAD** then prompts you to “**Pick existing wall [new]:**”. If you pick an existing wall, new walls with the new width will be added to the selected network. If you right-click, a new network will be started.

Width > Change All This is a shortcut to the **WCWIDA** command [**Draw > Walls > Chg Wid All**]. This command suspends the current draw operation and allows you to change the width of all spans in a selected network.

Width > Change Span This is a shortcut to the **WCWIDS** command [**Draw > Walls > Chg Wid Span**]. This command suspends the current draw operation and allows you to change the width of a single selected span.

Width > Change End This is a shortcut to the **WCWIDE** command [**Draw > Walls > Chg Wid End**]. This command suspends the current draw operation and allows you to change one end width of a single selected span.

Chapter 9

Dimension Commands

Add measurement and scale to your drawings

Draw Dimensions Faster

When you draw dimensions, it's important not to "eyeball" any points.

Typically, you would use modifiers to assist in precision selection. The most common modifier used is EPT (endpoint).

A faster method is to turn on the Attach mode. The Attach button is located at the bottom of the screen on the *Button bar*. Right-click it and make sure that Nearest Endpoint is the selected mode.



When Attach mode is active, you won't need the EPT modifier. When you select a point on an entity, it will automatically snap to the entity's nearest endpoint.

Dimensions make your drawing useful by providing real life measurements that are used to construct, scale, or layout the information described in your drawings.

EasyCAD facilitate dimensioning by providing a set of specialized commands to measure distances and angles, and placing that information on the screen.

EasyCAD dimensions are associative. If you dimension an entity and then stretch or scale both the dimension and entities together, the dimension will update to reflect the new measurement.

Dimension commands fall into three broad categories:

- **Linear**, which measure distances between specified points.
- **Angular**, which measure angular widths.
- **Circular**, which measure radii or diameters with proper symbols.

Use the **DIMENSION STYLE** command [Specs > Dimension Style] to set properties for *dimensions* you are about to draw. Use **CHANGED** command [Edit > Change > Dimension Style] to *change properties* of *dimensions* you have already drawn. Invoking either command displays the *Dimension Style dialog* box.

Dimension entities also possess *Line Width* and *Line Style* properties and draw with these properties. The **CHANGE PEN THICKNESS**, **CHANGE-LINE WIDTH** and **CHANGE-LINE STYLE** commands work with dimensions.


To set the *text color different from the rest of the dimension*, use the **CHANGEC2** command [Edit > Change > Fill (2nd) Color], and apply it to the selected *dimension(s)*. *Only the text will redraw with the secondary color.* The leaders, extension lines, and arrowheads will remain the same as the primary color.

The **DYNEDIT** command [Edit > Dynamic Edit] provides the following capabilities on drawn *dimensions*:

Linear, Horizontal, Vertical, Parallel, or Baseline Use **DUNAMIC EDIT** to *visually reposition the dimension line*. If you hold down the **SHIFT** key, you can *visually reposition the dimension text*. The *dimension remains associative*.

Ordinate Use **DYNAMIC EDIT** to *insert or delete* leaders.

Linear



LINEAR dimensions measure and display either the *horizontal or vertical* distance between two points (or of an existing entity). If you *pick the dimension points horizontally* EasyCAD determines that you want a *horizontal dimension*. If you *pick the two dimension points vertically*, EasyCAD determines that you want a *vertical dimension*.

Drawing Horizontal and Vertical Dimensions around entities at the same time:

You can actually *dimension* around each side of an entity or entities such as **polygons** and **segments of paths** and depending on where the pick points are, EasyCAD will draw the proper *horizontal or vertical dimension*. This means that if you had a rectangle and you wanted to *dimension* the *top horizontal side* and the *right vertical side*, pick the first and second *dimension* points at the left and right endpoints of the top horizontal side and then pick the lower endpoint of the right side for the third *dimension* point EasyCAD will draw a *horizontal dimension on the top* and a *vertical dimension on the right side*. This is a real time saver.

EasyCAD allows *dynamic placement of the dimension and text*. Final placement and orientation is dependent upon your dynamic selection.

1. The prompt reads “**1st geometry point:**”. To select a point, use the crosshairs or type numeric coordinates. **Modifiers** or the **Attach mode** should be used to ensure precise point selection.
2. The prompt reads “**Next geometry point:**”. EasyCAD displays a dynamic cursor of the dimension.
3. The prompt reads “**Text baseline point (Shift =Spec Text Center):**”. Depending on where you move the dynamic cursor, EasyCAD will draw a

horizontal or vertical dimension. Text placement snaps to default positions, again depending upon the position of the dynamic cursor. If you hold down the **SHIFT** key and move the cursor, the text “**separates**” from the extension and dimension lines, allowing custom placement of the text.

Keyboard entry is not applicable for this input. Left-click when you are satisfied with the placement and orientation of the dimension. **EasyCAD** draws the **dimension**.

4. The prompt reads “**Next geometry point:**”. You can right-click to end dimensioning. Otherwise, **EasyCAD** allows you to continue the dimension chain in the orientation (horizontal or vertical) in which you placed the first dimension entity. From the previous point, select a point at the other end of the distance to be measured.
5. The prompt reads “**Text baseline point (Shift = Spec Text Center):**”. Again, you have dynamic control over the placement of the dimension line. The new dimension builds off the last point of the previous dimension. Right-click to accept the default which draws dimension text and arrows lined up with (in line with) the last dimension you drew. Keyboard entry is not applicable for this input.

EasyCAD keeps extension lines at right angles to dimension arrows during all drawing and editing operations.

When **EasyCAD** places a **linear dimension text**, it adheres to the text alignment parameters as specified in the **Dimension Style dialog box**.

Setting properties for new linear dimensions:

Use the **DIMENSION STYLE** command [**Specs > Dimension Style**].

Position editing of baselines or text of an existing linear dimension:

Use the **DYNAMIC EDIT** command [**Edit > Dynamic Edit**] to dynamically reposition the dimension line. Hold down the **SHIFT** key to reposition the text. The **DIMENSION** remains associative.

Editing properties for an existing linear dimension:


Use the **EDIT** command [**Edit > Edit**] to change the **arrowhead**, **leader options**, **tolerances**, and **text properties** and **position** for an existing **linear dimension**. Only options you “**touch**” will take effect, unless you apply a named **dimension style**.

To enter a fixed dimension text value:

Use the **EDIT** command, select the **dimension(s)**, and enter a new value between the **less than** and **greater than** brackets in the window labeled **Text format <>** **denotes value location** in the **Dimension Style dialog box**. The value you enter must be numerical (alphabetic characters and other non-numerical characters are not valid). **The value you enter will not change if the dimension is stretched or scaled**. If you wish to revert the fixed value back to its default associative mode, use the **EDIT** command again, select the same **dimension** and remove the value from between these brackets..You may also add **prefix** and **suffix text** to **dimensions** by

placing the *prefix text on left side* and *the suffix text on the right side* of the brackets (**prefix<fixed value>suffix**).

EXAMPLE:




Fixed value only - <4.75>

Prefix & fixed value - aprox<4.75>

Prefix, suffix & fixed value - aprox<4.75>less .5

Text equivalent: DIML

Horizontal



HORIZONTAL dimensions measure and display only the *horizontal* distance (along the **X axis**) between two points (or of an existing entity), ignoring any vertical difference between the points. Dimension text and arrows are *horizontal*.

The *dimension* entity data structure is identical to that created by the **LINEAR DIMENSION** command.

1. The prompt reads “**1st geometry point:**”. To select a point, use the crosshairs or type numeric coordinates. Modifiers or the **Attach mode** should be used to ensure precise point selection.
2. The prompt reads “**Next geometry point:**”. **EasyCAD** displays a dynamic cursor of the *dimension*.
3. The prompt reads “**Text baseline point (Shift = Spec Text Center):**”. Text placement snaps to default positions, depending upon the position of the dynamic cursor. If you hold down the **SHIFT** key and move the cursor, the text “**separates**” from the extension and *dimension lines*, allowing custom placement of the text.


Keyboard entry is not applicable for this input. Left-click when you are satisfied with its placement and orientation. **FastCAD** draws the *horizontal dimension*.

4. The prompt reads “**Next geometry point:**”. Right-click to end dimensioning. Otherwise, **FastCAD** allows you to continue the *dimension chain* in the direction in which you selected the first two points. From the previous point, select a point at the other end of the distance to be measured. *The next dimension will automatically be drawn inline with the dimension text and arrows of the last dimension you drew*. Keyboard entry is not applicable for this input.

EasyCAD keeps extension lines at right angles to *dimension arrows* during all drawing and editing operations.

Text equivalent: **DIMH**

Vertical



VERTICAL dimensions measure and display only the *vertical distance (along the Y axis)* between two points (or of an existing entity), ignoring any horizontal difference between the points. *Dimension arrows are horizontal.* You can control the orientation of *vertical dimension text* with **DIMENSION STYLE** command [Specs > **Dimension Style**]. Check the '*Text: Align text with arrows*' check box if you want the *dimension text to read vertically instead of horizontally*.


The direction that the **TEXT** reads depends on how you pick the points to *dimension between*. If you select the two points from **TOP** to **BOTTOM** the *dimension text* will read from **TOP** to **BOTTOM**. Pick the two points from **BOTTOM** to **TOP** and the *dimension text* will read from the **BOTTOM** to the **TOP**.

The *dimension* entity data structure is identical to that created by the **LINEAR DIMENSION** command.

To draw **VERTICAL DIMENSIONS**, follow the methodology outlined for the **HORIZONTAL DIMENSION** command, except in the *vertical orientation*.

Text equivalent: **DIMV**

Parallel




PARALLEL dimensions measure and display the actual distance, *at any angle*, between two points (or of an existing entity). **Parallel dimensions** have identical length leader lines.

To draw **parallel dimensions**, follow the methodology outlined for the **HORIZONTAL DIMENSION** command, except in an orientation parallel to the reference entity.

Text equivalent: **DIMP**

Ordinate



ORDINATE (also called rectangular coordinates) *dimensions* show the relative *horizontal* or *vertical* distance from a *local origin point* that you select. An *ordinate dimension* entity consists of an *origin leader* and a series of *additional leaders*, each of which displays its *horizontal distances* across the bottom and *vertical distances* up the side.

1. The prompt reads “**Dimension origin:**”. This is the point from which you wish to measure. To select the *origin*, use the cursor or type numeric coordinates.

EasyCAD displays a rubber-band cursor anchored at the *origin point*.

2. The prompt reads “**Text baseline at:**”. Select a location for the *origin point's text*. This point also determines whether you are drawing a *horizontal* or *vertical dimension*. Pick a point to the left or right of the origin to measure vertical distances; pick a point above or below the origin to measure horizontal distances. **Modifiers** (and the active **attach mode**, if toggled on) can be used.

EasyCAD draws the origin text and leader using the active color and line style. Note that the rubber-band cursor is locked parallel to the *origin leader*.

3. The prompt reads “**Dimension point:**”. Select a point on the object you want to measure.

EasyCAD draws the ordinate dimension value and leader.

4. The prompts reads “**Dimension point:**”. Continue selecting dimension points as needed. To end the command, right-click or press **ENTER**.

Typically, at this point, you would construct *ordinate dimensions* in the *perpendicular direction*. For example, if your first set of *ordinate dimensions* were *horizontal*, you would now create *ordinate dimensions* for those same objects in the *vertical direction*.

Setting properties for new dimensions (of any kind) Use the **DIMENSION STYLE** command [Specs > Dimension Style].


Adding or removing leaders to an existing ordinate dimension Use the **DYNAMIC EDIT** command [Edit > Dynamic Edit] to add a new leader. After you select any *ordinate leader* you are automatically in *insert mode* to *add* new leaders. Hit the **DEL** key and click a leader to *remove it*. After removing a leader you are automatically back to *insert mode* so press the **DELETE** key again to remove another leader. Right-click to terminate the **DYNAMIC EDIT** command.

Editing properties for an existing ordinate dimension Use the **EDIT** command [Edit > Edit] to change the arrowhead, leader options, tolerances, text properties and position for an existing ordinate dimension. Only options you “**touch**” will take effect, unless you apply a named dimension style.

You may add *prefix* and *suffix* text to on *Ordinate dimensions* using the *Dimension Style dialog* but if you add a *fixed value* it will appear in *all leaders* of the *dimension*.

Text equivalent: DIMO

Baseline



BASELINE dimensions show the relative *horizontal* or *vertical* distance from a *local origin point* that you select. Each *dimension* you *add* is *automatically* “*stacked*” *adjacent to the previous baseline dimension*.

Each *baseline dimension* entity is identical to that created by the **LINEAR DIMENSION** command, and their construction method is also similar. However, *baseline dimensions* and *ordinate dimensions* share more similar usage traits. Your own style requirements will dictate usage of one over the other. Typically, *ordinate dimensions* are more common in *mechanical drawings*, while *baseline dimensions* are more prevalent in *architectural drawings*.

1. The prompt reads “**1st geometry point:**”. To select a point, use the crosshairs or type numeric coordinates. **Modifiers** or the **Attach mode** should be used to ensure precise point selection. To select an entity to dimension, right-click or press **ENTER**, then use the pick cursor to select an entity.
2. The prompt reads “**Next geometry point:**” **EasyCAD** displays a dynamic cursor of the dimension.
3. The prompt reads “**Text baseline point (Shift = Spec Text Center):**”. Depending on where you move the dynamic cursor, **EasyCAD** will draw a horizontal or vertical dimension. Text placement snaps to default positions, again depending upon the position of the dynamic cursor. If you hold down the **SHIFT** key and move the cursor, the text “**separates**” from the extension and dimension lines, allowing custom placement of the text.

Keyboard entry is not applicable for this input. Left-click when you are satisfied with the placement and orientation of the *dimension*. **EasyCAD** draws the *dimension*.

4. The prompt reads “**Next geometry point:**”. You can right-click to end dimensioning. Otherwise, **EasyCAD** allows you to continue the *dimension chain* in the orientation (*horizontal* or *vertical*) in which you placed the first *dimension*.

From the previous point, select a point at the other end of the distance to be measured.

EasyCAD draws the *dimension*, spaced as specified in the **Baseline Spacing** field in the *Dimension Style dialog*. Continue adding more points, or right-click to end.

EasyCAD keeps *extension lines* at *right angles* to *dimension arrows* during all drawing and editing operations.

Setting properties for new dimensions (of any kind) Use the **DIMENSION STYLES** command [Specs > Dimension Style].


Position editing of baselines or text of an existing baseline dimension

Use the **DYNAMIC EDIT** command [Edit > Dynamic Edit] to dynamically reposition the *dimension line*. Hold down the **SHIFT** key to reposition the text. The *dimension remains associative*.

Editing properties for an existing baseline dimension Use the **EDIT** command [Edit > Edit] to change the arrowhead, leader options, tolerances, and text properties and position for an existing *baseline dimension*. Only options you “touch” will take effect, unless you apply a named *dimension style*.

To enter a fixed dimension text value Use the **EDIT** command, select the *dimension(s)*, and enter a new value between the *less than* and *greater than* brackets in the window labeled *Text format <> denotes value location* in the *Dimension Style* dialog box..The value you enter must be numerical (alphabetic characters and other non-numerical characters are not valid). *The value you enter will not change if the dimension is stretched or scaled*. If you wish to *revert the fixed value back to its default associative mode*, use the **EDIT** command again, select the same *dimension* and *remove the value from between these brackets*..You may also add *prefix* and *suffix text* to *dimensions* by placing the *prefix text on left side* and the *suffix text on the right side of the brackets* (prefix<fixed value>suffix).

EXAMPLE:




Fixed value only - <4.75>

Prefix & fixed value - aprox<4.75>

Prefix, suffix & fixed value - aprox<4.75>less .5

ext equivalent: DIMB

Full Angular



FULL ANGULAR dimensions measure an *angle width (in degrees)* and displays that value. You specify the *center*, *starting point*, and *ending point* of the *angle*. Optional leaders are drawn in the current line style. *Angular dimensions* are specified in the *positive angular direction*.

To draw *angular dimensions*, select **[Dimensions > Full Angular]**:

1. The prompt reads "**Angle vertex:**". Pick a point (for example, the intersection of two lines) or type numeric coordinates. The *angle vertex* also determines the *center* of the *dimension arc*.

EasyCAD draws a rubber-band cursor from the center.

2. The prompt reads "**Start point on arc:**". The *starting point* specifies:
 - *Starting angle* of the *dimension arc*
 - *Radius* of the *dimension arc*

Use the dynamic cursor to pick a point.

EasyCAD displays a rubber-band cursor, anchored at the *starting point* and radially aligned to the *angle vertex*.

3. The prompt reads "**Start leader extend [none]:**". If no leader is desired, right-click or press **ENTER**. To create a leader, stretch the cursor and click when the leader is the desired size.

EasyCAD draws the leader and displays dynamic cursor of the dimension form.

4. The prompt reads "**End arc bearing point:**". Stretch the cursor and pick a point when the angular width of the dimension is correct.

EasyCAD displays a rubber-band cursor for the second leader.

5. The prompt reads "**End leader extend [none]:**". When **EasyCAD** asks for the length and orientation of the second leader, specify as you did for the first.


EasyCAD draws the dimension counterclockwise from the starting point to the ending point, and the command terminates

To set properties for new dimensions, use **DIMENSION STYLE**.

To *edit properties* for an existing *angular dimension*, use **EDIT**.

To enter a fixed dimension text value Use the **EDIT** command, select the dimension(s), and enter a new value between the *less than* and *greater than* brackets in the window labeled *Text format <> denotes value location* in the *Dimension Style dialog box*..The value you enter must be numerical (alphabetic characters and other non-numerical characters are not valid). The value you enter will not change if the dimension is stretched or scaled. If you wish to *revert the fixed value back to its default associative mode*, use the **EDIT** command again, select the same dimension and *remove the value from between these brackets*..You may also add *prefix* and *suffix text* to dimensions by placing the *prefix text on the left side* and the *suffix text on the right side of the brackets* (prefix<fixed value>suffix).

EXAMPLE:



Fixed value only - <4.75>

Prefix & fixed value - aprox<4.75>

Prefix, suffix & fixed value - aprox<4.75>less .5

Text equivalent: DIMA

Use the dynamic cursor to pick a point.

EasyCAD displays dynamic cursor of the dimension form. The dynamic cursor is anchored at the *vertex*, and the *radius* and leaders shrink or grow according to mouse movement.

4. The prompt reads "**Point on arc (SHIFT to set fixed text position):**". Stretch the cursor and pick a point to place the *dimension text*. If you move the mouse through the "**Angle vertex**" point (step 1), the dimension switches to measure the outer angle width.

During this step, the text can be repositioned by holding down the **SHIFT** key and moving the mouse. When you satisfied with the location of the text, release the **SHIFT** key.


After you pick a point, **EasyCAD** *draws the dimension counterclockwise from the starting point to the ending point*, and the command terminates.

To set properties for new dimensions, use **DIMENSION STYLE**.

To *edit properties* for an existing *angular dimension*, use **EDIT**.

To enter a fixed dimension text value Use the **EDIT** command, select the *dimension(s)*, and enter a new value between the *less than* and *greater than brackets* in the window labeled *Text format* <> *denotes value location* in the *Dimension Style dialog box*. The value you enter must be numerical (alphabetic characters and other non-numerical characters are not valid). The value you enter *will not change if the dimension is stretched or scaled*. If you wish to *revert the fixed value back to its default associative mode*, use the **EDIT** command again, select the same dimension and *remove the value from between these brackets*. You may also add *prefix* and *suffix text* to *dimensions* by placing the *prefix text on the left side* and the *suffix text on the right side of the brackets* (prefix<fixed value>suffix).

EXAMPLE:




Fixed value only - <4.5>

Prefix & fixed value - aprox<4.75>

Prefix, suffix & fixed value - aprox<4.75>less .5

Text equivalent: **DIMAQ**

Radius



RADIUS dimensions measure the *radius* of a *circle* or *arc* and display that value.

To draw a *radius dimension*, select **[Dimension > Radius]**:

1. The prompt reads "**Circular entity:**". Pick a circle or arc at the arrow leader attachment point.

EasyCAD displays a rubber-band cursor anchored to the pick point, and radially aligned with the entity's *center point*.

2. The prompt reads "**Bend point [inside]:**". If you right-click, **EasyCAD** will automatically draw the dimension from the *center point* to the pick point, and the command terminates.

Otherwise, you can pick the bend point for the arrow leader. The leader can be either inside or outside the entity. Use the rubber-band cursor to visually determine the leader length.


3. The prompt reads "**Leader end point [standard]:**". If you right-click, **EasyCAD** automatically draws the horizontal portion of the leader, connecting the text to the leader bend point. **EasyCAD** uses the current dimension arrow length as the "**standard**" leader length.

Otherwise, you can manually specify the leader length by picking a point on the screen.

EasyCAD draws the radius dimension adjacent to the leader and terminates the command. Radius dimensions begin with the capital letter **R**.

Text equivalent: **DIMR**

Diameter



DIAMETER *dimensions* measure the *diameter* of a *circle* or *arc* and display that value.

To draw a *diameter dimension*, select [**Dimension > Diameter**]:

1. The prompt reads "**Circular entity:**". Pick a *circle* or *arc* at the arrow leader attachment point.

EasyCAD displays a rubber-band cursor anchored to the pick point, and radially aligned with the entity *center point*.

2. The prompt reads "**Bend point [inside]:**". If you right-click, **EasyCAD** will automatically draw an interior dimension from the pick point through the *center*, and the command terminates.

Otherwise, you can pick the bend point for the arrow leader. The leader can be either inside or outside the entity. Use the rubber-band cursor to visually determine the leader length.

3. The prompt reads "**Leader end point [standard]:**". If you right-click, **EasyCAD** automatically draws the horizontal portion of the leader, connecting the text to the leader bend point. **EasyCAD** uses the current dimension arrow length as the "**standard**" leader length.

Otherwise, you can manually specify the leader length by picking a point on the screen.

EasyCAD draws the diameter dimension adjacent to the leader and terminates the command. *Diameter dimensions* begin with the letter **phi** as the first character in the *dimension*.


Text equivalent: **DIMD**



Dimension Style

Dimension Style Dialog Box

This dialog box is displayed when you invoke the **DIMENSION STYLES** command by clicking the *Dimension Style* icon as seen at the left or selecting [**Specs > Dimension Styles**] from the menu, the **CHANGE-DIMENSION STYLE** command [**Edit > Change > Dimension Style**], or when selecting a dimension entity using the **EDIT** command [**Edit > Edit**]. All of the parameters that control how a **Dimension** will appear on the screen are set from this dialog box.



Style Name Style Name Window

This window displays the names of the Dimension Style sets you set up. Setting up a series of **Dimension Style Sets** can be a real time saver. You set the desired **Dimension Text Height**, **Font Style**, **Arrowhead style** and **size**, **Dimension Text Position**, **Thickness** for the **Leaders**, type of **Dimension Tolerance** etc. You then click the **Add** button and type a **Style Name** in the window and click **OK**. You may set up several **Dimension Style Sets** and select them from the **DStyle Status** window drop-down menu. All of **Dimension** properties of the **Dimension Style Set** are changed at once. You may use the [**Edit > Change > Dimension Style**] and select one or more **Dimension** entities and select a different **Dimension Style Name** and they all change at once to the properties of the new **Dimension Style Set**.

AutoUpdate Box

When checked, **EasyCAD** automatically applies the current format to all **dimensions** with the same **named dimension style**. If you want dimensions of the same named style to have different formats, leave this option unchecked.

Add Button

Creates a new **Dimension Style Name**. Initially, the new style will acquire the current listed properties. As styles are added, they are auto-named **#n**, where n is the next ordinal number. To rename any style, click into the Name field and type in a new name.

Delete Button

Deletes the selected Dimension Style.

Dimension Arrowhead

Dimension Style

Style Name: (Individual) ☐ AutoUpdate Add Delete

Arrowhead

Type:

Length: 0.18000

Height: 0.08000

Thickness: 0.00000mm

Leaders

Offset Dim Point: 0.06250

Extend past text: 0.18000

Thickness: 0.00000mm

Tolerance Display format

☐ Symmetrical ☐ Limits
☐ Deviation ☐ Basic
☒ None

+ 0.00000 - 0.00000

Text

Font: Arial

More Fonts

VPos: Centered HPos: Auto-Right

Height: 0.20000 # Dec.Pl: 3

Text Format, <> denotes value location:
<>

Scale value by: 1.00000

Baseline Spacing: 0.40000

Vector Text Thickness: 0.00000mm

Options

☐ Align text with arrows
☐ Show Center Mark
☐ Show Center Line

Ok Cancel Help

- Type** Select the arrowhead style from a drop-down list of available styles.
- Length** Length of arrowhead from endpoint to base (drawing units).
- Height** Base width of arrowhead (drawing units).
- Thickness** Pen Thickness of arrowheads.

Dimension Leaders

Dimension Style

Style Name: ☐ AutoUpdate

Arrowhead

Type:

Length:

Height:

Thickness:

Leaders

Offset Dim Point:

Extend past text:

Thickness:

Tolerance Display format

☐ Symmetrical ☐ Limits

☐ Deviation ☐ Basic

☒ None

+ -

Text

Font:

VPos: HPos:

Height: # Dec.Pl:

Text Format, <> denotes value location:

Scale value by:

Baseline Spacing:

Vector Text Thickness:

Options

☐ Align text with arrows

☐ Show Center Mark

☐ Show Center Line

- Offset Dim Point** Specifies the distance from the edge of a dimensioned entity to the start of the extension line.
- Extend past text** Specifies the distance of the extension line beyond the dimension line.
- Thickness** Pen Thickness of leader lines in millimeters.

Dimension Tolerance Display format

Dimension Style

Style Name: (Individual) ☐ AutoUpdate

Arrowhead

Type:

Length: 0.18000

Height: 0.08000

Thickness: 0.00000mm

Leaders

Offset Dim Point: 0.06250

Extend past text: 0.18000

Thickness: 0.00000mm

Tolerance Display format

☐ Symmetrical ☐ Limits

☐ Deviation ☐ Basic

☒ None

+ 0.00000 - 0.00000

Text

Font: Arial

VPos: Centered HPos: Auto-Right

Height: 0.20000 # Dec.Pl: 3

Text Format, <> denotes value location:

<>

Scale value by: 1.00000

Baseline Spacing: 0.40000

Vector Text Thickness: 0.00000mm

Options

☐ Align text with arrows

☐ Show Center Mark

☐ Show Center Line

Symmetrical Format

Tolerance Display format

☒ Symmetrical ☐ Limits


☐ Deviation ☐ Basic

☐ None

+ 0.50000 - 0.00000

Symmetrical Dimension Tolerance

This method adds a **plus/minus** value of tolerance displaying a \pm after the **dimension text**. Enter the tolerance value in the window to the right of the + **plus sign**.



NOTE: Values placed in the window to the right of the – **minus sign** will be ignored by **Symmetrical Tolerance**. The value in the window to the right of the + **plus sign** is the only one that will be displayed in the **Symmetrical Tolerance** method.

Limits Format

Tolerance Display format

☐ Symmetrical
 ☒ Limits
 ☐ Deviation
 ☐ Basic
 ☐ None

+ -

Limits Dimension Tolerance

This method displays a **Limit dimension** which displays a **maximum** and a **minimum** value.. The **maximum value** is the **dimension value plus the value entered in + window**. The **minimum value** is the **dimension value minus the value entered in + window**.

The actual **Dimension value** in the Dimension below is **7.5"** so the **upper limit** is **7.5" + 0.5" = 8"**. The **lower limit** is **-.02" or 7.5" -.02" = 7.3"**



Deviation Format


Tolerance Display format

☐ Symmetrical
 ☐ Limits
 ☒ Deviation
 ☐ Basic
 ☐ None

+ -

Deviation Dimension Tolerance

This method displays a **plus/minus tolerance value** suffix to the **dimension text**. The **plus value** and **minus values** of the **deviation** of the **dimension** are entered into the + and - windows in the dialog box



Basic Format

Tolerance Display format

☐ Symmetrical
 ☐ Limits
 ☐ Deviation
 ☒ Basic
 ☐ None

+ -

Basic Dimension Tolerance

This method draws a **box** around the **dimension** signifying that its value may vary or be changed later.



None

Tolerance Display format

☐ Symmetrical
 ☐ Limits
 ☐ Deviation
 ☐ Basic
 ☒ None

+ -

None Disables the display of Dimension Tolerance

Tolerance Value

Tolerance Display format

☐ Symmetrical
 ☐ Limits
 ☐ Deviation
 ☐ Basic
 ☒ None

+ -

+ Window contains Maximum value for Tolerance

-- Window contains Minimum value for Tolerance

Dimension Text

Font Select a **font** for **dimension text** and numbers from the drop-list of available **fonts**.

More Fonts Select to add fonts to the drop-down list. For more information on specific font types, see the **TEXT PROPERTIES** command.

VPos Select placement of dimension text relative to the dimension line, for horizontal dimensions. Available choices are **Above/Centered/Below**. Centered text will break the dimension line. During placement, Any of these settings can be manually overridden by holding down the **SHIFT** key.

HPos Select placement of dimension text relative to the dimension line, for horizontal dimensions. Available choices:

- **Auto-Left:** Dynamic cursor displays Dim Text in middle; but if text will not fit, the Dim Text position defaults to left. Can be overridden during placement

- **Auto-Right:** Dynamic cursor displays **Dim Text** in middle; but if text will not fit, the **Dim Text** position defaults to **RIGHT**. Can be overridden during placement.
- **Center/Left/Right:** **Dim Text** forced to **middle/left/right** position, respectively. Cannot be overridden during placement (unless manually repositioned by holding down **SHIFT** key).

Height Specify the **height** of **dimension text** in drawing units.

Dec. Pl. Specify the number of decimal places to be displayed for individual dimensions drawn in this style.

Dimension Text Fixed Values Format

Dimension Style

Style Name: (Individual) ☐ AutoUpdate

Arrowhead

Type:

Length: 0.18000

Height: 0.08000

Thickness: 0.00000mm

Leaders

Offset Dim Point: 0.06250

Extend past text: 0.18000

Thickness: 0.00000mm

Tolerance Display format

☐ Symmetrical ☐ Limits

☐ Deviation ☐ Basic

☒ None

+ 0.00000 - 0.00000

Text

Font: Arial

VPos: Centered HPos: Auto-Right

Height: 0.20000 # Dec.Pl: 3

Text Format, <> denotes value location:

<>

Scale value by: 1.00000

Baseline Spacing: 0.40000

Vector Text Thickness: 0.00000mm


Options

☐ Align text with arrows

☐ Show Center Mark

☐ Show Center Line

Text Format Use this field to specify fixed prefix or suffix text that is appended to the true dimension value. The "<>" is used as a placeholder for the true value. If the value placeholder is omitted, the value is not included in the dimension output.




Examples, where the actual dimension value is 18"

<u>Input in Text Format Window</u>	<u>Dimension Displayed on Drawing</u>
<>	18"
<> ROUGH BORE	18" ROUGH BORE
MULTIPLES OF <>	MULTIPLES OF 18"
MIN. <> CRAWL	MIN. 18" CRAWL
MIN. <24"> CRAWL	MIN. <24"> CRAWL
{empty} Delete Brackets	{no text} Dimension is Blank

Scale value by Typically used only to deal with the AutoCAD® DWG/DXF import/export issues. This value is used as a scale factor. The true **Dimension** is multiplied by the scale factor, and the scaled value is represented by the **Dimension Text**. Scale value = 1 represents actual dimension.

Baseline Spacing Specifies the *automatic spacing between BASELINE DIMENSIONS* (drawing units)



Vector Text Thickness Pen thickness of VECTOR text. Only applicable if EasyCAD DOS .FNT or AutoCAD® .SHX fonts are used (not TrueType®).

Dimension Options

Dimension Style

Style Name: (Individual) ☐ AutoUpdate

Arrowhead
Type:

Length: 0.18000
Height: 0.08000
Thickness: 0.00000mm

Leaders
Offset Dim Point: 0.06250
Extend past text: 0.18000
Thickness: 0.00000mm

Tolerance Display format
☐ Symmetrical ☐ Limits
☐ Deviation ☐ Basic
☒ None
 + 0.00000 - 0.00000

Text
Font: Arial
VPos: Centered HPos: Auto-Right
Height: 0.20000 # Dec.Pl: 3
Text Format, <> denotes value location: <>

Scale value by: 1.00000
Baseline Spacing: 0.40000
Vector Text Thickness: 0.00000mm

Options
☐ Align text with arrows
☐ Show Center Mark
☐ Show Center Line

Align text with arrows

Check to align text with the **Dimension Line**, regardless of orientation. If not checked, **Dimension Text** will always display horizontally.

Show Center Mark

Check to display center marks, which are small crosses **EasyCAD** creates at the center of dimensioned circles or arcs.

Show Center Line

Check to display center lines, which consist of alternating short and long dashes. **EasyCAD** automatically draws them as extension lines for dimensioned circles and arcs. Center marks are always created whenever center lines are drawn.

Edit Commands

Modify and manipulate the entities in your drawing

The **Edit menu** commands let you modify entities that you have already drawn. You can alter *geometry*, such as the endpoint of a line or the radius of a circle. You can change *entity properties*, such as color or layer. With the advanced editing commands **EasyCAD** provides, you can manipulate entities in almost any way you desire.

- **ERASE** command let you delete entities from your drawing.
- **EDIT** commands let you modify the geometry of entities you have drawn, either parametrically or with dynamic cursors that preview the changes.
- **CHANGE** commands let you edit the properties of entities you have drawn, such as color, layer, fill style, etc.
- **MOVE** command let you displace entities you have drawn, while *scale* and *rotate* commands let you transform entities.
- **TRIM** commands let you shorten or extend entities.
- **BREAK** command let you separate one entity into two (or more).
- **FRONT-BACK-ABOVE-BELOW** commands let you arrange entity order, so that they redraw in the sequence you desire.
- **EXPLODE** command reduce complex entities into their simpler components.

You can **UNDO** all **Edit** commands. Left-click or right-click after any editing command to auto-repeat it.

Some Edit commands work on one entity at a time, while others allow you to select multiple entities before performing the command. **Chapter 2: Communicating with EasyCAD v7**, deals in depth with entity selection. Choosing entities is an integral step in almost every editing command. **EasyCAD** provides several options to optimize entity selection to the way you think and work. Review the methods and choose the one that works best for you.

Commands that *duplicate* entities are a wide and special subset of editing commands. As such, they are grouped under their own **Copy menu** heading (*see Chapter 11: Copy Commands for more information*)

Erase



Erase icon

The **ERASE** command removes the selected entities from your drawing.

You can **NOT ERASE** entities on *hidden/frozen layers, hidden sheets, reference files, or XREFs*. Entities within a **PART** cannot be erased until it is *ungrouped* or *unlocked*. Entities *within a symbol reference cannot be erased* unless the *symbol referenced* is **EXPLODED**.

Use the **UNDO** command to recover any unintended erasures. You can **UNDO** an **ERASE** as long as it was *one of the last ten commands run*.

NOTE: EasyCAD erases entities from your screen by drawing over them in the *background color*. This may leave apparent holes in other entities, especially if the erased entities were filled or crosshatched. Select [**View > Redraw**] command to clean up the screen.

Text equivalent: **ERASE**

Edit

Edit? Or Dynamic Edit?

EasyCAD provides EDIT and DYNAMIC EDIT commands. At first glance, these might seem quite similar. Fundamentally, they are, since they both allow you to modify existing entities.

So when to use either command?

In general, use EDIT when you need to alter the geometry of an entity to known specifications. You aren't provided with visual aids, so you must type in new coordinates, radii, etc.

DYNAMIC EDIT is more flexible, because you can visually modify the entities. Modifiers or attach mode can also be used to connect or reference other entities.

For text, use EDIT to change the actual text or its properties (such as font, justification, etc.) Use DYNAMIC EDIT to visually reposition, resize, or rotate the text.

The **EDIT** command is a general-purpose command that lets you modify most entities one at a time, using dialog boxes for changing parametric values. When you invoke **EDIT**, the prompt reads '**Entity to edit:**', and a pick box cursor appears on the drawing screen. Select a *single entity* (remember to select text entities on their base line). **EDIT** works differently depending on the type of entity you select.

EDIT is used to *single edit* the *geometry* of entities. If you wish to similarly *edit* an entity's *properties* (color, layer, line style, etc.), use the **PEDIT** command [**Edit > Properties**] instead.

NOTE: The values in dialog boxes can be modified with algebraic expressions. For example, select a circle. After pointing to the end of the **Radius** value in the *Edit Circle dialog*, enter "***2**". The *radius* will double *in length*. Click **OK** to accept the value and display the *larger circle*.

Selectable entities:

LINES

- Edit endpoint coordinates
- Toggle arrowheads at either endpoint
- Change the line style

CIRCLES

- Edit center point coordinates
- Edit radius value

ARCS

- Edit center point coordinates
- Edit radius value
- Edit start angle
- Edit angle width
- Flip start angle & angle width
- Toggle arrowheads at either endpoint

ELLIPSES

- Edit center point coordinates
- Edit major radius value
- Edit minor radius value
- Edit inclination value

ELLIPTICAL ARCS

- Edit minor radius value
- Edit inclination value
- Edit start angle
- Edit angle width
- Flip start angle & angle width
- Toggle arrowheads at either endpoint

TEXT

- Edit text
- Change text properties
- Convert to file text

PATHS/POLYS/SPLINES

- Edit node coordinates
- Toggle smoothing
- Toggle closed (poly) or open (path)
- Toggle arrowheads at either endpoint (open only)
- Edit trim parameters (open only)
- Change line style

POINT

- Edit node coordinates

DIMENSIONS

- Change any dimension style setting

PICTURE

- Change source bitmap image file
- Change picture options

XREF

- Change path\filename of XREF

Wall network entities cannot be edited with **EDIT**. Instead, use the individual wall commands.

Other non-selectable entities include symbol references, grouped entities, and multipoly entities.

Symbol definitions can be edited using the **EDIT SYMDEF** command [**Insert > Edit Symbol Def...**].

Text equivalent: **EDIT**


Dynamic Edit

The **DYNEDIT** [**Edit > Dynamic Edit**] command is a general-purpose command that lets you modify most entities one at a time, using visual screen methods to modify them.

Because most dynamic edit instances utilize dynamic cursors, the [**SHIFT=move CTRL=scale SHIFT+CTRL=rotate**] prompt allows the use of these keys to expand your editing capabilities.

If you need to edit an entity's geometry with precision, consider using the **EDIT** command [**Edit > Edit**]. To edit entity properties, use the **PEDIT** command [**Edit > Properties**].

Dynamic edit does not work with *elliptical arcs* or **WALL** entities (there are special commands to edit walls).




LINES

Repositions the end.

prompt reads “Next point [done]”

Use **SHIFT** to re-position the anchor point.




CIRCLES

Changes the radius.

prompt reads “[**SHIFT=move**]”

Use **SHIFT** to re-position the center point.




ARCS

Changes the endpoint (arc end angle).


prompt reads “[**SHIFT=move CTRL=scale**]”

Use **SHIFT** to re-position the center point.

Use **CTRL** to change the radius.

**ELLIPSES & ELLIPTICAL ARCS**

Repositions the center point.


**PATHS & POLYS**

Repositions any node.

prompt reads “[INS DEL <--> New position [done]”

Use INSERT or DELETE to add or remove nodes.

Use LEFT ARROW or RIGHT ARROW to cycle through nodes. Right-click to terminate editing mode.


**SPLINES & SPOLYS**

Repositions any control point.

Use INSERT or DELETE to add or remove points (Bezier splines must have exactly four points).

Use LEFT ARROW or RIGHT ARROW to cycle through points.

Right-click to terminate editing mode.


**TEXT**

Repositions resizes and rotates.

prompt reads “[CTRL=scale CTRL+SHIFT=rotate]”

Use CTRL to resize.

Use SHIFT+CTRL to rotate.




LINEAR DIMENSIONS

(Linear/Horizontal/Vertical/Parallel)

Repositions dimension Text.

prompt reads “[Text baseline point (SHIFT=Spec Text Center)]”

Use **SHIFT** to manually re-position text.



ORDINATE DIMENSIONS

(Linear/Horizontal/Vertical/Parallel)

Inserts or Delete a dimension leader.


prompt reads “Insert leader at [DEL to delete]”

Use **DEL** and pick a leader to remove. Right-click to end the Dynamic Edit command.

Text equivalent: **DYNEDIT**

Change

When you select **CHANGE**, the *Change dialog box* appears in the center of the screen, allowing you to select the *properties* of entities to *modify*. This is the old **DOS** style for selecting properties to *change*. All entities have a common set of *properties* like *color*, *layer*, *line style*, *pen thickness* etc. that can be *edited* on an individual basis:



Selecting any option invokes the specific **CHANGE** command for that property. For instance, if you click the **Color** button, **EasyCAD** starts the **CHANGE**EC command.

Use the **PEDIT** command to change multiple properties of a single entity.

Text equivalent: **CHANGE**

Change > Properties

CHANGE > PROPERTIES lets you change multiple properties for any number of selected entities, using an interactive dialog box. Modified properties are applied to all selected entities. This command works like **PEDIT**, except that you can select more than one entity.

The properties you can edit are like those you can edit using the various **CHANGE** commands:

- **Layer**
- **Line Style**
- **Fill Style**
- **Line Width (geometric width)**
- **Pen Thickness (paper scale thickness)**
- **Color (entity's outline color)**
- **Fill [2nd] Color**
- **Text Properties (when applicable)**
- **Text (what the Text reads)**
- **Dimension Style (when applicable)**
- **Color of SymRef (applies to Symbols only)**
- **Arrowheads**


To *change* the *properties* of entities, select [Edit > Change > Properties]:

1. Select entities to *edit*. *Groups* and *multipolys* select as such, and any changes affect the *entire group* or *multipoly*. *Symbol references* can be selected, but property changes affect the selected *Reference(s) only, never* the *Symbol Definition(s)*.
2. **EasyCAD** displays the appropriate *Entity Properties dialog box*. Modify the desired properties and click **OK**.

EasyCAD applies the modified properties to all of the selected entities.

Entity Properties dialog

EasyCAD displays the *Entity Properties dialog box* when you invoke the **PCHANGE** command or **PEDIT** command [**Edit > Properties**]. Note that changes made in this dialog do not affect the current drawing properties in any way—just those of the selected entity. For example, if you change an entity's color, the current drawing color does not change.



Sample Displays an extents sample of the selected entity. As you make changes to its properties, the entity updates accordingly.

Layer Changes the entity layer. Initially, the current entity layer is displayed. To change layer, click to open a list of usable layers, and select a layer name.

Line Style Changes the entity line style. Initially, the current entity line style is displayed. To change line style, click to open a list of usable line styles, and select a line style name.

Fill Style Changes the entity fill style. Initially, the current entity fill style is displayed. To change fill style, click to open a list of usable fill styles, and select a fill style name.

Line Width Changes the entity line width. Initially, the current entity line width is displayed. To change line width, type in a new value (in drawing units).

Pen Thickness Changes the entity pen thickness. Initially, the current entity pen thickness is displayed. To change pen thickness, type in a new value. The value is in drawing units, but this can be overridden by specifying a mm (millimeter) or " (inch) suffix.

Outline Color # Changes the entity color. Initially, the current entity color is displayed. To *change color*, type in a *new color ID#*, or click the color button to display the 256-color palette. When the color is changed, **Fill Color #** also changes to the same color.

Fill Color # Changes the fill style color, when applicable. This changes the text color in dimensions. Initially, the current entity fill color is displayed. To change fill color, type in a new color ID#, or click the color button to display the 256-color palette.

Text Properties Opens the *Text Properties dialog box*. To modify specific text properties, make desired changes in the dialog, then click **OK**.

Dimension Properties Opens the *Dimension Styles dialog box*. To modify specific dimension properties, make desired changes in the dialog, then click **OK**.




Color bar

In this figure, yellow (color #4) is the active color, as indicated by the heavy black border.

Change > Color

CHANGE > COLOR redraws selected entities in a different color.



To *change entity colors*, select [Edit > Change > Color]:

1. Select entities to modify.
2. The prompt reads "**Color value [dialog]:**". To select a new color:
 - Pick a color icon from the *Color bar*;
 - Right-click to display the 256-color palette, pick a new color, and click **OK**;
 - Type a color number and press **ENTER**.

EasyCAD redraws the entity in the selected color.

NOTE: If an entity uses a *secondary fill color*, use the [Edit > Change > Fill (2nd) color] command to change it. [Edit > Change Color] only changes an entity's *primary outline color*.

Text equivalent: **CHANGE C**

Change > to Color of SymRef

CHANGE > TO COLOR OF SYMREF sets selected entities to "**color by block**." This command is only relevant for entities that will be included in a symbol definition.

When an entity in a *symbol* has **By Block color**, it will behave similarly as if it were drawn in color #31. Entities in a *symbol definition* that have the by block setting will draw in the current color when inserted. It is recommended that this method be used rather than using the #31 "**no change**" color.

To quickly change **ALL** of a drawing's symbol definitions to By Block color, you can use the **CHANGESCB** [Insert > Change All Sym Defs > Change All Color by Block] command or type "**CHANGESCB**" at the command line.

Text equivalent: **CHGCBB**

Change > Fill (2nd) color

CHANGE > FILL (2ND) COLOR lets you *assign a secondary interior color* to an entity.

When set, the *secondary color* is used for:

- **Fill pattern color** on valid entities. Valid entities include *polygons*, *multipolys*, *circles*, *ellipses*, *walls*, entities drawn with **LINE WIDTH 0.0**, etc.
- Text on dimension entities

When entities are created, the *secondary color is always the same as the primary color*. Using the [Edit > Change > Fill (2nd) color] command is the only way to change the *secondary color*.

To *change* an entities *secondary colors*, select [Edit > Change > Fill (2nd) color]:

1. Select entities to modify.
2. The prompt reads "**Color value [dialog]:**". To select a new color:
 - Pick a different color from the *Color bar*;
 - Right-click to display the **256-color palette** dialog, from which you can pick a new color and click **OK**;
 - Type a color number and press ENTER.

EasyCAD redraws the entity with the selected *secondary color* (if a valid use exists).

Note that this command *will not change an entity's primary color*. Also entities cannot be selected by their *secondary color*.

Text equivalent: **CHANGE C2**

Change > Pen Thickness

CHANGE > PEN THICKNESS lets you change the pen width of an existing entity.

To *change* entity *pen thickness*, select [**Edit > Change > Pen Thickness**]:

1. Select entities to modify.
2. The prompt reads “**Pen thickness:**”. Type in a value. Note that the value is specified in current drawing units, so explicit entry, such as **1.5mm** or **.05**, is recommended.

EasyCAD redraws the entity using the *new pen thickness*.

Use the **PTHICK** command [**Specs > Pen Thickness**] to set the *current pen thickness*. You can also access the *Pen Thickness dialog* by clicking directly on the *Pen Thickness indicator* on the *Status bar* or click the drop arrow at its right to select a previously used *pen thickness* from its drop-down menu.

Text equivalent: **CHANGEPT**

Change > Layer

CHANGE > LAYER moves entities to a *different layer*. The target layer must already exist.

To *change* entity *layer*, select [**Edit > Change > Layer**]:

1. Select entities to modify.
2. The prompt reads “**Layer name or # [dialog]:**”. To select a new layer:
 - Type an existing layer name and press ENTER.
 - Type a layer ID# and press ENTER.
 - Right-click to display the *Select Layer dialog*, and pick the layer name.

EasyCAD moves the entity to the target layer, and the command terminates.

IMPORTANT: Use of this command does not change the *current layer*. Note that the ‘L:’ setting on the *Status bar* does not change.

To *change the active layer*, use the [**Specs > Layer Options > Set Current**] command or click inside of the *Layer Status window* and click the leftmost checkbox of the **LAYER NAME** you want to be the new current **LAYER**.

Text equivalent: **CHANGEL**

Change > Line Style

CHANGE > LINE STYLE redraws entities in a different, pre-defined line style.

To *change* the *line style* of an entity, select [**Edit > Change > Line Style**]:

1. Select entities to modify.
2. The prompt reads "**Line style name or # [dialog]:**". To select a *new line style*:
 - Type an existing line style name and press **ENTER**.
 - Type a **Line Style ID#** and press **ENTER**.
 - Right-click to display the *Line Style dialog*, and pick a line style name.

EasyCAD redraws the entity in the target *line style*, and the command terminates.

IMPORTANT: Use of this command does not change the *current line style*. Note that the 'LS:' setting on the *Status bar* does not change.

To *change* the *active line style*, use the [**Specs > Line Style**] command or click directly inside of the *Line Style Status window* to open its dialog box and click on the desired *Line Style* and click **OK**.

Text equivalent: **CHANGELS**

Change > Fill Style

CHANGE > FILL STYLE redraws applicable selected entities with a different, pre-defined *fill style*.

To change the *fill style* of an entity, select [**Edit > Change > Fill Style**]:

1. Select entities to modify. The selected entities must be of a type valid for fills (**polygons**, **SPolys**, **circles**, **ellipses**, **mulipolys**).
2. The prompt reads "**Fill style name or # [dialog]:**". To select a new fill style:
 - Type an existing *fill style* name and press **ENTER**.
 - Type a **Fill Style ID#** and press **ENTER**.
 - Right-click to display the *Fill Style dialog*, and pick a *style name*.

EasyCAD redraws the entity with the target *fill style*, and the command terminates.

IMPORTANT: Use of this command *does not change the current fill style*. Note that the 'FS:' setting on the *Status bar* does not change.

To change the *active fill style*, use the [**Specs > Fill Style**] command or click directly inside of the *Fill Style Status window* to open its dialog box and click on the desired *Fill Style* and click **OK**...

Text equivalent: **CHANGFS**

Change > Line Width

CHANGE > LINE WIDTH redraws selected entities with user-modified line widths. Each entity possesses a *Line Width* property that is set at the time the entity is created.

1. Select entities to modify.
2. The prompt “**New width:**”, where *x.x* is the last value used for this command. Type in the desired line width and press **ENTER**, or right-click to accept the prior value.

EasyCAD redraws the entity with the *new line width*, and the command terminates.

Text equivalent: **CHANGELW**

Change > Dimension Style

CHANGE > DIMENSION STYLE redraws selected *dimensions* with user-modified properties. Dimension properties include *arrowhead*, *leaders*, *tolerances*, *center lines*, *text metrics*, and *text positioning*. You can either apply a *defined dimension style* to the entire dimension(s), or just change individual properties.

This command operates similarly to **CHANGE > TEXT PROPERTIES**. If you choose to apply a *named dimension style*, observe the settings at the bottom of the *Dimension Style dialog*. If “**Change only touched items**” is checked, then you must “**touch**” each edit control with a mouse click in order for that property change to take effect. **Non-touched properties are not changed**. However, if you check “**Change everything**”, then *all dimension properties change to the displayed settings*. Please see the **DIMENSION STYLES** command for more information on *named dimension styles*.

To change any properties of an *dimension*, select [**Edit > Change > Dimension Style**]:

1. Select dimension entities to modify.
2. **EasyCAD** automatically displays the *Dimension Styles dialog box*. The current dimension specifications are displayed. Clicking on and/or changing any value will result in the selected entities acquiring the new property values. Unless the “**Change everything**” option (**located at the bottom of the dialog**) is checked, then only options that are “**touched**” will affect the selected dimension(s).

This action does not change the current dimension specifications, only those of the selected dimension entities.

3. Click **OK** to accept the changes and close the dialog box. The dimension(s) will redraw with the updated properties.

Text equivalent: **CHANGED**

Change > Text

CHANGE > TEXT changes *selected text entities* to the *entered text*. Use this command to change multiple, existing text entities to the *same text*. Each changed entity keeps its own location and properties.

1. **EasyCAD** displays the *Text dialog box*. Type in the new text. For longer text, you may check the **Multi-line** option. Click the **OK** button when done.
2. Select text entities to modify. When you select **OK-Do it**, **FastCAD** changes all selected text to the new value.

To *change* a *single text entity* to a new value, use the **EDIT** command [**Edit > Edit**].

To change any text metrics or properties of an existing text entity, use the **CHANGE > TEXT PROPERTIES** command [**Edit > Change > Text Properties**].


Text equivalent: **CHANGETX** or **CHANGEX**

Change > Text Properties

CHANGE > TEXT PROPERTIES redraws selected text with user-modified properties. Text properties include *Font*, *Metrics*, and *Character style*.

This command operates similarly to **CHANGE > DIMENSION PROPERTIES**. If you choose to apply a *named text style*, observe the settings at the bottom of the *Text Properties dialog*.

If ‘**Change only touched items**’ is checked, then you must “touch” each edit control with a mouse click in order for that property change to take effect. Non-touched properties are not changed. However, if you check ‘**Change everything**’, then all dimension properties change to the displayed settings. Please see the **TEXT PROPERTIES** command for more information on *named text styles*.



Text Properties dialog

To change any *text properties* of an existing text entity, select [**Edit > Change > Text Properties**]:


1. Select text entities to modify.
2. **EasyCAD** automatically displays the *Text Properties dialog box*. The current text specifications are displayed. Clicking on and/or changing any value will result in the selected entities acquiring the new property values. Unless the “**Change everything**” option (located at the bottom of the dialog) is checked, then only options that are “touched” will affect the selected text.

This action does not change the current text specifications, only those of the existing selected entities.

3. Click **OK** to accept the changes and close the dialog box. The selected text will redraw with the modified properties.

Text equivalent: **CHANGET**

Change > Arrowhead



CHANGE > ARROWHEAD toggles on or off the *current Arrow style* on the nearest end of a selected *line*, *arc*, *path* or *spline*. To add an arrow to one of these entities, invoke the command and pick an entity near an endpoint. **EasyCAD** adds an arrowhead to the nearest endpoint.

To reverse the operation, apply the arrowhead command again to the entity, or select the **UNDO** command [**Clip > Undo**].

To set the *arrow style* for entities that don't yet have an arrowhead, use the **ASTYLE** command [**Specs > Arrowhead Style**].


To *change* the *arrow style* on an entity that already has an arrowhead, use the [**Edit > Change > Arrow Style**] command and select a *new style*.

Text equivalent: **AHEAD**

Change > Arrow Style

Use **CHANGE > ARROW STYLE** to change the existing *arrow style* on an entity. This command only affects **line**, **path**, **arc**, or **spline** entities that *already have arrowheads*.

Arrowheads are *added* or *removed* using the **[Edit > Change > Arrowhead]** command. If you apply **[Edit > Change Arrowhead Style]** to an entity *without arrowheads*, the edit *will have no net effect*.



Style Select the *arrowhead style* from the drop list. The *arrowhead style* you select will be applied to currently selected entity.

Length Sets the *length of the arrowhead* in drawing units. If you edit this value, the height will automatically update to maintain the arrow's aspect ratio.

Height Sets the *height of the arrowhead* in drawing units, measured as the total height of both arrowheads. When the *Length value is changed, Height updates by the same factor to maintain the arrow's aspect ratio*. You can override this suggested value by entering a *different height*.

Text equivalent: **CHANGEAS**

Change > Radius

Use **CHANGE > RADIUS** commands allows you to select one or more **CIRCLES** and **ARCS** change the **RADIUS** of all of them at one time to a new **RADIUS** you specify and the **CIRCLES** and **ARCS** **original CENTER XY locations** will be retained.

To change **RADIUS** of existing **CIRCLES** and **ARCS** select the **[Edit > Change > Radius]:command**.

1. The prompt reads: “**New radius:**”.
Type a value like **3**” and press **ENTER**..
2. The prompt reads: “**Select entities**”.
Select the **CIRCLES** and **ARCS** that you want to have the new **RADIUS** value and press **ENTER**.

EasyCAD v7 changes the selected entities to the new **RADIUS** and the **original CENTER XY locations** of the **CIRCLES** and **ARCS** remain the same.

*Text equivalent: **CHGRAD***

Change > Diameter

The **CHANGE > DIAMETER** command allows you to select one or more **CIRCLES** and **ARCS** change the **DIAMETER** of all of them at one time to a new **DIAMETER** you specify and the **CIRCLES** and **ARCS** **original CENTER XY locations** will be retained.

To change **DIAMETER** of existing **CIRCLES** and **ARCS** select the **[Edit > Change > Diameter]:command**.

1. The prompt reads: “**New diameter:**”.
Type a value like **3**” and press **ENTER**..
2. The prompt reads: “**Select entities**”.
Select the **CIRCLES** and **ARCS** that you want to have the new **DIAMETER** value and press **ENTER**.

EasyCAD v7 changes the selected entities to the new **DIAMETER** and the **original CENTER XY locations** of the **CIRCLES** and **ARCS** remain the same.

*Text equivalent: **CHGDIA***

Properties


PROPERTIES allows you to *edit ALL* of the *standard properties of a single selected entity* through an interactive dialog box. When you wish to apply property changes to a *single entity*, the [**Edit > Properties**] command can often be much quicker than using a series of **CHANGE** commands.

The properties you can edit are like those you can edit using the various **CHANGE** commands:

- **Layer**
- **Line Style**
- **Fill Style**
- **Line Width**
- **Pen Thickness**
- **Outline Color**
- **Fill Color**
- **Text Style (when applicable)**
- **Dimension Style (when applicable)**

To *change the properties of an entity*, select [**Edit > Properties**]:


1. **EasyCAD** displays a pick cursor. Select *any single entity*. You cannot pick multiple entities with this command. A single entity can be discretely selected even if it is grouped. *Multipolys select as a single entity* (any changes affect the **entire multipoly**). *Symbol references* can be selected, but all property changes are made to the *selected reference(s) only, not to the symbol definition*.
2. **EasyCAD** displays the *Entity Properties dialog box* (see **PCHANGE** command). Modify the desired properties and click **OK**.



Entity Properties dialog box

Text equivalent: **PEDIT**

Drag



DRAG moves selected entities *dynamically* - you see the entities moving on-screen. The **DRAG** command utilizes a displacement (distance and direction) that you specify with two points.

To *drag* entities, select [**Edit > Drag**]:

1. Select entities to drag.
2. The prompt reads "**Origin:**". To specify a base point for the move, pick the point or type numeric coordinates.

EasyCAD displays the selected entities as an outline cursor that moves with your mouse.

3. The prompt reads '**CTRL=scale SHIFT+CTRL=rotate**'. As you move the mouse, the entities move to follow. If *snap locking is turned on*, the entities jump over positions between *snap points*. Pick a point when the entities are where you want them positioned.


EasyCAD moves the selected entities to their new position.

This command uses dynamic cursors. Because of this capability, the functionality of the **DRAG** command can go far beyond simply repositioning entities and makes it much more powerful than the **MOVE** command. Holding down keys while moving the mouse provides the following action:

- **CTRL** *dynamically scales* objects, making them larger or smaller depending upon direction of the mouse movement.
- **CTRL+SHIFT** *dynamically rotates* objects about the "**Origin:**" point. Potentially, you may find this more useful than using the **ROTATE** command [**Edit > Rotate**].

Text equivalent: **DRAG**

Move



MOVE *moves* the selected entities in relation to the rest of the drawing, using a displacement (distance and direction) that you specify with two points.

To *move* entities, select [**Edit > Move**]:


1. Select entities to move.
2. The prompt reads "**Move from point:**". Select a base point for the move with the crosshairs or type a numeric coordinate. Use *modifiers* such *endpoint of segment* [F5] for precision.
3. The prompt reads "**Move to point:**". Select a second point with the cursor or by typing in numeric coordinates. Use *modifiers* such as *endpoint of segment* [F5] for precision.

EasyCAD calculates the distance and direction between the points, and *moves* the selected entities accordingly.

You can force the selected entities to move *only horizontally* or *only vertically* by turning on *orthogonal locking* by clicking the **ORTHO** button.

Text equivalent: **MOVE**

DynStretch



DYNSTRETCH reshapes most entities by moving some of their end or node points in relation to the others. **DYNSTRETCH** differs from the regular **STRETCH** command by its use of dynamic cursors. **DYNSTRETCH** displays a ghost image of the entities as they are stretched to help you visually distort the selected entities.

When stretching dimensioned entities, you should select the actual **DIMENSION(s)** as well. A stretched **DIMENSION** *will automatically update its new value*. You can verify this by watching the dynamic cursors during a **DYNSTRETCH** operation involving **DIMENSIONS**.

To **Dynamically Stretch** entities with dynamic cursors, select [Edit > DynStretch]:

1. Select the entities to *stretch*.
2. The prompt reads '**First corner:**'.

EasyCAD is asking you to *draw a selection window around the end points or nodes you want to move* [STRETCH].

This selection window you draw must include the actual entity points. In Step 1, you select the entities you want to **STRETCH** then you select with a *window* which points on those entities that will be modified. Points not selected in this step remain fixed.

If you enclose entities in this step that were not selected in Step 1, they are ignored and not modified in any way.

3. The prompt reads: '**Opposite corner:**'.


Finish drawing the *selection window around the stretch points*.

4. The prompt reads: '**Origin:**'.

To select a *base point for the move*, pick a point using a modifier for precision or type numeric coordinates.

EasyCAD displays dynamic cursors that preview the **STRETCH** based on cursor movement.

5. The prompt reads: '**SHIFT=move CTRL=scale CTRL+SHIFT=rotate:**'.



Use the dynamic cursors to pick a point in the drawing window.

This point indicates the distance and direction you want the selected points to move (in relation to the origin specified in **Step 4**). If you use modifiers in this step, the dynamic cursors are suspended.

EasyCAD moves the endpoints that were inside the stretch window, leaving other endpoints where they were.

Stretch Tips:


- You can force the selected points to **move only horizontally** or **only vertically** by turning on **orthogonal locking**
- If you enclose the **center** of a **circle**, **ellipse** or **arc** in the selection window these entities are moved *by the distance of the STRETCH*.

This command uses **dynamic cursors**. In *Dynamic Track mode*, holding down keys while moving the mouse provides the following action:

- **CTRL dynamically scales** objects, making them larger or smaller depending upon direction of the mouse movement. In **STRETCH**, the scale origin stays fixed relative to the selected entities, not it's absolute coordinates when specified.
- **CTRL+SHIFT dynamically rotates** objects about the 'Origin:' point. In **STRETCH**, the rotate origin stays fixed relative to the selected entities, not it's absolute coordinates when specified.

Text equivalent: **DSTRETCH**

Stretch



STRETCH *reshapes* most entities by moving some of their end or node points in relation to the others.

To *stretch* entities, select [**Edit > Stretch**]:

1. Select the entities to stretch.
2. The prompt reads "**First corner:**". **EasyCAD** is asking you to draw a selection window around the end points or nodes you want to move. *This selection window you draw must include the actual entity points*. In Step 1, you *select the entities you want to stretch*, then you *select which points on those entities will be modified*. Points not selected in this step remain fixed.

If you enclose entities in this step that were not selected in Step 1, they are ignored and not modified in any way.

3. The prompt reads "**Opposite corner:**". Finish drawing the selection window for stretch points.
4. The prompt reads "**Origin:**". To select a base point for the move, pick a point or type numeric coordinates. Use *modifiers* such as *endpoint* for precision.


EasyCAD displays dynamic cursors that preview the stretch based on cursor movement.

5. Pick a point to indicate the *distance* and *direction* you want the points in the window to move. Use *modifiers* such as *endpoint* for precision.

EasyCAD *moves the endpoints that were inside the stretch window*, leaving other endpoints where they were unless the entities were selected in step one. If so they will be *moved* by the amount of the *stretch distance*.

Text equivalent: **STRETCH**

Scale > Scale Value



SCALE > SCALE VALUE *shrinks* or *enlarges* the selected entities based on a *scale value* you enter.


To *scale* entities, select [**Edit > Scale > Scale value**]:

1. Select entities to *scale*.
2. The prompt reads "Scale by factor [n]:". If you wish to accept the default, right-click or press **ENTER**. To enter a new scaling factor, type a scaling value and press **ENTER**. *Scaling factors > 1 will make entities larger. Scaling factors < 1 will make entities smaller.* For example, to make the selected entities twice as large as they are now, type "2" and press **ENTER**. To make them half as large, type "0.5" and press **ENTER**.
3. The prompt reads "Origin point [x,y,z]:". **FastCAD** scales the entities about this *scale center*. Use *modifiers* such as *endpoint* for precision. To specify define the origin:
 - Right-click or press **ENTER** to accept the default or prior center.
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.

EasyCAD redraws the entities at the *new scale*. The scale center remains fixed.

Text equivalent: **SCALE**

Scale > Dyn Scale



SCALE > DYNAMIC SCALE visually *shrinks* or *enlarges* selected entities, using a *dynamic cursor*.


To *dynamically scale* entities, select [**Edit > Scale > Dyn Scale**]:

1. Select entities to *scale*.
2. The prompt reads "**Origin:**". The drag from point is the point around which **EasyCAD** should scale the entities (the "**scale center**"). To define the scale center:
 - Pick a point in a drawing window, or;
 - Type numeric coordinates and press **ENTER**.
3. The prompt reads "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**". Move the mouse on the screen to visually resize the selected entities. They will shrink or grow depending on the direction of mouse movement. When you are satisfied with the size of the entities, left-click to create the scaled entities.

The "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**" prompt tells you that dynamic cursors are in effect. While scaling the selected entities, you can also move the scale center or rotate the entities. To *move the scale center*, hold down the **SHIFT** key while moving the mouse. To *rotate* about the *scale center*, hold down the **SHIFT+CTRL** keys while moving the mouse.

Text equivalent: **DYNSCL**

Scale > ScaleXY



SCALE > SCALE XY reshapes selected entities, scaling them by different amounts **horizontally (x)** and **vertically (y)**.


To *scale XY* entities, select [**Edit > Scale > ScaleXY**]:

1. Select entities to *scale*.
2. The prompt reads "**Scale X by factor [n]:**". If you wish to accept the default, right-click or press **ENTER**. To enter a new scaling factor, type a value and press **ENTER**. *Scaling factors > 1 will make entities larger. Scaling factors < 1 will make entities smaller.* For example, to make the selected entities twice as large in the **X** direction as they are now, type "**2**" and press **ENTER**. To make them half as large in the **X** direction, type "**.5**" and press **ENTER**.
3. The prompt reads "**Scale Y by factor [n]:**". Select or enter a value as you did for **Scale X**.
4. The prompt reads "**Origin point [x,y]:**". The *scale center* is the point around which **EasyCAD** should scale the entities. To define the *scale center*:
 - Right-click or press **ENTER** to accept the default or *prior center*;
 - Pick a point in a drawing window, or;
 - Type numeric coordinates and press **ENTER**.

EasyCAD redraws the entities at the new **X, Y** scales. The *scale center* remains fixed.

Text equivalent: **SCALEXY**

Rotate > Rotate ang




ROTATE > ROTATE ANGLE turns entities around a *specified center* and *angle*. To rotate entities, select [**Edit > Rotate > Rotate ang**]:

1. Select entities to *rotate*.
2. The prompt reads "**Rotate by Angle [n]:**", with the last angle you used suggested as a default or prior value. You can:
 - Right-click or press **ENTER** to accept the default or *prior rotation*.
 - Type a positive or negative angle, which can include values like **90.0005°** or **22+1/2°**. (**Remember that positive angles turn counterclockwise.**) For example, to turn the entities **45° counterclockwise**, type "**45**" and press **ENTER**.
3. The prompt reads "**Origin point [x,y,z]:**". For **2D** work, this point is the *center* about which **EasyCAD** rotates the entities. To specify the *rotation center*:
 - Right-click or press **ENTER** to accept the default or *prior center*.
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.
4. The prompt reads "**Rotate Axis Point [XY plane]:**". For **3D** rotation, **EasyCAD** rotates the selected entities around any axis in three-dimensional space. This axis is defined by the *Origin point* specified in the previous step, and a point specified in this step. *Positive angles rotate counterclockwise as you look along the axis from the center to the axis endpoint*. To specify the *axis point*:
 - Right-click or press **ENTER** to accept the **XY** plane.
 - Pick a point on the axis. You'll get best results if you place the axis point farther away from you than the center of rotation.

EasyCAD rotates the entities around the *axis*, which remains fixed.

Text equivalent: **ROTATE**

Rotate > Dyn Rotate



ROTATE > DYNAMIC ROTATE turns selected entities around a specified center. It works like the **ROTATE** command, except that it lets you visually see and specify the *rotation angle* using dynamic cursors.


To *dynamically rotate* copies of entities, select [**Edit > Rotate > Dyn Rotate**]:

1. Select entities to *rotate*.
2. The prompt reads "**Origin:**". The *origin point* is the point around which **EasyCAD** should turn the entities. To define this *origin*:
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.
3. The prompt reads '**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**'. Move the mouse on the screen to visually rotate the selected entities. They will rotate to the bearing defined by the cursor position to the rotation center. When you are satisfied with the rotation of the entities, left-click to draw the rotated entities.

The '**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**' prompt tells you that dynamic cursors are in effect. While rotating the entities, you can also move the rotation point or scale the selected entities. To *move the rotation point*, hold down the **SHIFT** key while moving the mouse. To *scale about the rotation center*, hold down the **CTRL** key while moving the mouse.

Text equivalent: **DYNROT**

Rotate XY Align



Use the **ROTATE XY ALIGN** command to align selected entities to an existing reference entity by rotation. The *rotation angle* is derived from selected points.

To *rotate align* entities, select [**Edit > Rotate > Rotate XY Align**]:


1. Select entities to *rotate*.
2. The prompt reads "**Origin point [x,y,z]:**", where **x,y** is the *last center point* selected. You can pick a *center point*, type in numeric coordinates, or right-click to accept the default value.
3. The prompt reads "**1st bearing point:**". The rubber band cursor stretches from the center point. Pick a point to establish the *bearing* of the entities to be rotated.
4. The prompt reads "**2nd bearing point:**". The rubber band cursor again stretches from the center point. Pick a point to establish the new bearing for the selected entities. Selecting another point on the reference entity works best, provided that it emanates from the rotate center point.

EasyCAD *rotates* the entities to the same bearing as the reference entity.

This command works best when lines on both the target and reference entities share the rotation center point. This allows you to easily establish bearing angles. **ROTALN** works by determining the difference between the two bearing angles, and then rotating the entities to that difference.

Text equivalent: **ROTALN**

Connect



CONNECT moves, scales, and rotates an entity or entities, connecting it to other entities. You supply **EasyCAD** with four points, two on the entity to be moved (source entity) and two on the target entity.


To *connect* entities, select [**Edit > Connect**]:

1. Select entities to *connect*. Select only the entity or entities that should be changed to make the connection. For example, to move an *arc so it connects to two lines*, which stay in place, select the *arc*, not the lines.
 2. The prompt reads "**Connect from 1st point:**". Pick a point on the source entity.
 3. The prompt reads "**Connect it to point:**". Pick the first connection point on the target entity.
 4. The prompt reads "**Connect from 2nd point:**". Pick the second connection point on the source entity.
 5. The prompt reads "**Connect it to point:**". Pick the second connection point on the target entity.
 6. The prompt reads "**Align meridian point [2d plane]:**". **EasyCAD** is asking you how to spin the source entity after connecting it to the target entity.
 - Right-click or press **ENTER** to accept the **2D** plane.
- EasyCAD** calculates the changes needed to fit the "**connect from**" points to the "**connect to**" points and redraw the entity as desired. The command ends.
- Pick a point on the axis. You'll get best results if you place the axis point farther away from you than the center of rotation.

EasyCAD calculates the changes needed to fit the '**connect from**' points to the '**connect to**' points and redraw the entity as desired.

Text equivalent: **CONNECT**

Mirror



MIRROR transforms an entity into a *mirror image* of itself, flipped over a mirror line that you specify.

The *mirror line* you specify is never actually drawn.

To *mirror* entities, select [**Edit > Mirror**]:


1. Select entities to *mirror*.
2. The prompt reads "**Mirror line 1st point:**". Pick the mirror line's starting point in the drawing window, or type numeric coordinates.
3. The prompt reads "**Mirror line 2nd point:**". Pick the mirror line's ending point in the drawing window, or type numeric coordinates. The mirror line can be drawn at any angle.

Hint: To lock the **2nd point** precisely *vertical* or *horizontal* to the **1st point**, use the **ORTHO** button.

EasyCAD flips the entities and terminates the command.

Text equivalent: **MIRROR**

Trims > Trim



TRIMS > TRIM trims or extends an entity to a *new endpoint*.


To *trim* an entity, select [**Edit > Trims > Trim**]:

1. The prompt reads "**Entity to trim:**". Pick the entity you wish to trim, selecting a point on the end of the entity you want to keep.
2. Now the prompt reads "**Trim to point [pick point]:**". You can:
 - Pick a new endpoint for the entity. **EasyCAD** trims or extends the entity to the "**Trim to**" point.
 - Right-click or press **ENTER**. The point you used to select the entity will be used as the "**Trim to**" point. **EasyCAD** erases the shorter entity segment.

If *snap locking is on* when you use **TRIM**, **EasyCAD** *trims* the entity to the point *closest to the nearest snap point*. As always, the use of *modifiers* or the **Attach mode** overrides *snap locking*.

Text equivalent: **TRIM**

Trims > Trim to Entity




TRIMS > TRIM TO ENTITY *trims* or extends selected entities to terminate cleanly at their intersections with a selected boundary entity.

1. The prompt reads “**Select entity to trim to:**”. Pick *any point* on the *boundary entity* to which you will *trim* other entities.
2. The prompt reads “**Select entity to trim:**”. The entity (or entities) you select *will be trimmed to the previously chosen entity*. **EasyCAD** allows you to continue to select entities to trim as needed. Right-click to end the command.

Text equivalent: **TRIMTO**

Trims > Trim to Intersection



TRIMS > TRIM TO INTERSECTION *trims* or extends two entities to a new endpoint at their intersection. This command is very useful for creating precise vertices with two non-parallel entities.


To *trim to entities to an intersection*, select [**Edit > Trims > Trim to intersection**]:

1. The prompt reads "**1st entity to trim:**". Pick a point on the first entity you want to trim or extend.
2. The prompt reads "**2nd entity to trim:**". Pick a point on a second entity.

Both entities will be *trimmed* and redrawn, *sharing a common endpoint*. **EasyCAD** terminates the command.

Text equivalent: **TRIMINT**

Trims > Trim to Length



TRIMS > TRIM TO LENGTH trims or extends an entity to a pre-defined length.

To *trim an entity to length*, select [Edit > Trims > Trim to length]:


1. The prompt reads "**Trim to length [n]:**". Enter a *new length* or accept the default or *prior value* with a right-click.
2. The prompt reads "**Entity to trim:**". Select each entity near the end you wish to keep or anchor.

The entity you select will be trimmed to the pre-defined length. **EasyCAD** stays in the **Trim** command, allowing you to select additional entities to *trim to the specified length*. Right-click to end the command.

This command will *trim* an *arc* to its actual "**arc length**".

Text equivalent: **TRIML**

Trims > Trim Inside Entities



TRIMS > TRIM INSIDE ENTITIES will *trim an entity at its intersection with two selected bounding entities, keeping the portion inside the boundaries*. This command can optionally be used with only one bounding entity (trimming a line within a circle, for instance).

To use **Trim Inside Entities**, select [**Edit > Trims > Trim inside entities**]:

1. The prompt reads "**Trim Edge Entity:**". Pick a point on the *first boundary entity*.
2. The prompt reads "**2nd Trim Edge Entity [optional]:**". Pick the *second boundary entity*. The second entity is *optional*. Right-click or press **ENTER** to bypass second edge selection.
3. The prompt reads "**Entity to trim:**". Pick the entity you wish to *trim*. Be sure to *select the entity on a point between the two boundaries*. EasyCAD trims the selected entity.


You can continue selecting additional entities to *trim*, as long as they are appropriately bounded. Right-click to end the command.

NOTE: This command does not '*extend*' entities like most other *trim* commands do. If you wish to lengthen a line to a boundary entity, use the [**Edit > Trims > Trim to entity**] command instead.

TIP: Remember to select the '**Entity to trim**' somewhere on the segment you wish to '**keep**'. Using this logic, you can use this command in lieu of **TRIM OUTSIDE ENTITIES**.

Text equivalent: **TRIMIE**

Trims > Trim Outside Entities



TRIMS > TRIM OUTSIDE ENTITIES will break an entity at its intersection with two selected bounding entities, discarding the portion inside the boundaries. This command can optionally be used with only one bounding entity (breaking a line that crosses a circle, for instance).


To use **Trim Outside Entities**, select [**Edit > Trims > Trim outside entities**]:

1. The prompt reads "**Trim Edge Entity:**". Pick a point on the *first boundary entity*.
2. The prompt reads "**2nd Trim Edge Entity [optional]:**". Select the *second boundary entity*. The second entity is *optional*. Right-click or press **ENTER** to bypass second edge selection.
3. The prompt reads "**Entity to trim:**". Select the entity you wish to *trim* or extend. Be sure to *select the entity on a point between the two boundaries*. **EasyCAD** breaks the selected entity, creating two new entities.

You can continue selecting additional entities to *trim*, as long as they are appropriately bounded. Right-click to end the command.

Text equivalent: **TRIMOE**

Break




BREAK makes *gaps* in all entities except points, text, and dimensions. If you **BREAK** a line, arc, path, or spline, **EasyCAD** creates two entities where there was one.

BREAK turns a circle into an arc, a polygon into a path, or a smooth polygon into a spline. If you **BREAK** an arrow or double arrow, **EasyCAD** doesn't add arrowheads—it replaces an arrow with an arrow and a path, or a double arrow with two single arrows.

1. The prompt reads “**Entity to break:**”. Select the entity you wish to *break*.
2. The prompt reads “**Break starts at point:**”. Pick the *start point for the gap*. If you do not select a point directly on the entity, the point will be projected perpendicularly to the entity (or the entity's tangent).
3. The prompt reads “**Break ends at point:**”. Pick the *end point for the gap*.

EasyCAD breaks the entity and removes the portion selected. The command terminates.



Break Tips

- If the **break** start and end points are the same, **EasyCAD** creates two entities, even though you can't see the place where they join (as with the **SPLIT** command). If you **break** a **line** or **arc** at one of its **endpoints**, **EasyCAD** creates two entities (**one is zero length**). To **shorten** or **extend** an **arc** or **line**, use the **TRIM** command instead.
- When you **break** a **polygon** or **smooth polygon**, **EasyCAD** always keeps node #1. When you **break** a **circle**, **EasyCAD** keeps the portion of the circle you selected at the "entity to break:" prompt.
- If **snap locking** is turned on when you use **BREAK**, **EasyCAD** breaks the entity where it passes nearest to a snap point. You can use **modifiers** like **ON**, **% ALONG** or **DEGREE** to **break** at specific points on the entity; or use the **SNAP** button on the command bar.

Text equivalent: **BREAK**


Bend

This **BEND** command allows you to select a **LINE** entity and move the mouse cursor to a desired location and left-click to create **TWO LINES** that start at the original **ENDPOINTS** of the selected **LINE** and intersecting at this new location. Select the [**Edit > Bend**] command.

1. The prompt reads:

Entity to bend: 


Select a **LINE** with a left-click.



2. The prompt now reads:

Bend to point 

A dynamic cursor will appear and as you move across the drawing you will see the image of the two new **LINES** that will be created when you left-click to place the intersecting point.



NOTE: The **BEND** command only works on **LINE** entities.

Text equivalent: **BEND**

Split

SPLIT *divides an entity into two entities* of the same type at the point you select.

1. The prompt reads “**Entity to split:**”. Select the entity you wish to *divide*.
2. The prompt reads “**Split at point:**”. Pick the *split point*. If you do not pick a point directly on the entity, the point will be projected perpendicularly to the entity (or the entity’s tangent). Use *modifiers* such as *endpoint* for precision.

EasyCAD creates two entities, even though you can’t see the place where they join, and terminates the command.

Text equivalent: **SPLITNode Edit > Insert**

The **NODE EDIT > INSERT** commands allow you to *insert nodes* in entities that have *nodes* as *control points*, such as *paths*, *polygons*, and *splines*.

For a more intuitive approach to the same function, try using the **DYNAMIC EDIT** command [**Edit > Dynamic Edit**].

The prompt reads “**Insert node at:**”. Pick a point on the entity you wish to modify. Then pick a point for the *new node*. The endpoints of the original entity stay in place, and **EasyCAD** draws two new segments from the endpoints to the *new point*.

Text equivalent: **INSNODE**

Node Edit > Delete

The **NODE EDIT > DELETE** commands allow you to *delete nodes* in entities that *have nodes* as *control points*, such as *paths*, *polygons*, and *splines*.

The prompt reads “**Delete node at:**”. Pick a point on the entity near the *node* you wish to *delete*. The *node* is *deleted* and a new segment drawn between the two previously adjoining nodes. *Paths*, *polygons*, and *splines must have at least two nodes*.

Text equivalent: **DELNODE**


Node Edit > Insert

The **NODE EDIT > INSERT** command allow you to *insert nodes* in entities that *have nodes* as *control points*, such as *paths*, *polygons*, and *splines*.

The prompt reads “**Insert node at:**”. Pick a point on the entity near the *node* where you wish to *insert a new node*. The *dynamic cursor* shows an image of the *new node* as you move and a left-click places it. *Paths*, *polygons*, and *splines must have at least two nodes*.

Text equivalent: **INSNODE**

Front



FRONT brings entities to the *front of your screen*. After you select the entities, **EasyCAD** moves them to the *end* of the drawing file. Because **EasyCAD** draws entities in the order that it finds them in the file, *entities at the end appear to be on top of or in front of other entities*.


For example, a *filled polygon* drawn after a *line* is drawn *hides* the *line* on-screen. You could use **FRONT** to select the *line* to be in **FRONT** of the *polygon*.

If the entity style of the polygon uses a scaleable or symbol fill pattern that is transparent and not totally opaque, the line will be seen behind the fill pattern.

Use **UNDO** to reverse the operation.

Text equivalent: **FRONT**

Above



ABOVE works like the **FRONT** command but is different in that it “**moves**” the selected entities in *front* of a specifically selected entity..


To *move* an entity *above* another, select [**Edit > Above**]:

1. The prompt reads “**Move above entity:**”. Pick one entity that the **ABOVEd** entities will *move in front of*.
2. The prompt reads “**Select entities:**”. Use the standard entity selection procedure to select one or more entities to be *moved in front* of the previously selected entity.

Use **UNDO** to reverse the operation.

Text equivalent: **ABOVE**

Below



BELOW works like the **BACK** command, drawing selected entities at the *back of your screen*. **BELOW** is different in that it “**moves**” the selected entities *behind* specifically selected entities. **BACK** *moves the selected entities to draw behind all other entities in the drawing*.


To *move* an entity *below* another, select [**Edit > Below**]:

1. The prompt reads “**Move above entity:**”. Pick one entity that the **BELOWed** entities will *move behind*.
2. The prompt reads “**Select entities:**”. Use the standard entity selection procedure to select one or more entities *to be moved behind* the previously selected entity.

Use **UNDO** to reverse the operation.

Text equivalent: **BELOW**

Back



BACK moves entities to the *back of your screen*. After you select the entities, **EasyCAD** moves them *to the front of the drawing file*. Because **EasyCAD** draws entities in the order that it finds them in the file, *entities at the front appear to be in back of or behind other entities*.

For example, a *filled polygon* drawn after a *line* is drawn *hides* the *line* on-screen. You could use **BACK** to select the *polygon* to be *behind* the *line*.

If the entity style of the polygon uses a scaleable or symbol fill pattern that is transparent and not totally opaque, the line will be seen behind the fill pattern.

Use **UNDO** to reverse the operation.

Text equivalent: **BACK**

Explode

EXPLODE command [**Edit > Explode**] reduces the complexity of entities down to more *basic components*.

- **Points, lines, circles, and arcs do not reduce.**
- **Ellipses** reduce to a **Polygon** with **one EXPLODE** and a series of **Lines** with a second **EXPLODE**.
- **Elliptical arcs** reduce to a **Path** with **one EXPLODE** and a series of **Lines** with a second **EXPLODE**.
- **Multipolys** and **symbol references** reduce to the **original entities**.
- **Groups** reduce to **original entities (all levels)**.
- **Polygons, paths, and splines** reduce to a **series of lines**.
- **Arrows** reduce to the **base entity (path/line/arc) without arrow-head** info.
- **Dimensions** reduce to **text, lines, and polygons** representing the arrowheads.
- **File text** reduces to **multi-line text** entities.
- **Multi-line** text reduces to **single line text** entities.
- **Walls** reduce to **line** entities.
- **Xrefs** are disassociated from the source drawing; their entities become integral to the host drawing (analogous to an ungrouped part).
- **Symbol References** reduce to **original entities after one EXPLODE**. A second **EXPLODE** will reduce **nested Symbols** back to the **original entities**. Using **EXPLODE** on these original entities will reduce them as stated above.

EXPLODE can also be useful for **removing errant blocks, symbols, or special** entities found after importing some **DXF** files produced by third parties.

WARNING: You should never use the **EXPLODE** command and select entities by **ALL** unless you really mean to do this. **ALL** of the entities in the *active drawing* will be reduced to the *basic entities* described above.

If you select **ALL** entities by mistake, use the **UNDO** command immediately after hitting the **DO IT** command. If you have **SAVED** the drawing after using the **EXPLODE** command, **UNDO** will **NOT** work.

Do not use the **EXPLODE** command on entities that are **GROUPED**. Use the **UNGROUP** command from the **INSERT** menu or click the **LOCKED** button at the right end of the command line so it reads **UNLOCKED**.

This is a temporary *unlock* for **GROUPS** that will allow you to **EDIT** them. Click the **UNLOCKED** button so it reads **LOCKED** to turn **GROUP** locking back on.

Use **UNDO** to reverse the operation.

Text equivalent: **EXPLODE**


Copy Commands

Duplicate entities in your drawing

Commands in the *Copy* menu add new entities to your drawing by duplicating existing entities. **EasyCAD** marks the entities added as new when you use **Copy** commands. You can edit the copies or make copies of the copies by choosing **Prior** from the *Entity Selection* dialog box.

- **COPY** duplicates existing entities
- **DRAG COPY** duplicates entities using dynamic cursors
- **COPY TO LAYER** duplicates entities, but to different layers.
- **COPY CONNECT** works like **CONNECT**, but leaves the selected entities unchanged.
- **Scale Copy** commands resize copies of existing entities.
- **Rotate Copy** commands rotate copies of existing entities.
- **MIRROR COPY** works like **MIRROR**, but leaves the selected entities unchanged.
- **Array** commands create evenly spaced copies in rectangular or circular patterns.

Copy



Tip:

You can force the copies to line up horizontally or vertically with the originals by turning on orthogonal locking.

Turn on ortho by depressing the *Ortho button*.

COPY duplicates entities from one location to another within a drawing. **COPY** does *not rotate* or *scale* the entities.

To *copy* entities, select [**Copy > Copy**]:

1. Select the entities to *copy*.
2. The prompt reads "**Copy origin:**". This is a base point that **EasyCAD** uses to determine *copy* placement. The cursor turns into crosshairs. To specify the *copy origin*, pick a point or type numeric coordinates. Usually, you would pick a point on the entity, though that is not a requirement.

EasyCAD displays a rubber-band cursor anchored at the *copy origin*.

3. The prompt reads "**Copy to point:**". To specify the new *copy* location, pick a point or type numeric coordinates.

EasyCAD calculates the *distance* and *direction* between the points and copies the selected entities accordingly.

4. The prompt still reads "**Copy to point:**". You can make *multiple copies*, selecting a new location for each, until you right-click to end the command.


You can force the *copies* to line up *horizontally* or *vertically* with the originals by turning on *orthogonal locking* by clicking the **ORTHO button**.

Text equivalent: **COPY**

Ortho

Ortho button

Drag Copy



DRAG COPY works almost identically to the regular [**Copy > Copy**] command except for two key differences:

1. The **DRAG COPY** command displays a dynamic cursor of the entities that are being *copied*, exactly like the regular **DRAG** command. This allows you to use the **CTRL** key to *scale*, and the **CTRL+SHIFT** keys to *rotate*, during placement.
2. For multiple copies from a single source, the '**copy from**' point remains fixed in the regular **COPY** command. With **DRAG COPY**, the '**copy from**' point changes relative to the *last copy*. This can be helpful when the displacement between each of the copy elements is easier to quantify, rather than the vector between each copy element and the original.

To *drag copy entities*, select [**Copy > Drag Copy**]:

1. Select the entities to *copy*.
2. The prompt reads "**Origin:**". This is a base point that **EasyCAD** uses to determine copy placement. The cursor turns into crosshairs. To specify the *copy origin*, pick a point or type numeric coordinates. Usually, you would pick a point on the entity, though that is not a requirement.

EasyCAD displays a rubber-band cursor anchored at the *copy origin*.

3. The prompt reads "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**". To specify the *new copy* location, pick a point or type numeric coordinates.

EasyCAD calculates the *distance* and *direction* between the points and *copies* the selected entities accordingly.

4. The prompt still reads "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**". You can make *multiple copies*, selecting a new location for each, until you right-click to end the command.

Text equivalent: **DRAGCOPY**

Copy to Layer

COPY TO LAYER *copies* selected entities to a *different layer*, leaving the originals in place.

To *copy entities to a layer*, select [**Copy > Copy to Layer**]:


1. Select entities to *copy*.
2. The prompt reads "**Layer name or # [dialog]:**". **EasyCAD** is asking for the *layer* to which the selected entities will be copied. To specify a *target layer*:
 - Type in an existing *layer name or ID #* and press **ENTER**.
 - Right-click to display the *Select Layer dialog*. Pick the *target layer* from the list.

EasyCAD *copies* the entities to the selected *layer* and terminates the command. You can verify the command's proper operation with the [**Info > List**] command.

To *move* the entities to a *new layer*, use the [**Edit > Change > Layer**] command.

Text equivalent: **LAYERCPY**

Copy Connect



COPY CONNECT *copies* an entity or entities, then *scales* and *rotates* the *copy*, *connecting* it to other entities and designated points. You supply **EasyCAD** with four points, two on the entity to be moved (**source entity**) and two on the target entity.

This command works exactly like the [**Edit > Connect**] command, except that the entity being connected is not altered. Instead, a copy of that entity is created and transformed.

To *connect* entities, select [**Copy > Copy Connect**]:

1. Select entities to *connect*. Select only the entity or entities that should be copied to make the connection. For example, to copy an arc so it connects to two lines that remain in place, select the arc, not the lines.
2. The prompt reads "**Connect from 1st point:**". Pick a point on the source entity, using modifiers or the **Attach mode** to assist in precision.
3. The prompt reads "**Connect it to point:**". Pick the first connection point on the target entity.
4. The prompt reads "**Connect from 2nd point:**". Pick the second connection point on the source entity.
5. The prompt reads "**Connect it to point:**". Pick the second connection point on the target entity.
6. The prompt reads "**Align meridian point [2d plane]:**". **EasyCAD** is asking you how to *spin* the source entity after connecting it to the target entity.

Right-click or press **ENTER** to accept the **2D plane**.

EasyCAD calculates the changes needed to fit the "**connect from**" points to the "**connect to**" points and redraws a transformed copy of the entity as desired.

Text equivalent: **CONNECTC**

Dynamic Scale Copy

DYN SCALE COPY visually shrinks or enlarges a copy of the selected entities, using a dynamic cursor.

To *dynamically scale copies* of entities, select [**Copy > Dyn Scale Cpy**]:

1. Select entities to *copy* and *scale*.
2. The prompt reads "**Origin:**". The drag from point is the point around which **EasyCAD** should scale the entities (the "*scale center*"). To specify the scale center:
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.

3. *The prompt reads*

SHIFT=move CTRL=scale CTRL+SHIFT=rotate: 

Move the mouse on the screen to visually resize the selected entities. They will shrink or grow depending on the direction of mouse movement. When you are satisfied with the size of the entities, left-click to create the scaled copies. The original selected entities remain unchanged.

EasyCAD redraws the entities at the new scale. The *scale center* remains fixed.

4. The prompt continues to read "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**". You can continue to create new scaled copies, or you can right-click to end the command

The "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate**" prompt tells you that dynamic cursors are in effect. While creating the *scaled copies*, you can also move the *scale center* or *rotate* the copied entities. To move the *scale center*, hold down the **SHIFT** key while moving the mouse. To *rotate* about the *scale center*, hold down the **SHIFT+CTRL** keys while moving the mouse.

Text equivalent: **DYNSCLC**

Scaled Copies

SCALED COPIES shrinks or enlarges *copies* of selected entities, based on a *scale* value you enter.


To *scale copy* entities, select [**Copy > Scaled Copies**]:

1. Select entities to *scale*.
2. The prompt reads "**Scale by factor [n]:**". If you wish to accept the default, right-click or press **ENTER**. To enter a new scaling factor, type a scaling and press **ENTER**. Scaling factors **> 1** will make entities larger. Scaling factors **< 1** will make entities smaller. For example, to make the selected entities twice as large as they are now, type "**2**" and press **ENTER**. To make them half as large, type "**.5**" and press **ENTER**.
3. The prompt reads "**Origin point [x,y,z]:**". The *scale center* is the point around which **EasyCAD** should *scale* the entities. To specify the *scale center*:
 - Right-click or press **ENTER** to accept the default or *prior center*.
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.

EasyCAD draws new copies of the entities at the *new scale*. The *scale center* remains fixed.

Text equivalent: **SCLCPY**

Dynamic Rotate Copy



DYN ROTATE CPY works like **DYNAMIC EDIT**, except that, instead of rotating the selected entities, it makes rotated copies of the entities, leaving the originals in place.

To *dynamically rotate copies* of entities, select [**Copy > Dyn Rotate Cpy**]:

1. Select entities to *copy* and *rotate*.
2. The prompt reads "**Origin:**". The drag from point is the point around which **EasyCAD** should turn the entities. To specify the *rotation center*:
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.

3. The prompt reads SHIFT=move CTRL=scale CTRL+SHIFT=rotate: 

Move the mouse on the screen to *visually rotate* the selected entities. They will *rotate* to the bearing defined by the cursor position to the rotation center. When you are satisfied with the rotation of the entities, left-click to create the rotated copies. The original selected entities remain unchanged.


FastCAD creates *copies* and *rotates* them around the center, which remains fixed.

4. The prompt continues to read "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate:**". You can continue creating new rotated copies, or you can right-click to end the command.

The "**SHIFT=move CTRL=scale SHIFT+CTRL=rotate**" prompt tells you that dynamic cursors are in effect. While creating the rotated copies, you can also move the rotation point or scale the copied entities. To move the rotation point, hold down the **SHIFT** key while moving the mouse. To *scale* hold the **CTRL** key while moving the mouse.

Text equivalent: **DYNROTC**

Rotated Copies



ROTATED COPIES works like **ROTATE**, except that, instead of rotating the selected entities, it makes rotated copies of the entities, leaving the originals in place.


To place *rotated copies* of entities, select [**Copy > Rotated Copies**]:

1. Select entities to *rotate*.
2. The prompt reads "**Rotate by Angle [n]:**", with the last angle you used suggested as a default or prior value. (The **default is 90°** when you start a new work session.) You can:
 - Right-click or press **ENTER** to accept the default or prior rotation.
 - Type a positive or negative angle, which can include values like **90.0005°** or **22+1/2°**. (Remember that positive angles turn counterclockwise.) For example, to turn the entities **45°** clockwise, type "**45**" and press **ENTER**.
3. The prompt reads "**Origin point [x,y,z]:**". This is the point which **EasyCAD** should turn the entities. To specify the rotation center:
 - Right-click or press **ENTER** to accept the default or prior center.
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.
4. The prompt reads "**Rotate Axis Point [XY plane]:**". Right-click to accept the **XY plane**.

EasyCAD creates copies of the selected entities and *rotates* them around the *center*, which remains fixed.

Text equivalent: ROTCPY

Mirrored Copies



MIRRORED COPIES works like **MIRROR**, except that instead of flipping the selected entities, it makes *mirror-image copies* of them, leaving the originals in place. This is useful for drawing objects that are symmetrical about any axis. You can draw one side of the object, then use **MIRCPY** to create the other side.

The mirror line you specify is never actually drawn.

To *mirrored copies* of entities, select [**Copy > Mirrored Copies**]:


1. Select entities to *mirror*.
2. The prompt reads "**Mirror line 1st point:**". Pick the mirror line's starting point in the drawing window, or type numeric coordinates.
3. The prompt reads "**Mirror line 2nd point:**". Pick the mirror line's ending point in the drawing window, or type numeric coordinates. The mirror line can be drawn at any angle.

Hint: To lock the 2nd point precisely *vertical* or *horizontal* to the 1st point, use the *Ortho* button.

EasyCAD draws *new copies* of the selected entities and *flips* them over the *mirror line*. The command terminates.

Text equivalent: **MIRCPY**

Rectangular Array



Tip:

You can force the mirror line to be perfectly horizontal or vertical turning on orthogonal locking. Turn on ortho by depressing the *Ortho* button.

This way, the second mirror line point can be chosen semi-arbitrarily (you just need to establish direction). This can often be faster than having to carefully choose both mirror line points.

Ortho

Ortho button

RECTANGULARARRAY makes a *rectangular array* (regularly spaced *rows* and *columns*) of copies. Build *rectangular arrays* using entities in your drawing or parts and symbols inserted from another file.

To build a *rectangular array*, select [**Copy > Rectangular Array**]:

1. Select entities to *array*.
2. The prompt reads "**# of columns [n]:**". **EasyCAD** is asking for the number of *horizontal copies* to draw. Type the total number of objects in each *row*, including the original. Right-click to accept the default or *prior value*.
3. The next prompt reads "**# of rows [n]:**". **EasyCAD** is asking for the number of *vertical copies* to draw. Type the total number of objects in each *column*, including the original. Right-click to accept the default or *prior value*.
4. The prompt reads "**Origin:**". This is a base point that **EasyCAD** uses to determine spacing between copies. Pick a point on the object to be copied.

EasyCAD displays a rubber-band cursor, anchored at the "**Repeat origin**".


5. The prompt reads "**2nd col, 2nd row point:**". This offset from the *origin point* tells **EasyCAD** both the *horizontal* and *vertical* distance you want between parts in the *array*. You can use the rubber-band cursor to help you judge the spacing. Pick the point in a drawing window *diagonally* from the *origin point*.

EasyCAD draws the *array* and terminates the command.

Note: If you enter quantity = 1 for the number of columns and rows, the array command will cancel itself rather than (**likely inadvertently**) copy the selected entities on top of themselves.

Text equivalent: REPEAT

Circular Array



CARY creates multiple copies arranged in rings. Build *circular arrays* using entities in your drawing or parts and symbols inserted from another file.

To build a *circular array*, select [**Copy > Circular Array**]:

1. Select entities to *array*.
2. The prompt reads "**Number of spokes [n]:**". **EasyCAD** is asking for the number of copies to draw per revolution. Type the total number of spokes, including the original. Right-click or press **ENTER** to accept the default or prior value.
3. The next prompt reads "**Number of rings [n]:**". **EasyCAD** is asking for the number of concentric rings of copies to draw. Type the *total number of rings*, including the original. Right-click or press **ENTER** to accept the default or prior value.
4. The prompt reads "**Array center [x,y]:**". This is the *center point of the array*. To specify a *center*:
 - Right-click or press **ENTER** to accept the default or *prior center*.
 - Pick a point in a drawing window.
 - Type numeric coordinates and press **ENTER**.
5. The prompt reads "**Copy origin:**". This base point determines spacing between copies. Pick a point on the entity or entities to be copied.
6. The prompt reads "**Angle between spokes [n]:**". The default value spaces the spokes evenly to make a full circle. Right-click or press **ENTER** to accept the default, or type in a different angle value if desired.

If you did not specify more than one ring, **EasyCAD** draws the *array* and terminates the command.

7. If you asked for more than one ring, the prompt reads "**Distance between rings:**" This is the distance from the origin point of the original to the corresponding point on the first copy in the next ring. Enter a measurement.

EasyCAD draws the array and terminates the command.

Text equivalent: **CARY**

Insert Commands

Working with Symbols and Parts

One of the great advantages of **CAD** over pen & paper is its ability to readily duplicate drawings or components. After you've drawn something once, you can use it over and over again, even in other drawings. **EasyCAD** uses two methods to accomplish this task: *symbols* and *parts*.

Commands in the **INSERT** menu are used to manipulate *symbols* and *parts* (which are simply any **EasyCAD** drawing). In the most general sense, *symbols* and *parts* are **EasyCAD** drawings that are made "**portable**". Though they share similar usage traits, they differ in a number of important ways. Consider these differences when determining which method is best for a particular purpose.

Symbols and Parts Defined

Symbols are collections of entities that are stored internally in each drawing, hidden from view. These unseen, internal representations are called *Symbol definitions*. In order to see a *symbol* on the drawing, you must draw a *symbol reference*. Each *reference* accesses a *definition* and *cannot exist without that definition*. Because many *references* can point to the *same definition*, *symbol references* can help keep your drawing small.

Symbols also possess an optional property called *attributes*. *Attributes* are pieces of information that are attached to each instance of a *symbol reference*. These are helpful when extracting drawing information for use in a database, bill of materials, etc.

Parts also contain a collection of entities, but they are stored as *separate drawing files*. When you *insert a part* into your drawing, you are adding the *entire part drawing file* into your existing drawing—including any custom *layers*, *line styles*, *fill styles*, etc., contained therein. When you *insert a part*, you also import *all symbol definitions* in that *part*.

EasyCAD's Symbol Catalog Viewer

The *Symbol Catalog viewer* greatly enhances *symbol* usage.

Manage your *symbols* by creating **.FS7 symbol catalog files**. Entire sets of *symbols* can be loaded into your drawing for instant accessibility. **.FS7** files can be created and customized like any standard **EasyCAD** drawing. The **LOAD PART AS SYMDEF** command is available to *convert entire folders of parts into a single .FS7 catalog file*.

Symbol insertion with the *Symbol Catalog viewer* is a drag-and-drop type operation. Use the thumbnail viewer to browse the catalog, then select, and insert. You can expand the single column thumbnail display into a full-page spread by right-clicking directly on the viewer.

Choosing Symbols or Parts Method

While you can *scale* or *rotate* both *symbols* and *parts* upon insertion, there are some distinctions that make one or the other a more appropriate choice for your current drawing.

If you are placing numerous copies of identical entities, symbols are your best choice. When you *edit* a *symbol definition*, *all symbol references in your drawing update accordingly.* EasyCAD also allows dynamic placement of *symbols*, meaning that you can see a ghost cursor of the *symbol* before you actually insert it. *Symbols* can possess *attributes*. *Symbols* can be efficiently and logically consolidated into *catalog files for use with the Symbol Catalog viewer.*

Parts are more useful in situations where the source will be inserted into a drawing once, such as a drawing border. Also, use *parts* if you intend to *edit* the inserted entities. When *parts* are inserted, they are completely disassociated from the source.

Xrefs

External References files [XREF] are another method of combining different drawing files. Each **XREF** points to a separate drawing file, which then appears as part of the host drawing. There is no limit to the number of xrefs contained in a drawing.

When the **INSERT XREF** command is used to create a combined drawing file, the **XREF** file is actually inserted as a *symbol reference*. In essence, an **XREF** is a *symbol definition stored in another file*. The host drawing simply contains a *reference* that contains the **XREF** file's *drive, path, and file name*. As long as that information is valid, The **XREF** files will appear automatically when the host file is loaded.

When a drawing exists as an **XREF**, *it cannot be modified*. However, the xrefed file can be loaded as a drawing file and edited. Those changes are reflected wherever that drawing is xrefed.

Exploding an Xref

An **XREF** *can be made a perminate part of the host drawing* by using the [Edit > Explode] command. This works exactly like *exploding a symbol reference*. The ghost image of the *xfer* file now become real entities in the host drawing and may be edited. The link between the *xref* file is broken and changes made to it will *not be reflected in the host drawing*.

Part commands

A *part* is any **EasyCAD** drawing that you insert into another drawing. If your work uses repeated elements like furnishings, electronic components, or standard details, save each element as an individual drawing file. The **PART** commands let you use such elements over and over without ever having to construct them again.

Frequently used *symbols* can be imported into drawings via the *parts* method.

To create a part file:

- Load or create a **EasyCAD** drawing in the usual way;
- Use the [**Insert > Create Part**] command to save selected entities from an existing drawing as a *separate file*.

When **EasyCAD** inserts one file into another as a *part*, it puts the inserted file's *origin* or (0,0) coordinate on the "insert at/scale factor [INS=specs]:" point. When you start a new drawing, the (0,0) point is below and to the left of the screen. When you create a drawing to use as a *part*, use the [**View > Change Origin**] command to set the (0,0) point to a *logical point in the part*—the center or lower-left corner is usually a good choice.

Normally, entities that you insert as *parts* keep the **layer assignments** that they had in the original *part* file (so you can have multi-layer parts). If you want **EasyCAD** to insert the *part* on the *current work layer* instead, draw the entities in the *part* file on the **MERGE layer**. If you forget to set up a *part* this way, it is easy to move the newly inserted *part* to the *current layer*—just select [**Edit > Change > Layer**], select by **Prior**, then choose 'Do it'. Right-click to display the *Layer Management dialog box*, then choose **OK** to accept the *current layer*.


Commands for Inserting Parts:

- **INSERT PART** adds one part at a time;
- **PART ARRAY** builds a rectangular array (**rows and columns**);
- **CIRC PART ARRAY** builds a circular array (**spokes and rings**).

Each time you insert a *part*, you can *scale* and *rotate* it as needed. If units in the *part* file are different from the units in the current drawing, **FastCAD** does the conversion for you. For example, if you insert a 48" desk with units defined as Inches into a floor plan with units defined as Feet, the desk is 4 units long in the floor plan.

EasyCAD inserts each *part* as a **GROUP** as it is added to your drawing, treating the *entire part as a single entity*. To modify individual entities within inserted *parts*, you can *unlock group effects* by clicking the *Locked* button so it reads *Unlocked*, perform entity *edits*, and then *restore group effects* by clicking the *Unlocked* button so it reads *Locked* again. Use the **UNGROUP** command to permanently disassociate a grouped *part*.


Insert Part



INSERT PART adds any other **EasyCAD** drawing, as a *part*, to the working drawing. One part at a time is inserted.


1. **EasyCAD** displays the **Part to Insert dialog box**. This is the standard **Load Drawing dialog box**. Note that **EasyCAD** displays the last inserted *part* as the default. To select a *part to insert*:

- Double-click a filename;
- Select a filename using the cursor and choose **Open**;
- Type a drawing filename from the list of available drawings.


2. **The prompt reads** Insert part at/scale factor [INS=specs]: 

You should see a *ghost image* of the *part* attached to the moving cursor. If you want to change the *scale* of the original you may immediately **type a new scale factor** such as “2” to make the *part* twice as large. If you press the “Ins” key on the keypad **EasyCAD** displays the **Insert Parameters dialog box** with the *default Scale factor* and *XY Rotation Angle* of the *part*. You may adjust both *part scaling* and *rotation* from this dialog box. The *name* of the *part drawing* is also displayed in the dialog box.

- The *default scaling is 1.0* (same size as the original part). Type in a *new scale factor* if you wish to insert the *part* at a *larger* or *smaller* size.
- The *default XY rotation angle is 0.0°*. If you wish to *rotate* the *part* upon insertion, *type in a new rotation between 0 degrees and 360 degrees*. For example, type “45” to *rotate the part 45 degrees counter-clockwise*.




Insert Parameters dialog box

3. Choose the **OK** button to accept the *scaling* and *rotation values*.
4. *The prompt reads* .
Enter an insertion point by using the crosshairs, or by typing numeric coordinates.
EasyCAD draws the contents of the *part* file at the *insertion point*.
5. The prompt continues to read “**Insert part at/scale factor [INS=specs]:**”.
Continue inserting copies of the *part* if you wish. Right-click to end the command.

Text equivalent: **PART**

Macro equivalent (bypass dialog box): **PARTM**



Insert XREF

External references (XREFs) provide another method of working with multiple drawing files.

An XREF placed within a host drawing "points" to another physical drawing file. The XREF then appears in the host drawing. Because the **XREF pointer** is embedded in the *host drawing*, the **XREF** files automatically load with the *host drawing*.

The easiest way to understand the benefits and limitations of **XREFs** is by thinking of them as how they are implemented: A visible **XREF** is like a *symbol reference*, where the *definition is an external file*. An **XREF** file itself is a valid and editable drawing, but it *exists in the host drawing only as a file name (along with its drive and path)*.

By contrast, *overlay* and *reference* files never create an inherent association between themselves and any other drawing. They must always be loaded manually.

It is critical that the **XREF** file must exist on the *same drive* and *directory path* as when it was created in the *host drawing*. **EasyCAD** will not "search" for the file if it is not where the **XREF pointer** says it will be. This may create portability problems, especially if the *host drawing* contains **XREFs** to many different drawing files in many different *drives* and *directorues*.

If the host drawing is moved to another computer, the XREF files must be moved into the identical drive and directory path structure.

Like a *symbol reference*, an **XREF** within a drawing cannot be directly edited *within the host file*. You must instead load the **XREF** file as a *separate* drawing, then perform *edits* and *save* the file. When the *host drawing* is opened, the **XREF** will *reflect the updates*.


An **XREF** reference can be *changed to point to a different file* by clicking directly in the **Work Dwg: status** window to open the **External Reference [XREF] Management dialog box**. Left-click the **XREF** file name and click the **Change File** button. **EasyCAD** displays the standard **Load Drawing** dialog, from which you can choose a new **XREF** file. The new file will appear at the same *Origin point* as the original **XREF**.

Importing AutoCAD .DWG and .DXF drawings containing XREFs

You can import **AutoCAD** files with **XREFs**, but the exact original path (**DWG**) cannot be changed. If the *host drawing* is in **.DWG format**, then the **XREF** files must be in **.DWG** also. If the *host drawing* is in **.DXF format**, then the **XREF** files must be in **.DXF** format also.

If you open an **AutoCAD .DWG** or **.DXF** drawing with **XREFs** in them, you may have the **XREF** drawings also or there will be missing information from the *host drawing*. This missing information may be important to your project so **EasyCAD** alerts

you to the fact that the drawing being imported contains **XREFs** that can not be located in the *original drive* and *directory path* pointed to by the *host drawing*..



XREF Not Found Alert box

If you have the XREF files

If you were sent the **XREF** drawing files by the **AutoCAD** user, along with the *host drawing*, *click directly in the Work Dwg: status window* to open the *External Reference [XREF] Management dialog box*.. You will see the original **XREF file name**, *drive* and *directory path* where it was originally stored. The left most checkbox will have a "U" in it signifying that it is *Ulocated*.



External Reference [XREF] Management dialog box.

This checkbox normally has "OK" in it when the **XREF drawing** is located properly.

Left-click the **XREF** file name and click the *Change File* button. **EasyCAD** displays the standard *Load Drawing* dialog, from which you can choose the *drive* and *directory* where you saved the **XREF** file. The **XREF** drawing will appear in the *host drawing*.

If you do not have the XREF files

Contact the **AutoCAD** user that sent you the *host drawing* and have them send you the **XREF** drawings. Then use the method described above to locate them.

An alternative to this would be to Have the **AutoCAD** user use the **AutoCAD 'BIND'** command which will convert **all XREF files referenced in the host drawing to Symbols** Then have them use a file compression program such as **WinZip** to compress it and send it to you again and the **XREFs** won't be an issue.

Inserting an XREF into an EasyCAD Drawing

1. Click the **INSERT XREF** command from the **INSERT** menu. EasyCAD displays the **Load Drawing dialog box**. This is the standard **File Selection dialog box**. Note that EasyCAD displays the last inserted **XREF** as the default. To select an **XREF** to insert:


- Double-click a filename;
- Select a filename using the cursor and choose **Open**;
- Type a drawing filename from the list of available drawings.

2. *The prompt reads*

Insert part at/scale factor [INS=specs]: 

You should see a *ghost image* of the **XREF drawing** attached to the moving cursor. If you want to change the *scale* of the original you may immediately *type a new scale factor* such as 2 to make the **XREF** twice as large. If you press the '**Ins**' key on the keyboard EasyCAD displays the **Insert Parameters dialog box** with the *default Scale factor* and *XY Rotation Angle* of the **XREF**. You may adjust both *scaling* and *rotation* from this dialog box.. The **XREF drawing name** is also displayed in the dialog box.

- *The default scaling is 1.0 (same size as the original drawing)*. Type in a *new scale factor* if you wish to insert the **XREF** at a larger or smaller size.
- The default *XY rotation angle is 0.0°*. If you wish to *rotate* the **XREF** upon insertion, type in a new *angle between 0 degrees and 360 degrees*. For example, type "**45**" to *rotate the XREF 45 degrees counter-clockwise*.




Insert Properties dialog box

3. Choose the **OK** button to accept the *scaling* and *rotation* values.
4. The prompt reads "**Insert part at/scale factor [INS=specs]:**". Enter an insertion point by using the crosshairs, or by typing numeric coordinates.
5. The prompt continues to read "**Insert part at/scale factor [Ins=specs]:**". Continue inserting copies of the **XREF drawing**. Right-click to end the command.

Text equivalent: XREF


Part Array



PART ARRAY builds a *rectangular array* (rows and columns) from *multiple copies* of a *part* file, arranging the parts in regularly spaced *columns* and *rows*.

To create an *array* of *parts*, select [**Insert > Part Array**]:

1. **EasyCAD** displays the *Part to Insert* dialog. This is a variant of the standard *File Selection* dialog. To specify a *part to insert* and *array*:
 - Double-click a filename;
 - Pick a filename and click **Open**;
 - Type a drawing filename from the list of available drawings, and press **ENTER**.
2. **EasyCAD** displays the *Part to insert* dialog and then the *Rectangular Part Array* dialog from which you may adjust *part scaling*, *rotation*, and *array* options.



Rectangular Array dialog

File name The file you specified in Step 1 is displayed here. To change the file, you must cancel the command and start over.

Scale Sets the size of all *parts* inserted into this *array*. *The default scaling is 1.0 (same size as the original part)*. Type in a new *scale factor* if you wish to insert the *part* at a larger or smaller size.

XY Rotation *Part rotation in the XY plane (rotation center is the part's origin)*. The *default XY rotation angle is 0.0°*. If you wish to rotate each part by the same angle upon insertion, type in a *new angle* between **0 degrees** and **360 degrees**. For example, type "45" to *rotate each part 45 degrees counter-clockwise*.

Number of columns The number of *vertical columns* in this *array*.

Number of rows The number of *horizontal rows* in this *array*.

3. Click **OK** to confirm the parameters.
4. The prompt reads "**Insert 1st part at:**". To specify the first *insertion point*, pick a point on the screen, or type coordinates.

EasyCAD displays a rubber-band cursor, anchored at the *insertion point*.

5. The prompt reads "**2nd column 2nd row at:**"; This offset from the insertion point tells **EasyCAD** both the horizontal and vertical distance between parts. Use the rubber-band cursor to help you judge the spacing. Pick a point when you are satisfied with the distance.

EasyCAD draws the *array* and terminates the command.

*Text equivalent: **PARY***

Circ Part Array



CIRC PART ARRAY (Circular Part Array) inserts *multiple parts arranged in rings*. It's like a combination of **CIRCULAR ARRAY** and **PART ARRAY**. The angle of the first *spoke* (from the center to the "**copy origin**" or insertion point) determines the *angle of each part in the array*.

To draw a *circular part array*, select [**Insert> Circ Part Array**]:

1. **EasyCAD** displays the *Part to Insert dialog*. This is a variant of the standard *File Selection dialog*. To specify a *part to insert and array*:
 - Double-click a filename;
 - Pick a filename and click **Open**;
 - Type a drawing filename from the list of available drawings, and press **ENTER**.
2. **EasyCAD** displays the *Circular Part Array dialog box*. You may adjust *part scaling*, *rotation*, and *circular array* options.



Circular Part Array dialog

File name The file you specified in **Step 1** is displayed here. To change the file, you must cancel the command and start over.

Scale The size of all *parts* inserted into this *array*. The *default scaling is 1.0 (same size as the original part)*. Type in a *new scale factor* if you wish to insert the *part* at a larger or smaller size.

XY Rotation Each *part's rotation relative to the "0°" axis* defined by each *spoke* (rotation center is the *part's origin*). The *default XY rotation angle is 0.0°*. If you wish to *rotate* each *part* by the same angle upon insertion, type in a *new angle between 0 degrees and 360 degrees*. For example, type "45" to *rotate each part 45 degrees counter-clockwise, relative to its spoke*.

Number of spokes The *number of spokes* in the *array*. Parts are radially aligned with each *spoke* upon insertion. Enter an integer value of at least 1 (though in most cases, 1 spoke is a trivial case). *Each spoke in a circular array is evenly spaced from the others.*

Number of rings The *number of rings* in the *array*. The default and minimum (integer) value is 1. *Each ring is a circular array is evenly spaced from the others.*

Angle between spokes The *angle between spokes*. *The default value of the angle is always pre-calculated to space the parts evenly around a full circle.* You may override this value with a different angle to evenly arrange the spokes around a partial circle.

Distance between rings The *distance between rings*. Value ignored if **Number of rings** = 1.

3. Click **OK** to confirm the parameters.
4. The prompt reads "**Array Center:**". To specify the *center point*, pick a point on the screen, or type coordinates.


EasyCAD displays a rubber-band cursor, anchored at the *center point*.

5. The prompt reads "**Insert 1st part at:**". Pick the *insertion point for the first part (on the inner ring of the first spoke)*.

EasyCAD draws the *circular array* and terminates the command.

Text equivalent: **CPARY**

Create Part



CREATE PART saves selected entities from the active drawing as a separate drawing. You can use this command to create a number of parts to use over and over.

To create a part from the current drawing, select [**Insert > Create Part**]:

1. EasyCAD displays the **Create Part Name** dialog box, which is a variant of the standard **Load Drawing** dialog, allowing you to *select* or *create a filename* to which the *part* will be written. Remember that the *part file* will be a standard **.FC7** type file that can be *opened by itself* or *inserted as a part*.
2. Select entities to be included in the *part*.
3. The prompt reads "**Part origin:**". Specify the *part origin* by picking a point or typing numeric coordinates. This is the **(0,0,0)** point for the *new part file*. **EasyCAD will align the new part's origin with the insertion point when you insert the part into another file.** Usually, you will select a point on the lower-left corner or center of the entities to be included in the part.
4. EasyCAD copies the selected entities into the specified file. **If entities you select for the part are already part of a group, they will be assimilated into a new part group when the new part is inserted into another drawing.**

Text equivalent: **CPART**



Group

GROUP combines multiple entities so they act like a single entity. Use **GROUP** to create structures composed of multiple entities that you want to keep together.

Groups maintain a hierarchical (or "nested") structure. As groups are combined, they retain their original identities and member entities (each group is internally assigned a unique number that identifies itself). For example, if two existing *groups* were grouped together and then **UNGROUPEd**, the two original groups would still exist.

Individual entities in a group cannot be edited. Single-entity **EDIT** commands such as **BREAK** or **TRIM** will not operate on entities in a *group*. *Multiple-entity EDIT commands will operate on the entire group, even if some entities in the group are on hidden layers.*

When you *insert parts* with **INSERT PART**, **PART ARRAY**, or **CIRC PART ARRAY**, they come in the drawing as *groups*. You can toggle this behavior using the **OPTIONS** command [Spec > Options]. Remove the check from the box labeled "Group parts on insertion" to prevent this *automatic grouping*.

To break a group temporarily in your drawing Click the *Unlock* button on the *Button bar* so that its label reads "Unlocked". *In this state, all group effects are turned off. Entities behave as if they were never grouped.* Full group effects, including all nested levels, can be restored by clicking on the *Unlocked* button so that its label reads "Locked".

To break a group permanently in your drawing Use the [Insert > Ungroup] command. Each use of **UNGROUP** removes one level of grouping.

To remove all levels of grouping from a grouped entity Use the [Edit > Explode] command. Make sure that you select by "Entity Type" *Part Groups* and not by *All*. When you use the **EXPLODE** command never select entities by *All* unless you really mean to do this. Entities will revert to more basic structures. *Polygons* will become *lines*, *dimensions* will become *lines*, *text* and *polygons* for *arrows* etc.

To determine the hierarchical structure of a nested group Use the [Info > List] command and select the *group(s)* you wish to inspect.

Text equivalent: **GROUP**

Ungroup


UNGROUP breaks up a selected group into its base entities. This effect of **UNGROUP** will be permanent unless it is part of a valid **UNDO** sequence.

If you only wish to *edit an entity in a group*, you should click the *Locked* button on the *Button bar* to temporarily suspend group effects.

When using this command on a *nested group*, **UNGROUP** *removes one level of grouping*. To remove all levels of grouping, use the [Edit > Explode] command. Make sure that you select by “**Entity Type**” *Part Groups* and not by *All*. When you use the **EXPLODE** command never select entities by *All* unless you really mean to do this. Entities will revert to more basic structures. *Polygons* will become *lines*, *dimensions* will become *lines*, *text* and *polygons* for *arrows* etc.

Text equivalent: **UNGROUP**

Sheet commands



Sheets let you store multiple-page drawings in a single .FC7 file. All sheets share common layer/style settings and symbol definitions. Multiple *sheets* can be printed in a single *batch operation*. If you create several pages of drawings and keep them at different locations in one file, *sheets* will significantly speed up your work.

You can also use *sheets* as “**super layers**”, since there is a similarity in concept. Like layers, *sheets* can be *hidden* or *shown*. All entities on each *sheet* are sorted into order by sheet name, back to front.

Because *sheets* contain an entity sub-list that can be *hidden* or *shown*, *sheets* can greatly speed up the handling of large drawings. Entities on *hidden sheets* are *disregarded during entity selections and redraws*. By contrast, layer information is stored as an entity property, so each entity must be processed before it is hidden, shown, or selected. Note that the **LIST** command will display *sheet* membership information.

All **EasyCAD** drawings use the “**common**” *sheet*, as it is the standard, non-sheet drawing. The **COMMON** *sheet* may be selected, but *never hidden as a sheet*.

EasyCAD provides commands to *create*, *rename*, and *delete sheets*.

Managing Sheets

Use the **SHEET** command to display the *Drawing Sheets dialog*. This dialog allows you to *create*, *rename*, and *delete sheets*. Use the checkbox controls to make any one *sheet current*, or to *hide/show any sheet*. The **COMMON** *sheet cannot be deleted*.

There is no practical limit to the number of sheets a drawing can contain (A single drawing can accommodate over 30,000).

Drawing and Editing on Sheets

All new and copy entities are placed on the current sheet.

The special commands **MOVE TO SHEET** and **COPY TO SHEET** let you select entities on any *visible sheet* and either *move* or *copy* them to a *selected sheet*. The *destination sheet* is the one you select in the *Drawing Sheets dialog* (entities can be moved/copied to sheets that are currently hidden).

If you *delete a sheet*, then all entities on that *sheet* are also *deleted*. Be careful; **UNDO** **WILL NOT RESTORE** a *sheet* that has been *deleted*!

Printing Sheets

The **Print Drawing** dialog contains *sheet* commands in the **View to Print** options. The **Sheet** drop down menu lets you specify one of five standard *sheet printing* options:

- **COMMON only** (standard drawing)
- **All visible sheets as overlays** (single page)
- **All visible sheets as separate pages**
- **All sheets as separate pages**
- **The currently selected sheet**




Sheets icon

You can also choose the check box that allows “**common**” entities (those not assigned to any *sheet*) to be printed on each separate page of a multi-page print.

Sheet

Use the **SHEET** command to display the **Drawing Sheets** dialog. This dialog allows you to *create*, *rename*, and *delete sheets*. Use the checkbox controls to make any one *sheet current*, or to *hide/show* any *sheet*. Note that the **COMMON sheet** cannot be deleted.

In the illustration below, the *sheets* **COMMON**, “**Project A Block Text**”, and “**A Electrical**” are visible. The *current sheet* is “**A Electrical**”, so any new entities will be created on this *sheet*.



Drawing Sheets dialog box

Auto hide all sheets except current and COMMON When checked, *only the current and COMMON sheets are visible*. Whenever you choose a *new current sheet*, all others (including the previous current) *are automatically hidden*. If you wish to have *more than one sheet visible* (not including **COMMON**, which is always visible), *this option must be unchecked*.

List Control All *sheets* contained in the *active drawing* are listed here. The **COMMON sheet is always listed first**. Additional *sheets* are listed in the order created, but you may reorder them using the **Move Up** and **Move Down** buttons. *Sheets* will both *draw* and *print* in this order.

The **first column checkbox** indicates the *current sheet*. Choose the *current sheet* by clicking directly on the **first column checkbox** by the *sheet name*. *Only one sheet can be current at any time. The current sheet is always visible.*

The **second column checkbox** indicates the *visible/hidden* state of the *sheet*. If **Auto hide all sheets...** is **ON**, then *only the current sheet and COMMON will be made visible*. If **Auto hide all sheets...** is **OFF**, then *other sheets can be made visible* by clicking directly on the **second column checkbox**. Clicking on the checkbox toggles *hidden “H” (dark background) or visible (white background) states*.

Rename button Choose to *rename* the *selected sheet*. Any *sheet* except **COMMON** can be *renamed*.

Add button Choose to *create a new sheet* in the *active drawing*. The *new sheet* is added to the bottom of the page. **EasyCAD** will not let you duplicate existing *sheet names*. *Sheet names* are not case sensitive, so “abc” is the same as “ABC”. *Maximum length is 63 characters*.

Delete button Choose to *delete* the *selected sheet*. The *sheet name* and all entities on the *sheet* will be erased from the *active drawing*. Use with care, as:


- **UNDO** will **NOT** reverse this operation, and
- Choosing the **Cancel** button will not restore deleted sheets.

Move Up button Choose to *move* the *selected sheet name up one position* in the list. **COMMON** is permanently listed first. **Note: Move Up** and **Move Down** are not undone by **Cancel**.

Move Down button Choose to *move the selected sheet down one position* in the list. **Note: Move Up** and **Move Down** are not undone by **Cancel**.

Text equivalent: SHEET

Move to Sheet



MOVE TO SHEET lets you move selected entities from one sheet to another. The target sheet does not need to be current or visible. The target sheet can be created during the operation.

Like the [Edit > Change > Layer] command, the selected entities are *moved to the target sheet without being displaced*. That is, the entities remain in the same coordinate space, but they are now members of a *different sheet*.

To move entities to another sheet, select [Insert > Move to Sheet...]:

1. Select entities to *move*.
2. EasyCAD displays the *Drawing Sheets dialog*. Select the *target sheet* and click **OK**.

You can create the target sheet at this time by clicking Add.

EasyCAD then *moves* the entity to the *target sheet*, and the command terminates.

Text equivalent: **MOVESHT**

Copy to Sheet

COPY TO SHEET lets you duplicate selected entities to another sheet. The selected entities remain unchanged. The target sheet does not need to be current or visible. The target sheet can be created during the operation.

Like the [Copy > Copy to Layer] command, the selected entities are *copied to the target sheet*. That is, the new entities are duplicated and reside to the same coordinate space, but they are members of a different sheet. You could *hide* one *sheet* and use the **DRAG** command and move the copy to a different location then *show* the *hidden sheet* and the original entity would remain in the original location. These entities may be on the *same layer* but on different *sheets*. Using *sheets* is the only way to have entities residing on the *same layer* and by assigning them to different *sheets*, selectively *hide* and *show these sheets*.

To copy entities to another sheet, select [Insert > Copy to Sheet...]:

1. Select entities to *copy*.
2. EasyCAD displays the *Drawing Sheets dialog*. Select the *target sheet* and click **OK**.

You can create the target sheet at this time by clicking Add.

EasyCAD then *copies the entities to the target sheet*, and the command terminates.

Text equivalent: **COPYSHT**

Symbol commands

A symbol is a named collection of entities that defines a complex object—each symbol acts like a single entity. Like *parts*, *symbols* provide a mechanism for handling repeated elements. To use *symbols*, *create a symbol definition* that **FastCAD** stores in an invisible section of the *active drawing* file. Then you insert copies of the *symbol*, called *symbol references*, throughout the drawing. *Because each reference is only an ghost image of the symbol definition, you can add hundreds of symbols without excessive memory usage.*

Symbol Definitions

- The mathematical representation of the entities comprising the *symbol*.
- Are never visible on the drawing screen.
- Can only be *created* using the **DEFINE SYMBOL** command.
- Can only be *edited* using the **EDIT SYMBOL DEF** command.
- Can be introduced into a drawing by *inserting a part with symbols*. The use of such *symbol libraries* makes *symbols portable* from one drawing to another.
- Can be singularly introduced into a drawing by inserting the *symbol reference* via the *Symbol Catalog viewer*. The use of *Symbol Catalog files* makes symbols efficiently portable from one drawing to another. You only insert *symbols* you want from the *Symbol Catalog viewer*
- Should never be duplicated in a single drawing. Duplications wastes memory and may cause problems when drawings are converted to **DWG** or **DXF** format for use in other **CAD** programs.
- Deleting the *definition will delete all references!* The *symbol references* will no longer appear anywhere on your drawing.

Symbol Reference

- The on-screen “**visible**” representation(s) of the *symbol definition*. The *reference* gets its drawing information *from the definition*.
- Can be inserted by using the **DRAW SYMBOL** command.
- Can be inserted by using the *Symbol Catalog viewer*.
- Always has *an associated symbol definition*. *References* cannot exist without the *definition*.
- There can be more than one *reference* for any *definition*.
- Editing or erasing the *symbol reference* does not affect its corresponding *definition* in any way.
- Can be *rotated*, *scaled*, or *moved*; but you cannot make internal changes without *exploding* the *symbol reference*.
- *Exploding a symbol reference* breaks it down into its component entities. Once a *symbol reference* has been *exploded*, it is no longer dependent upon the *definition*.

Note: Symbols in drawing files imported from other application programs may appear to be ill-behaved. If possible, have the exporting program “**explode**” its *symbols* or “**blocks**” before importing or updating the drawing.

Smart Symbols

When working with **wall networks**, you can use a special type of ‘**smart**’ *symbol*. *Smart symbols* add a level of automated intelligence to *symbol* placement.

Smart symbols, when inserted, *automatically align themselves with the span into which they are inserted*. Also, they can automatically ‘**cut**’ and trim off the *wall upon* insertion.

Smart symbols can be easily created with the simple addition of *control points* to the *symbol definition*. Not only does that permit easy Icreation, but existing *symbols* can also be rapidly converted into ready-to-use *smart symbols*.

Xrefs

When the **XREF** command is used to create a combined drawing file, the *xref file* is actually inserted as a *symbol reference*. In essence, an **XREF** is a *symbol definition stored in another file*. The host drawing simply contains a *reference* that contains the **XREF** file’s *drive, path, and file name*. As long as that information is valid, The **XREF** files will appear automatically when the host file is loaded.

Commands for managing symbols

- **DEFINE SYMBOL** *creates a named symbol definition;*
- **REPLACE SYM REFS** *instructs a symbol reference to use a different definition;*
- **EDIT SYMDEF** *permits modification of a referenced definition;*
- **LIST SYM DEF** *displays or prints a list of symbol definitions;*
- **DELETE SYMDEF** *removes a symbol definition and references to it;*
- **PURGE UNUSED DEFS** *removes unreferenced definitions;*
- **DRAW SYMBOL** *inserts symbol references at any angle or scale.*

To *create a symbol definition*, draw the individual entities, then use **DEFINE SYMBOL** to give it a *name* (up to 31 characters) and an *origin point*. EasyCAD moves the entities that make up the *symbol definition* to the drawing’s invisible *symbol area*, ready to be referenced by **DRAW SYMBOL**.

Symbol definitions are part of the current drawing only. To *share symbols* among several drawings, create a drawing file that contains nothing but *symbol definitions* and save it as a **EasyCAD Symbol Catalog (.FS7)** file. You can then use the *Symbol Catalog viewer* to add the *symbol definitions* and *references* to any drawing.

To *modify symbol references*, create the new *symbol definition*, then use the **REPLACE SYM REFS** to *direct the references to the new definition*.

If *symbols* appear to behave erratically use [Edit > **Explode**] command on them.

Colors and Symbols

By default, symbols will not change colors when you insert them into a drawing. That is, all symbol references will display the same color properties as the definition, regardless of the current color.

However, **symbols** can be defined so that they will appear in the **current color** when inserted. The recommend method is the **Color by Block** method. Before defining a **symbol**, apply the **Color by Block** property to those entities you wish to color update. Do this by using the [Edit > Change > to Color of SymRef] command.

Alternatively, you can use the [Edit > Properties] command and toggle the ‘Change > to color of SymRef’ option. Any number of entities in the **definition** (none, some, or all) can use the **Color By Block** property. Those that do not are “color locked”.


The Symbol Catalog Viewer

EasyCAD provides you with a unique graphical management system for your **symbols**. The **Symbol Catalog viewer** allows you to:

- Access separately maintained **symbol catalog files** (.FC7 files);
- Select and place **symbols** into your drawing with a simple point and click system.

Toggle the **Symbol Catalog viewer** on or off using the **SCREEN TOOLS** command [Specs > Screen Tools] or its icon equivalent.

EasyCAD’s **Symbol Catalog viewer** may be displayed by clicking the the left or right arrow position box in the **Screen Tools dialog box** to display the viewer on the left or right side of the screen.



Define Symbol

DEINE SYMBOL collects entities to make a *symbol definition*.

To *create* a *symbol definition*, select [**Insert > Define Symbol**]:

1. The prompt reads "New Symbol Name:". Type a name then press **ENTER**.
2. The prompt reads "Origin At:". Pick a point that will be used as the *symbol's insertion point*, usually at the lower-left or center of the new *symbol*.
3. Select the entities to be included in the *symbol definition*. After you **Do it**, the newly created *symbol definition* *will disappear*.

Use [**Insert > Draw Symbol**] to create visible *references* to the *symbol definition*.


UNDO brings back the entities that went into the *symbol definition*, but does not un-define the *symbol*! Use [**Insert > List SymDef...**] to see *names* or *pictures* of *symbol definitions* or use [**Insert > Delete SymDef...**] to *erase* a *definition*.

You can create *symbol catalog* .FS7 files for use in EasyCAD's *Symbol Catalog viewer*. A *symbol catalog* is a drawing file that contains only *symbol definitions*. You can create a *symbol catalog* by creating the *symbol definitions* in a drawing and saving it as an .FS7 file. *Symbol catalogs* should use *no grouping and contain noting but symbol definitions*.


NOTE: When you select entities for a *new symbol definition*, you can include *references* to other *symbols*. Keep in mind that *nested symbols* slow EasyCAD down, especially if the *references* are scaled or rotated.

For more help understanding *symbol definitions* and *references*, please see 'Symbol commands'.

Text equivalent: **DEFSYM**




Make Control Points



CONTROL POINTS are added to regular symbols to create “smart symbols”.

Smart symbols work intelligently with **wall networks**, in that both the **symbols** and **wall networks** are aware of each other during insertion. This awareness allows the **wall network** to automatically create **cuts** to accommodate the **symbol**, or have the **symbol align or scale itself to fit cleanly**. Typical uses for **smart symbols** would be doors, windows, etc.



Note that **control points** are invisible after a **symbol** is inserted.

Control points are added to **symbols** *before they are defined*. When creating new **symbols**, just add **control points** as entities and be sure to include them when you select entities during the **DEFINE SYMBOL** phase. If you are working with **existing symbols**, you can use the **EDIT SYMBOL DEFINITION** command to add control points.


To add **control points**, select [**Insert > Make Control Points**]:

The prompt reads “**1st point:**” and then “**Next point [done]:**”. The positioning of these two points is important.

Firstly, the two points define a vector that is used to determine *smart symbol* alignment with the **wall**. During placement, *this vector remains parallel to the direction of the wall span*, reorienting the **symbol** accordingly. This allows a single **smart symbol** to be used for **vertical walls**, **horizontal walls**, or **walls along any bearing!** The alignment vector also tells **EasyCAD** how to “**flip**” the **smart symbol** during insertion.

The two **control points** also define the wall “**cut points**” when the **symbol** is inserted into a wall. The **smart symbol** will cut the wall just as the [**Walls > Cut From**] command would. The wall cuts are capped perpendicularly to the span direction.

Control points are necessary for any **smart symbol**, but you can turn off their ability to align or cut upon insertion using the **Control Points Effects dialog**. This dialog appears automatically after you draw the two **control points**.



Control Points Effects dialog box

Control point effects can only be toggled at this time, before the *symbol* is *defined*. If you need to change the *control point effects* for an *already defined symbol*, you need to place a *symbol reference*, use [Edit > Explode] and select it. Use [Edit > Edit] and select the *control points entity* and change its *effects* from the dialog box then use [Insert > Define Symbol] to *redefine* the *symbol* with a new name.


A *symbol definition* can only contain one pair of valid *control points*.

Align on Insertion Enable this option to auto-rotate the reference upon insertion. The *smart symbol* will only *align* when placed on a linear entity. The two *control points* define the direction of the *smart symbol* alignment.

Cut on Insertion Enable this option to *automatically break* the existing linear entity to accommodate the *smart symbol*. The *break* will occur at the *control points*.

Scale Y to Fit Enable this option to force the *smart symbol* to *resize* in the “vertical” direction upon placement. This resizing is relative to the *width* of the WALL SPAN into which the *smart symbol* is inserted.

You can *define* a *smart symbol* so that it automatically snaps to the *same width* as any *wall*. To do this, the ends of the *symbol* that abut the *wall cut* (where the *control points* go) must be **ONE UNIT LONG**. *Symbols* constructed with **Scale Y to Fit** will scale in the *Y-direction only*. The length in the *X-direction* (the vector defined by the control points) remains constant. This can cause circular entities to distort into ellipses upon insertion.




Keep DynTrack Scale If checked, causes *symbol* to honor *dynamic scaling/rotation* performed during insertion into linear entities. Hold down the **CTRL** key

during insertion to *dynamically scale*. If unchecked, the *symbol* will insert using its defined size. Leave this option unchecked to “**lock**” insertion *size* and *alignment*.

Offset from Place Point Enable this option to *insert* the *symbol parallel* to the initial placement point and orientation. The exact placement is visually determined from the dynamic cursor. This overrides the *Cut on Insertion* *check box* option (i.e., *offset symbols will not cut the locating entity*).

Text equivalent: **CTRLP**

Replace Symbol References



*The **REPLACE SYM REFS** command redirects all symbol references pointing to one definition to use a new definition instead.* This command is particularly helpful when *symbol references* must be updated to reflect changes to the *symbol definition*.

Before using the **REPLACE SYM REFS** command, the *target symbol definition* must already exist in the drawing.

To use the **REPLACE SYM REFS** command, select [**Insert > Replace Sym Refs..**]:

1. The *Symbol to be Replaced* dialog box appears. Select the *symbol references* you want to change by selecting the corresponding *symbol definition*. (**Remember that you are not actually changing the symbol definition; you are simply redirecting the symbol reference from one symbol definition to another.** In this step, you are choosing the "from" *symbol definition*.)
2. The dialog box title now reads *Replace with Symbol*. Select the *new symbol definition* (the "to" *definition*).
3. EasyCAD redraws the *old symbol references* using the *new symbol definition*. Use the **UNDO** command to *revert back to the original symbol definition*.

EasyCAD updates all *symbol references* with the *new symbol definition*.

EXAMPLE: Suppose you have a *symbol* of an office chair in your drawing named **CHAIR01**, and that there are twelve *references* in your drawing (meaning you can see twelve chairs). Now you want to change these chairs to a new style, keeping their positions and orientations as they are. The new style is defined in the *symbol* **CHAIR04**.

Use the [**Insert > Replace Sym Refs..**] command, selecting **CHAIR01** in the *Symbol to be Replaced* dialog box, then selecting **CHAIR04** in the *Replace with Symbol* dialog box. All twelve *symbol references* that previously showed **CHAIR01** now display **CHAIR04**.

In the above example, **CHAIR04** must have already been defined in the drawing. This could have been done by previously inserting a **CHAIR04** *symbol* from the *Symbol Catalog* viewer. Or you could have drawn the **CHAIR04** from scratch. You might have also **EXPLODED** a **CHAIR01** *reference*, edited it (e.g., by adding a chair back), then used the **DEFINE SYMBOL** command to create the **CHAIR04** *symbol*, taking care to select the same *symbol origin*.

NOTE: Any *symbol references* you previously **EXPLODED** to their basic entities will not be updated. *Exploding* disassociates the entities from the *original symbol definition*.

NOTE: *References to symbol definitions that are nested under a different definition will not be affected by REPLACE SYM REFS.*

Text equivalent: **REPSYM**


List SymDef

LIST SYMDEF provides information about symbol definitions available in the *current drawing*. A dialog box identical to the *Select Symbol* dialog box is displayed. Select a *symbol* and the component entity information is displayed in a text window.

Text equivalent: **LISTSYM**

Delete SymDef

DELETE SYMDEF deletes an individual symbol definition. If the *active drawing* contains *symbol references* to the *deleted definition*, the *references* will also be deleted.




EasyCAD will warn you before proceeding with the alert box as seen above.

This command displays the *Select Symbol* dialog box. It is identical to the *Select Symbol* dialog box except that selection *deletes the symbol definition* and *all references* to it.


Use **UNDO** to reverse the effects of this command.

For more help understanding *symbol definitions* and *symbol references*, please see **Symbol** commands.

Text equivalent: **DELSYM**



Purge Unused Symbol Definitions



*The **PURGE UNUSED DEFS** command removes all unused symbol definitions from the current drawing. An unused symbol definition is one that does not have any corresponding symbol references.*

PURGE UNUSED DEFS does not affect symbol references or referenced definitions in any way.

This command is helpful for maintaining an efficient drawing file when **symbols** are frequently used. Unused **symbol definitions** sometimes propagate and accumulate, often inadvertently, possibly hindering **EasyCAD**'s performance and inflating file sizes. For instance, if you insert a **part** that contains **500 symbols and make use of only one of those symbols, the other 499 definitions remain as "excess baggage"** in the drawing file! The **PURGE UNUSED DEFS** command will easily remove them from the drawing in one step.

To use the **PURGE UNUSED DEFS** command, select [**Insert > Purge Unused Defs**], or type **PURGESYM** at the command line.



Note: **UNDO** will **NOT** work with this command; so be sure that you can reintroduce or re-create any un-referenced symbol definitions that you might again need in the future.

For more help understanding **symbol definitions** and **references**, please see **Symbol** commands.

*Text equivalent: **PURGESYM***

Load Part as SYMDEF..

*The LOAD PART AS SYMDEF command lets you load a drawing or part file as a symbol definition. Use this command to quickly create **FS7** symbol catalog files from stored **part** drawings.*



Load Symbols from Files dialog box

When you start the command, **EasyCAD** prompts you from the **Load Symbols from Files** dialog to enter a full path name and filename pattern, or a single filename. The use of the * or ? **wildcards** are supported. For instance, “\mylib*.fc7” will load all files in the \mylib directory. The appropriate filename extension must be entered if you are loading non-**.FC7** files (**EasyCAD** will convert the files “on the fly”). *If no extension is specified, **.FC7** is assumed. If no path is specified, then the EasyCAD working directory is assumed.*

Browse button

If you click the **Browse** button in the **Load Symbols from Files** dialog, the **Browse for Folder** dialog will open allowing you to visually select a folder that contains the drawings you want to load as **symbols**. When you click a folder it will appear in the **Load Symbols from Files** dialog with the default *.FC7 file extension. If you click **OK** the entire folder of **.FC7** files will be loaded and converted to **symbols** in the **active drawing** file. You can use wildcard characters instead of the * character if desired.

When a **part file** is loaded, it is loaded as a **symbol definition**. It is not loaded as a visible **reference**. *Each part's filename becomes the symbol name, and its (0,0) point is the symbol origin or insertion point handle.*



To see or verify the loaded **symdefs**, use the **LIST SYMBOL DEF** command [**Insert** > **List Symdef**]. If the **Symbol Catalog** viewer is on, click the **Dwg Syms** button below the **Catalog** button to view the **Symbols** you just loaded into the **active drawing**.

Wildcards can only be used for the filename, not the directory name. If you are loading multiple parts from different directories then **LOAD PART AS SYMDEF** must be run once for each directory.

This command can be run directly from a **macro** or **script**. The **path/name** is taken directly from the code; the dialog display is suppressed.

*Text equivalent: **LDSYMDEF***

Insert > Change All SymDefs > Scale All Defs



INSERT > CHANGE ALL SYMDEFS > SCALE ALL DEFS allows you to scale all symbol definitions in the current drawing by a specified factor. The definitions are scaled about their origin.

Existing *symbol references* that point to the *definition* are not rescaled, but they will reflect the scale changes made to their respective *definitions*. Existing attributes are not scaled; that is, the existing *symbol reference* attribute text height and location do not readjust. *References* inserted after **CHANGESS** will properly locate and scale.

This command can be helpful in symbol catalog maintenance. For example, you may have a *symbol catalog* containing 150 schematic symbols. However, in order to be useable in the units you draw, they need to be scaled up 2x. Rather than using **EDIT SYMBOL DEF** 150 times for each symbol, apply the **CHANGESS** scale once (using a factor of 2.0), and **SAVE AS** the catalog file.

To change the *symbol scale*, type **CHANGESS** at the command line or select [**Insert . Change All SymDefs > Scale All Defs**]:



The symbol definitions update and the command terminates.

This command is useful for managing **FS7 symbol catalog files**. To change the colors in a catalog, you must first load the catalog file itself as a drawing, then apply the command. **CHANGESCB** only affects the *symbol definitions* contained in a drawing, not those in the catalog displayed in the viewer.

Use **UNDO** to reverse this command.

Text equivalent: **CHANGESS**

Insert > Change All SymDefs > Change All Color



INSERT > CHANGE ALL SYMDEFS > CHANGE ALL COLOR allows you to *change all symbol definitions in a drawing to a selected color. Any references in the drawing will automatically update to reflect the new color.*

To change all symbol definitions color, type "**CHANGESC**" at the command line or select [**Insert > Change All SymDefs > Change All Color**]

Select a *new color* by choosing a *Color bar* or palette color, or typing in a color number.

This command is useful for managing **.FS7 symbol catalog files**. To change the colors in a catalog, you must *first load the catalog file itself as a drawing*, then apply the command. **CHANGESC** *only affects the symbol definitions contained in a drawing*, not those in the catalog displayed in the viewer.



To see which *symbols* are contained in the drawing, and which are in the catalog, press the **Catalog...** or **Dwg Syms** button at the top of the viewer.

- When **Dwg Syms** is **OFF** (not depressed), the *catalog symbols* are displayed. These are not affected by the [**Insert > Change All SymDefs > Change All Color**] command.
- When **Dwg Syms** is **ON** (depressed), the *symbol definitions in the drawing* are displayed. These will be affected by the [**Insert > Change All SymDefs > Change All Color**] command.

Use **UNDO** to reverse this command.

Text equivalent: **CHANGESC**

Insert > Change All SymDefs > Change All Color by Block



INSERT > CHANGE ALL SYMDEFS > CHANGE ALL COLOR BY BLOCK allows you to change all symbol definitions in a drawing to Color by Block. Any references in the drawing will automatically update to reflect the By Block color. References already in the drawing will change to the color current during insertion (this can be determined by using the **LIST** command). Symbol references that you add will use the current color.

If you want to change only a *single symbol definition* to use **By Block** color, use the **CHANGESCBB** command [**Edit > Change > to Color of SymRef**].

Note that this command is not in any standard menu. You must type “**CHANGESCBB**” at the command line prompt to invoke the command.

To change all drawing symbol definitions to color by block, type “**CHANGESCBB**” at the command line or select [**Insert > Change All SymDefs > Change All Color by Block**]:

The symbol definitions update and the command terminates.

This command is useful for managing **FS7 symbol catalog files**. To change the colors in a catalog, *you must first load the catalog file itself as a drawing*, then apply the command. **CHANGESCBB** only affects the symbol definitions contained in a drawing, not those in the catalog displayed in the viewer.


To see which *symbols* are contained in the drawing, and which are in the catalog, press the *Catalog* or *Dwg Syms* button at the top of the *viewer*.

- When **DWG SYMS** is **OFF (Not depressed)**, the *catalog symbols* in the external **.FS7** file are displayed. These will **NOT** be affected by [**Edit > Change > to Color of SymRef**] command.
- When **DWG SYMS** is **ON (Is depressed)**, the *symbol definitions* in the *active drawing* are displayed. These **WILL** be affected by [**Insert > Change All SymDefs > Change All Color by Block**] command.

Use **UNDO** reverse this command.

Text equivalent: **CHANGESCBB**

Insert > Change All SymDefs > Change All Layers



The CHANGE ALL LAYER command allows you to change the LAYER of ALL ENTITIES IN ALL SYMBOL DEFINITIONS in the active drawing to a DIFFERENT LAYER that you select.

ALL ENTITIES in ALL SYMBOL REFERENCES in the drawing will AUTOMATICALLY UPDATE to reflect the NEW LAYER assignments.

This means that if you HIDE the LAYER that you select with this command, ALL SYMBOL REFERENCES will disappear from the drawing screen.

The previously inserted SYMBOL REFERENCES will remain on the LAYER that was current at the time that they were inserted.

Using this command on your .FS7 SYMBOL CATALOG FILES is a good way to keep the SYMBOL REFERENCES behaving in a consistent manner after inserting them into a drawing from the SYMBOL CATALOG VIEWER.

NOTE: You should NOT use this command if you purposely have entities on DIFFERENT LAYERS in the SYMBOL DEFINITIONS that you want to selectively HIDE and SHOW.

1. To change the LAYER of ALL ENTITIES in ALL SYMBOL DEFINITIONS in the current drawing on your screen, select the [Insert > Change All Sym Defs > Change All Layer] command.

The prompt reads: 'Layer name or # [dialog:]'



2. Right-click to display the 'Layer Management' dialog box and left-click on the desired LAYER NAME.

Now ALL of the ENTITIES in ALL SYMBOL DEFINITIONS that you have inserted into the drawing on your screen will be associated with the LAYER you select.


As long as that LAYER is VISIBLE, as well as the LAYER each SYMBOL REFERENCE resides on, the entities in the SYMBOL REFERENCES will be VISIBLE.

Text equivalent: CHANGESLYR

Draw Symbol



DRAW SYMBOL adds a symbol reference to your drawing. A symbol reference is a ghost image of a symbol definition that you have stored in the invisible symbol area of your drawing. Invoking the command displays the *Select Symbol* dialog box:



The illustrated *Select Symbol* dialogs display identical information in different ways. The dialog on the left has the **Display symbols** option switched **ON** (located at the bottom of the dialog). This graphical display mode can only display seven symbol thumbnails per page (use the vertical scroll bar to see more or the scroll wheel on a mouse). The dialog on the right has **Display symbols** switched **OFF**. Only symbol names are displayed. In list mode, twenty-four names can be displayed per page.


To insert a symbol, select a symbol from the list. EasyCAD displays a ghost image of the symbol. You can dynamically scale or resize the image before positioning when the prompt reads “(CTRL=scale CTRL+SHIFT=rotate) Origin/Scale [INS=specs]”.

(CTRL=scale CTRL+SHIFT=rotate) Origin/Scale [INS=specs]:

- To **scale** the symbol, type a scale factor like “2” or “.5”.
- To **dynamically scale** the symbol, press **CTRL** and move the mouse..
- To **dynamically rotate** the symbol, press **CTRL+SHIFT** and move the mouse
- Press the **INS** key on the keypad the *Insert Parameters* dialog box. Set the **Scale** and **rotation angle** and click **OK**. The symbols inserted from this point will use these values. The **symbol name** is also displayed in dialog box.

If you want to change the **scale** of the original you may immediately type a **new scale factor** such as “2” to make the symbol twice as large. If you press the “**Ins**” key on the keypad, EasyCAD displays the *Insert Parameters* dialog box with the **default Scale factor** and **XY Rotation Angle** of the symbol. You may adjust both **symbol scaling** and **rotation** from this dialog box. All symbols inserted from this point will use these default values. The **symbol name** being inserted is also displayed in this dialog.

- The *default scaling is 1.0* (same size as the original symbol). Type in a *new scale factor* if you wish to insert the *symbol* at a *larger* or *smaller* size.
- The *default XY rotation angle is 0.0°*. If you wish to *rotate* the *symbol* upon insertion, *type in a new rotation between 0 degrees and 360 degrees*. For example, type “45” to *rotate the symbol 45 degrees counter-clockwise*.



Insert Parameters dialog box

To insert the *symbol reference*, pick a point in a drawing window. The *insertion point* of the *symbol* (its **0,0 Origin**) aligns exactly with the point you pick. You may continue to insert the same *symbol reference* by picking new points, or right-click to end insertion.

NOTE: Although **EasyCAD** doesn't have specific commands for drawing *symbols* in rectangular or circular arrays, you can do this very easily—just insert one *symbol*, then select **Prior** for the **COPY** or **ARRAY** commands.

*Text equivalent: **INSSYMD***

Define Attribute

*Attributes are pieces of information (text labels) you attach to symbols for later use. They act as **symbol** parameters or **references** that you might find useful for times when you are working with a database. **Attribute** definitions are contained in every **symbol**.*

Once you've drawn the entities that will eventually be your **symbol**, you'll need to define the symbols and attributes to recall it for later use.


1. Select [**Insert > Define Attribute**]. The “Text Attribute” dialog box appears with three options to *define* the *attribute*:
 - Tag text is the attribute definition or the per instance name of your **symbol**. You can change the *tag* or use its default before placing each **symbol**.
 - Prompt text is the constant name or *definition* of your **symbol**. Once you enter prompt text, you cannot change it.
 - Default value is the value you give your **symbols**. You can change the value or accept the default before placing each **symbol**. Values can be the same for all of your **symbol references**.
2. Review the three check boxes for defining attribute specifications. The checkboxes are:
 - **Hidden**: Checking this hides the text.
 - **Constant**: If this is checked, it means the values are unchanged.
 - **Display Tag**: Gives you the option to display the tag or value in your drawing.
3. Enter the **Tag text**, **Prompt text** and **Default value** for your symbol.
4. Select **Text Properties** if you want to change *text attributes* such as height, justification, etc.
5. Now select [**Insert > Define Symbol**] and type in a name for your **symbol**.
6. Select an insertion point with the crosshairs and left button or by typing in coordinates.
7. Select [**Insert > Draw Symbol**] and the *Attribute Reference dialog box* appears. Select the **symbol** you want to place. (**You can change the tag or value before placing each symbol**)
8. Drag the **symbol** dynamically and left-click to place it.
9. Continue placing as many **symbols** as you like. Right-click to stop placing **symbols**.

Text equivalent: ATTRIB


Extract Attributes

EXTRACT ATTRIBUTES, like **LIST** in the *Info menu*, acts as a “**reveal codes**” function by displaying a list of all of your **symbols** and their attribute values.

Text equivalent: EXTRACT



Insert Picture



Use **INSERT PICTURE** command to display a *bitmap image* .BMP file in your drawing. The image will appear in the rectangle you draw on the screen (**just like using the **BOX** command**). To draw the box, when prompted left-click to pick two diagonal corner points in the drawing window, or type **numeric coordinates**.

The **current fill style** has no bearing on the appearance of the **inserted picture**.


However, the image entity does acquire the current drawing properties. This may be a factor when selecting entities by **color**, **layer**, **fill style**, etc.

EasyCAD does not embed the image into the drawing. Instead, a **dynamic link to the actual .BMP file is maintained**. If you intend to **copy** or **move** an **.FC7 drawing containing images, remember to also copy or move the .BMP files as well**. You can minimize conflict by **copying** or **moving** the .BMP files into the same folder as the drawing that will use them before you even insert it into it. If a drawing is loaded and the **.BMP image file does not exist or cannot be found, EasyCAD displays an empty box**.

When you select this command, **EasyCAD** displays the **Select bitmap for picture dialog box**, allowing you to select the desired .BMP file. **EasyCAD** then displays the **Picture Options dialog box**.

To **Insert a Picture** into your drawing type the **PICT** command [**Insert > Insert Picture**] or select it from the **INSERT** menu.

1. Select a .BMP file from the **Select bitmap for picture dialog box**. After you select the .BMP file, the **Picture Options dialog box** opens.



Picture Options dialog box

Stretch to Fit (may distort)

**Frame drawn at exact image aspect ratio
(not distorted)**



**Frame not drawn at exact image aspect ratio
(distorted)**

The option *squeezes* the **.BMP image vertically** and **horizontally** so that it *fills the picture frame*. The image conforms to *aspect ratio of the picture frame you draw*. If you know the **exact dimensions of the .BMP file, x" by y" inches**, you can draw the *picture frame* this *exact size* and the **image will not distort**. *The picture frame is the proper aspect ratio*. Load the **.BMP** image into a program such as **Coral Photo Paint** and select the **PROPERTIES** command to see what the *dimensions of the scanned image* are.

After you have drawn the *picture frame the exact size of the scanned image*, you can use one of the **SCALE** commands to enlarge it. Remember you are displaying a *bitmap image composed of dots* so at some point it will look very blocky and be unusable. Experiment to see what works best for you. The images above were scanned at **72dpi** and **250 lpi**.

Align Top Left & Clip

The option *aligns the .BMP images upper left corner* to that of the *picture frame* and retains its original size. If the image is smaller than the *picture frame*, the blank area will opaquely fill with the background color.

Using this option, you will draw the *picture frame to fit the scanned image* since the pixels are not being scaled to fit inside the *frame*. The higher the resolution the larger the image will be when viewed on the drawing screen.

EXAMPLE: If you scanned an area that is **4" x 4"** at **75 dpi**, the image would be **75 x 4 = 300 pixels by 300 pixels**. If your video resolution is **1024 pixels horizontally**, the image would *cover about 1/3 of this horizontal screen area*. If the screen resolution is **768 pixes vertically**, the image would cover almost *1/2 of the vertical screen area*. If you scanned the **4" x 4"** area at **300dpi**, the image would be **300 x 4 = 1200 pixels by 1200 pixels**. This means that a **1024x768 resolution screen** would be totally covered. The *Align Top Left & Clip* method would not work. *The picture frame would be blank*. Usually scanning at **75dpi** is sufficient for this type of application.

Scale to Just Fit Inside



The image *scales* itself to fit entirely within the *picture frame* without clipping. The image will maintain its original aspect ratio, regardless of that of the *picture frame*. Any blank area in the box will appear transparent, and is only visible when **Hide Picture Outline** is off.

Scale to Just Cover



The option *scales* the image so there is no blank area in the *picture frame*. The image *scales itself just large or small enough so that the entire picture frame* is filled, clipping as needed. The image is centered in the box.

Tile to Fit and Clip



The image *maintains its original size and aspect ratio*, and will repeat itself within the *picture frame*, as to fill it. The "**start**" image aligns to the top left corner. Bottom and right border images will clip as needed.

Hide Picture Outline

When you draw the *picture frame* it uses the current color in the *active drawing*. If you check this box the *picture frame* will not appear on the screen.

2. Select a method for fitting the **.BMP** image into the *picture frame* and the prompt reads “**First corner:**”. Left-click to place the first corner of the *frame*

The prompt reads “**Opposite corner:**”. Left-click again to place the opposite corner of the *picture frame*

Force Frame to Bitmap Aspect Ratio

Checking this box ensures that the image will not distort but *it retains its original size as scanned* and may be too large to view on screen. If the *picture frame* is blank, this is the case. You must use one of the methods that *scales* the image to the *picture frame*.

Use copy of bitmap contained in drawing

The data contained in the **external .BMP file will become part of the drawings data**. This will increase the file size accordingly. If the **.BMP file is 200kb** and there is more than one instance of this same **.BMP** placed in the drawing, each placement **increases the drawing file size by 200kb**.

Advantages of including a copy of the .BMP data in the drawing

The **ADVANTAGE** of storing the **.BMP** data in the drawing file makes it portable. No matter where the drawing gets moved to or copied to, the **.BMP image** will always appear in the Picture Frame.

Disadvantages of including a copy of the .BMP data in the drawing

The **DISADVANTAGE** is that the **drawing file size is much larger when the .BMP data is stored in it** instead of just pointing to the **external .BMP file** and displaying the image in the **Picture Frame**. Another method is to always store the **.BMP files** on the *same drive* and *in the same folder* and the link to the **.BMP** can always be found as long as the drawing is on a **LAN** or on the same computer as the **.BMP** that it references. If you email a drawing with a **.BMP image** you should always use this method unless you also email the **.BMP file** separately and both it and the drawing that references it are stored on the *same drive* and *the same folder name* as the originals were.

Email file attachment file size limitations

If you email a drawing with a **.BMP file as part of the drawing file data**, the file may be too large to attach to the email. Many internet providers have a **maximum email file attachment size limit of less than 3MB**. If the file you attach to the email is too large the email will be rejected. You should contact the person you are emailing the drawing to and determine what the **email file attachment size limit is** for their internet provider.

NOTE: If the **.BMP** files are **ERASED** or **MOVED** to another **DRIVE** or **FOLDER** only the **PICTURE FRAME** will be displayed in the drawing unless you use the 'Use copy of bitmap contained in drawing' option.


Use the **[Edit > Edit]** command and select the edge of the **PICTURE FRAME** and select the **DRIVE** and **FOLDER** where the **.BMP** file is now located and it will be displayed again. If you send another **EasyCAD7/FastCADv7** user a drawing with a **.BMP** in it you will need to send them the **.BMP** file also. These **.BMP** **PICTURES** **DO NOT** convert to **AutoCAD .DWG** or **.DXF** files.

*Text equivalent: **PICT***

Specs Commands

Set-up and configure EasyCAD to the way you work

The **Specs (Specifications)** menu controls some of **EasyCAD**'s precision drawing features like **Grids**, **Frames**, and **Crosshairs**. Other commands set formats and styles for entities, text, and dimensions.



Grid button OFF




Grid button ON

Grids are drawing aids that help you visually scale, position, and orient entities in your drawing. They appear on your drawing screen as a series of evenly spaced white dots. Though you can edit their spacing properties, the grid dots themselves cannot be edited (they are *not* point entities). This “always frozen” property ensures that grids will not be inadvertently altered or moved. Toggle grid display using the **Grid button** on the **Button bar**.

Use **crosshairs** when you want more visual detail when you move the cursor. By default, **EasyCAD** displays either a pointing cursor (arrow shaped) or a pick box, depending on the context. **Cursor Crosshairs** add **horizontal** and **vertical tracking lines** to both standard cursors.

Grids, **Cursor Crosshairs**, and **Spline Frames**, are all toggled on in the illustration below. These and other options may be toggled or tailored through commands you find in the **Specs menu**.




Select Grid

Selecting the **SELECT GRID** command from the **SPECS** menu displays the *Select Grid System dialog box* with options that control the *grid system*. You may also right-click over the *Grid*, *Ortho*, *CsrSnap* or *Snap* buttons to open the *Select Grid System dialog box*. *Grids* are classified as rectangular, circular, or angular (angular grids are rotated rectangular grids). Horizontal and vertical *grid spacing* may be set independently. You may edit existing grids to create new grids, allowing for even greater control of your drawing environment. **EasyCAD** has one *rectangular grid*, one *15 degree circular grid* and one *30 degree angular grid* already set up for you to use. They can be edited, modified, even renamed, but these two can not be deleted.

You can type *grid names* containing spaces on the command line when using the **SGRID** command (press ENTER to invoke the command). *Grid* definitions are saved with each drawing file.

Select Grid System dialog box



Dialog Options **List Window** Pick one of the pre-defined grids or a grid that you have defined. If you click **OK**, the selected grid will become current.

Grid Class **EasyCAD** currently supports three classes of grids:

- **Rectangular**
- **Circular**
- **Angular**
- **Hexagonal**

Buttons **New** Creates a new grid system. You will first be asked to create either a rectangular, circular, or angular grid system. The corresponding *Edit Grid System dialog* will then appear, allowing you to edit values.

Edit Allows you to modify the **highlighted grid system**. The appropriate *Edit Grid System dialog box* is displayed.

Delete Deletes the highlighted grid system. Note that the default grid system "Standard Rectangular" cannot be deleted.

Rename Renames the highlighted *grid system*. Type a new name in the *Rename Grid System dialog*.

Switches Grid Displays a regular pattern of grid dots to help you keep track of distances and sizes. The dots are only a visual aid and are not part of your final drawing. Toggle the display mode with the *Grid button*.

Snap Forces point picks to regular intervals you specify. Toggle the snap mode with the *Snap button*, or by typing **SNAPON** and **SNAPOFF** at the prompt.

Cursor snap Forces cursor motion to *snap points*. Applies only if *Snap* is on. When snap locking is on, cursor snap makes cursors "jump" to snap points instead of moving smoothly over the screen. Toggle the cursor snap mode with the *CsrSnap button*.

Ortho Forces new lines or displacements to be horizontal or vertical. Toggle the ortho mode with the *Ortho button*.

Text equivalent: **SGRID**



Ortho button
When you use ortho
with an angular grid,
"horizontal" and
"vertical" are aligned
with the grid.

Align Grid

Use the **ALIGN GRID** command to reset visual alignment of the grid dots. The grid dots shift so that a grid dot coincides exactly with an alignment point you specify. This command does not reset the origin point (0,0,0) of the drawing. The drawing coordinates do not change; only the visual grid is shifted.

You can also use **EGRID [Specs > Edit Grid]** to enter a new alignment point. The coordinates are stored as the Grid center parameter in the *Edit Grid dialogs*.

To **align the grid**, select [Specs > Align Grid]:


The prompt reads "Align grid on point:". To specify a new *alignment point*:

- Right-click or press **ENTER** to accept the default or prior value;
- Pick a point in a drawing window;
- Type numeric coordinates and press **ENTER**.

EasyCAD aligns the *grid* with the point you specified.

Text equivalent: **AGRID**

Angle Grid



The grid on the left displays a typical 10° square grid. The grid on the right is an Angled Rectangular class grid, set to 30°.

Use the **ANGLE GRID** command to realign the current angular grid. You can either input a value (in standard decimal or dms format) or visually specify an alignment, using the mouse. *Ortho* locks to the *grid* orientation.

ANGLE GRID *only works if an angular-type grid is current.* If you attempt to rotate an **invalid grid** (rectangular or circular), EasyCAD displays a message box stating, “The currently selected grid is not an angular grid”. If the **grid** you are rotating is not visible (*Grid button off*), it will be automatically shown after the rotation (*Grid button on*).

To set the **grid angle**, select [**Specs > Angle Grid**]:

The prompt reads “**Bearing to +X:**”. You can:

- Type in a bearing, then right-click or press ENTER;
- Define a bearing by clicking two points on the screen.

EasyCAD *angles* the *grid* with the *angle* you specified.

Text equivalent: **GRIDANG**

Edit Grid

EDIT GRID allows you to re-specify any parameter for any grid system in the drawing.

EasyCAD displays a different *Edit Grid System dialog box*, depending upon the type of *Grid System* being modified or created:

- **Rectangular**
- **Circular**
- **Angular**
- **Hexagonal**

Editing Rectangular Grids



Edit Rectangular Grid System dialog box


Dialog Options **Align grid on point:** The **origin point (0,0,0)** of the **grid** can be different than the **(0,0,0)** point set by the **CHANGE ORIGIN** command [View > Change Origin]]. Can be visually specified using the **ALIGN GRID** command.

Snap divisions Number of snap points per grid unit (integer value).

X/Y Spacing Distance between grid dots in each axis direction. These values are displayed in the current distance display format.

Even sides Forces all Spacing values equal, resulting in a square. Click off **Even sides** to allow different values for **X** and **Y Spacing**.

TriGrid *TriGrid* is useful for creating isometric drawings. It creates a special grid that you can use to draw entities at **60°**. **EasyCAD** prompts you for horizontal spacing, which you can set with any of the usual methods. **EasyCAD** then calculates the vertical spacing and displays the grid dots.




TriGrid

TriGrid creates a special grid that you can use to draw entities at **60°**. Enter the **horizontal spacing only** (into the **Spacing field**). **EasyCAD** then calculates the vertical spacing.

Use **SNAP** to ensure that you are drawing in **angle increments of 30° and 60°** for drawing **ISOMETRICS**.

Editing Circular Grids

The '*Edit Cylindrical Grid System*' dialog box is displayed when a **circular/cylindrical grid** is selected for editing, or when creating a new **circular/cylindrical grid**.



Edit Cylindrical Grid System dialog box

Dialog Options

Align grid on point: The origin point (0,0,0) of the grid can be different than the (0,0,0) point set by the **CHANGE ORIGIN** command [View > Change Origin]. Can be visually specified using the **ALIGN GRID** command.

Snap divisions Number of snap points per grid unit (integer value).

Angle delta Angle (in degrees) between spokes in the cylindrical grid pattern.

Angle offset Bearing of the first spoke in the grid pattern. The Angle delta is maintained for the remaining spokes.

Radial delta Distance between rings in the cylindrical grid pattern.

Editing Angular Grids

The ‘*Edit Angular Grid System*’ dialog box is displayed when an *angular grid* is selected for editing, or when creating a new *angular grid*.




Edit Angular Grid System dialog box

Dialog Options **Align grid on point:** The origin point (0,0,0) of the grid can be different than the (0,0,0) point set by the **CHANGE ORIGIN** command [View > Change Origin]. It can also be visually specified using the **ALIGN GRID** command by picking a point with the mouse.

Snap divisions Number of snap points per grid unit (integer value).

X/Y Spacing Distance between grid dots in each axis direction. These values are displayed in the current distance display format.

Even sides Forces all Spacing values equal, resulting in a square. Click off **Even sides** to allow different values for X, Y, and Z Spacing.



The grid seen above is an Angled Rectangular class grid, set to 30°.


Text equivalent: **EGRID**

Editing Hexagonal Grids

EasyCAD v7 has a unique **Hexagonal Grid System**. The **HEX GRID CELL** allows you to draw **Lines at angle increments of 30 degrees**. This makes it easy to draw **isometrics**.

Selecting a Hexagonal Grid System

To select a **HEXAGONAL GRID SYSTEM** place the mouse cursor over the **GRID** button and right-click to open the '**SELECT GRID SYSTEM**' dialog box as seen below and click the '**1 unit vertical hex grid**'.





A **HEX GRID SYSTEM** is orientated either **VERTICALLY** or **HORIZONTALLY** depending on the setting in its **EDIT HEX GRID SYSTEM dialog box**.

Vertical HEX Grid cell Orientation

VERTICAL cell orientation for a **HEX GRID** system means that **2** of the **6** parallel sides of the **HEX GRID** cell are **VERTICAL** in the **Y** drawing axis. The default **GRID SPACING** for **VERTICAL** cell orientation is set to a cell size **WIDTH** of **1.00000** and a **HEIGHT** of **1.15470** automatically, which is the proper value to maintain the proper settings for the **HEX GRID** to have six equal and parallel sides.

The **WIDTH** value is measured **HORIZONTALLY** between the mathematical centers of each adjacent **GRID** cell. The distance between cell centers should be changed to make the cell larger or smaller NOT the **VERTICAL** distance across the cell between two **NODES**, which would be the **HEIGHT** of **1.15740** when the **HEX GRID** spacing is set to **VERTICAL**. See the example below for **VERTICAL** settings for the **HEX GRID** cell.

WIDTH and HEIGHT measurements for VERTICAL HEX Grid Orientation





Horizontal HEX Grid cell Orientation

HORIZONTAL cell orientation means that 2 of the 6 parallel sides of the HEX GRID cell are **HORIZONTAL** in the X drawing axis.

The default **GRID SPACING** for **HORIZONTAL** cell orientation is set to a cell size **HEIGHT** of 1.00000 and a **WIDTH** of 1.15470 automatically, which is the proper value to maintain the proper settings for the **HEX GRID** to have six equal and parallel sides.

The **HEIGHT** value is measured **VERTICALLY** between the mathematical centers of each adjacent GRID cell. The distance between cell centers should be changed to make the cell larger or smaller **NOT** the **HORIZONTAL** distance across the cell between two **NODES**, which would be the **WIDTH** of 1.15740 when the **HEX GRID ORIENTATION** is set to **HORIZONTAL**. See the example below for **HORIZONTAL** settings for the **HEX GRID** cell.

WIDTH and **HEIGHT** measurements for **HORIZONTAL** HEX Grid Orientation



Select Color



Select Color icon


EasyCAD provides you with a number of mechanisms for quickly changing the working (**active**) color. Usually, the quickest way to change the working color is to click directly on the **Color bar**. The working color is displayed on the **Color icon**. To quickly activate a color from the **256-color palette**, you can click directly on the **Color icon**.

SELECT COLOR command [**Specs > Select Layer**] allows you to select the new active drawing color or modify the color palette. When selecting this command from the menu, you may elect to:

- Type a color number and press **ENTER**;
- Pick a color from the **Color bar**;
- Right-click to display the **Select Color dialog box**.

The quickest way to change your active drawing color is to select it from the **Color bar**. You can always change colors while in the middle of another command. Use the **SELECT COLOR** command only to adjust the palette, create new colors, or select a color that does not fit on the **Color bar**.

When you need to select a color from the larger **256-color palette**, choose it from the **Select Color dialog box**.



Select Color dialog box options

Dialog Options **Palette** Click on any color to make it the active drawing color.

The **Color palette** is a collection of colors stored together for easy access. The palette can be customized using the other buttons on the dialog box.

Each color on the palette is assigned a number **0-255**. Redefining a color will

change the appearance of all entities drawn in that color number.

Some colors numbers have special significance or uses:

0-23 appear on the color bar

16-20 are **system colors** extracted from the **Windows Display Properties**, Appearance settings. Modifying these colors in this dialog box will only affect the **EasyCAD** display environment. They will *not* affect the appearance of Windows or other applications.

Specific color assignments:

16 button face color

17 button text color

18 button shadow color

19 list paper background

20 prompt text

31 is the “**no change**” color. Entities drawn using this color will be drawn in the same color as the prior entity. This can be useful when defining arrowhead symbols. If the arrowhead symbol is drawn, a line command immediately following will use the color of the arrowhead. When a symbol has more than one color, the color used to draw the last entity in the symbol will be used.

Define Color Display the *Select Color dialog box*, which allows you to pick you color from a much larger spectrum if your video card allows. Only the selected color is modified.

Blend 16 Colors Create a 16-color spectrum using the selected color as a base. This command is useful for creating several shades of the same hue. Seven colors to the left will gradient to black, and eight colors to the right will gradient to white. The new colors will replace any existing colors, so use this command carefully.

Use Default PAL Replace a user-customized palette with the *Default Palette*. The *Default Palette* contains the standard **EasyCAD** color scheme. The *Default Palette* is hard-coded into **EasyCAD** and cannot be modified or deleted.

Save Custom PAL Save your modified palette. **EasyCAD** can save only one custom palette created with user defined colors. Individual palettes cannot be saved for each drawing. **EasyCAD** saves the custom palette in a file named **fcw32.pal**.

Reload Custom PAL Load the *user-defined palette* stored in the file **fcw7.pal**.

Text equivalent: **COLOR**



Layer icon

Layers & Order

When you add new layers, notice that they automatically sort in alphabetical order.

There may be instances when you want layer names to appear in a specified order. You can do this if you precede the layer name with a number. Numerical digits always precede alphabetic characters.


For instance, if you want a layer named "waterways" to always appear at the top of your list, re-name it "1_waterways", or "001_waterways".

Using this method, you can precisely control the list position of your layer names.


When you import CAD drawings created in the DOS versions of EasyCAD or FastCAD, the layer numbers are translated to characters. Therefore, layer "15" appears in the list before layer "2". Layer "237" appears in the list before layer "3".

Select Layer

The **SELECT LAYER** command [**Specs > Select Layer**] displays the *Layer Management dialog box* allowing you to select the current work layer for *new* entities or select layers to **HIDE** or **FREEZE**.



Current Layer Status window



Available Layer Status drop-down menu

To set the current work layer:

Click the drop-arrow at the right end of the *Current Layer status window* with the tag "L:" as seen below and a menu with all layers names in the drawing will drop down. Click the *layer name* you want to make current.

EasyCAD closes the menu. Note the *Layer indicator* on the *Status bar* shows the layer name you just selected. Any entities you draw from this point will acquire this layer property.

To create a new work layer:

1. Click in the *Current Layer status window* and the *Layer Management dialog box* is displayed. Choose the **New** button.
2. **EasyCAD** displays the *Add New Layer dialog box*. Type a new layer name (up to 32 characters) and click **OK**. **EasyCAD** returns to the *Layer Management dialog box*. The new name is added to the list, sorted alphabetically and will automatically become the *active work layer*.
3. Click **OK** to confirm the changes and close the dialog box. If you click **Cancel**, **EasyCAD** closes the dialog without adding the new layer(s) you just created.

To delete an existing work layer:


1. In the *Layer Management dialog*, highlight the layer name you wish to *delete*.
2. Click **Delete**. The layer name will be deleted from the list.

Note that **EasyCAD** will not allow you to delete a layer with entities on it. This is to prevent entities from becoming "orphaned". To remove entities from a layer, use the **ERASE** command and select entities by layer. To move entities to another layer, use

the **EDIT > CHANGE > LAYER** command and select entities by layer.

EasyCAD will **NOT** allow you to delete the *current layer*

3. Click **OK** to confirm the changes and close the dialog box. If you click **Cancel**, **EasyCAD** closes the dialog without deleting the layer(s) you just selected.



Layer Management dialog box

AutoHide all except current layer box If this box is checked when you pick a different layer as the *current work layer*, **all other layers are automatically hidden**. This is a quick way to see which entities are on a specific layer. Normally this box should not be checked.

Layer Status boxes Three columns of checkboxes display the status of the listed layers. The *left column* is the *Active Work Layer*; only one layer can be designated as “**active**” at a time. The *center column* indicates that the layer is **HIDDEN**. The *right column* indicates that the layer is **FROZEN**.

Layer Name All layers are listed in alphabetical order.

Hide box [H] Toggles the *hide/show* state of the highlighted layer. The current layer cannot be hidden.

Freeze box [F] Toggles the *freeze/thaw* state of the highlighted layer. The current layer cannot be frozen.

Purge Unused button Automatically deletes any layer that contains no entities. This can be helpful when importing drawings that have many valid but unused layers.

Rename button Renames any layer except “**STANDARD**” and “**MERGE**”.

New button Adds a *new* layer. Type a name (**up to 32 characters**) in the *New Layer Name dialog box* and click **OK**. Layer names can contain spaces. You can define a new layer with a name even in the middle of the **CHANGE-LAYER** or **COPY TO LAYER** commands.

Delete Deletes the highlighted layer name. The “**STANDARD**” and “**MERGE**” layers cannot be *deleted*. Layers containing entities cannot be deleted.

Text equivalent: **LAYERDLG**

Macro equivalent (bypass dialog box): **LAYER**

Merge & StandardLayers

Merge and **Standard** are the two default layers that new EasyCAD drawings start with. Is there anything special about them?

In the case of **Merge**, the answer is yes.

The **Merge** layer has special significance when used with parts and symbols. If the entities of a part are on the layer **Merge**, then they will import onto the current layer of the target drawing. If part entities are on any other layer, then the entities will import on those layers instead. If those layers don't exist in the target drawing, they are created.

Symbols import the same way. Draw them on layer **Merge** (or use the **CHANGEL** command after you've drawn them). When you insert those symbols, the symbol reference acquires the current layer property.

There is and can be only one **Merge** layer.

On the other hand, the **Standard** layer is not so special. It's simply there so you have a non-**Merge** layer to draw on. Neither **Merge** or **Standard** may be *renamed* or *deleted*.

Select Layer

The **SELECT LAYER** command [**Specs > Select Layer**] displays the *Layer Management dialog box*, allowing you to select a *new current work layer* for new entities or **HIDE** nad **SHOW** other layers..

Text equivalent: **LAYERDLG**

Hide

The **HIDE** command hides layers. Entities on hidden layers aren't affected by edit and copy operations. Hidden layers aren't included in printed output. After invoking the **HIDE** command, the prompt reads "**Layer name or # [dialog]:**". Type the layer name or press ENTER to see the *Layer Management dialog box*..

Text equivalent: **HIDE**

Show

The **SHOW** command displays a hidden layer. After invoking the **SHOW** command, the prompt reads "**Layer name or # [dialog]:**". Type the layer name or press ENTER to see the *Layer Management dialog box*..

Text equivalent: **SHOW**

Hide All

The **HIDE ALL** command hides all but the current layer at once. You may find it more convenient than using the *Layer Management dialog box* and clicking the **HIDE ALL** button.

Text equivalent: **HIDEA**

Show All

The **SHOW ALL** command displays all hidden layers at once. You may find it more convenient than using the *Layer Management dialog box* and clicking the **SHOW ALL** button. .

Text equivalent: **SHOWA**

Freeze

Use the **FREEZE** command to freeze a layer or layers. Freezing a layer is the same as “write-protecting” the layer. You can see entities on *frozen layers* and refer to them with modifiers, but you can’t select them for edit or copy operations. After selecting the **FREEZE** command, the prompt reads “**Layer name or # [dialog]:**”. Type the layer name or press ENTER to see the *Layer Management dialog box*.

Text equivalent: **FREEZE**

Thaw

The **THAW** command *unfreezes* a layer. At the “**Layer name or # [dialog]:**” prompt, type the layer name or press ENTER to see the *Layer Management dialog box*. You can use **FREEZE** to *freeze* any thawed layer (**except the current layer**).

Text equivalent: **THAW**

Freeze All

Use the **FREEZE ALL** command to freeze all layers, except for the current layer, which must remain thawed. You may find **FREEZE ALL** more convenient than the clicking the **FREEZE ALL** button in the *Layer Management dialog box* if you need to *freeze all but the current layer* at once.

Text equivalent: **FREEZEALL**

Thaw All

Use the **THAW ALL** command to *unfreeze all frozen layers* at once. You may find it more convenient than clicking the **THAW ALL** button in the *Layer Management dialog box*.

Text equivalent: **THAWALL**

List Layers

The **LIST LAYERS** command [**Specs > Layer Options > List**] lists all drawing layers in a drawing file. The list is displayed in a text window. Note that the existence of a layer does not necessarily mean that it contains any entities.

Click the **PRINT** or **SAVE TEXT** icons at the right end of the *LIST dialog title bar* to print the list or save to a **.TXT** file.

If you wish to delete any layers that are unused, you can do so in one step by opening the *Layer Management dialog* and clicking the **Purge Unused** button.

Text equivalent: **LISTLYR**

Line Style



Line Style icon

LINE STYLE allows you to *change the current line style*. You can either type in a *line style* name or ID #, or you can right-click to display the *Line Styles dialog* for the *active* drawing. You can also use this dialog box to *create*, *edit*, and *delete* styles. When you choose a different style from the list, the style is applied only to new entities that are drawn.

Note that you can also click in the *Line Style status window* to choose from a list of used *line styles*, or to display the *Line Styles dialog*.

To change the style of an individual entity, use the **EDIT** command. To change the style of a collection of entities already drawn, use **EDIT > CHANGE >-LINE STYLE**. Both of these commands can be found in the **EDIT** menu.

Understanding Line Style Patterns


A **EasyCAD** line entity as seen on the screen and printouts is actually a defined pattern drawn over a specified distance, then repeated as needed.

Each repeating pattern is comprised of a specific sequence of alternating line segments and spaces. Each sequence consists of **up to 32 divisions**, or "**bits**," that can be toggled **ON** to make segments, or **OFF** to make gaps. A basic dash sequence, where the line and gap sizes are equal, can be defined by two bits.

Sequences are repeated one or more times within their pattern length to achieve desired density. For example, a basic dash sequence can be made denser by increasing the number of repeats.

The **pattern length** is the **paper scale length of the defined pattern**. Because *line styles* are *paper scale*, they **print with the same spacing regardless of the drawing's print scale**. *Line styles* are also displayed at the same resolution regardless of zoom factor.

Line style dialog



Line Style dialog box

Dialog Options **List window** All available *line styles* are graphically sampled in a scrollable list. When you click on any pattern, its editable properties are displayed in the dialog's right pane, and the *Line Style* name updates accordingly.

New Creates a *line style*.

Clone Creates a new *line style* by copying the currently selected *line style*. The new style is added to the end of the list and is made current for editing or use.

Delete Deletes the selected *line style*. Any *line style* can be renamed except "Solid".

Rename Renames the selected *line style*. Any *line style* can be renamed except "Solid".

Use Gallery File Opens the file dialog, where you can specify an existing gallery file. **FastCAD** lets you import styles contained in gallery files.

Update List Resets the *line style status* to show only "Solid", "No Outline", and those styles used in the drawing. New *line styles* are added to this list, whether they are used or not.

Style status Displays the selected style's **ID#** and type.

Editing Options **Pattern Sample** Displays a real-size, repeating sample of the *line style* as it would appear in actual use.

Pattern Edit Each *line style* is defined by a repeating pattern consisting of up to **32 on/off "bits."** The **Number of valid bits** determines how many of the bits represent the pattern. Click on each valid bit to switch it **on** or **off**. The **Pattern sample** updates to reflect the edit.

Bit pattern Hexadecimal value representing the on/off state of each of the **32 bits** in the displayed pattern. If known, you can enter the any bit pattern (in hexadecimal notation) to define a pattern.

Number of valid bits Number of bits used to define this pattern. The range of valid integer values is **1** through **32 bits**.

Number of repeats Number of times the bit pattern is repeated in the pattern. The higher the number, the denser the pattern. Decimal values can be entered.

Pattern length The length of each pattern, in *paper scale* units. If modified when **Use master pattern length** is checked, the value is used for all such patterns.

Use master pattern length Forces use of the master pattern length. All such patterns use the same pattern length. To set a new master pattern length, change the **Pattern length** while checked. To allow the selected pattern to use a unique length, uncheck this option and enter a new **Pattern length**.

Text equivalent: **LSTYLEDLG**

Fill Style



Fill Style icon

Fills are repeating patterns you can assign to bounded entities such as polygons, circles, and ellipses. Fills add information to your drawings by visually or schematically representing different surfaces, materials, or textures. Fills are sometimes called “**cross hatches**” or “**hatches**”.

All entities possess the *fill style* property, but the default setting is “**Hollow**”. Entities with the “**Hollow**” *fill style* are *transparent* and exhibit no fill pattern.

FILL STYLE allows you to change the current *fill style*. When a *fill style* is made current, all new valid entities will draw with that fill pattern. **EasyCAD** provides you with many different pre-built *fills* and *hatches* you can immediately use. **EasyCAD** also provides means for creating your own fills, so your selection is virtually unlimited.


To set the current *fill style*, you can invoke the **FILL STYLES** command and enter an existing *fill style* name (select from the dialog or type directly from the keyboard). To access a much broader set of *fill style* tools, right-click to display the *Fill Style dialog box*. Use this dialog box to *apply*, *create*, *edit*, and *delete* styles. When you choose a different style from the list, the style will only be applied to new entities that are drawn.

To change the *fill style* of an individual entity, use the **PEDIT** command [**Edit > Properties...**]. To change the *fill style* of a collection of entities already drawn, use the **CHANGE-FILL STYLE** command [**Edit > Change > Fill Style**].

The color of the *fill style* can be made different than that of the defining entities. Use the **CHANGE-2ND COLOR** command [**Edit > Change > Fill (2nd) Color**] to set the secondary color.


EasyCAD provides four types of fill styles:

Brush Patterns




Brush pattern fill styles are patterns composed of a repeating 8x8 matrix of pixels. Brush patterns are drawn in the selected **EasyCAD** color. This type of fill offers less constraint than others in pattern layout because you can “**paint**” it. Since brush patterns are drawn at the pixel level, they do not scale up or down with drawing. They will always appear the same size on your printouts.

Scaleable Hatching




Scaleable hatching is a type of *fill pattern* composed of actual line entities. Up to four lines can be used to create the repeating pattern. Scaleable hatch patterns should be used when outputting to pen plotters since they consist of plottable vector entities.

Bitmap Files



Bitmap (BMP) files can be used as a *fill pattern*. A single image can comprise the entire fill, or smaller bitmap images can be tiled to produce a repeating effect. Bitmap fills can be useful in creating a realistic texture or background in a drawing.

Symbol Fills



Symbol fills provide a means of arraying **EasyCAD** drawing entities as a fill pattern. This type of fill provides great flexibility in design since anything you draw in **EasyCAD** can be turned into a symbol fill. Symbol fills are vector entities that can be plotted on a pen plotter.

Options to select and edit these *fill styles* appear on a single dialog box called a property sheet. Across the top of the property sheet are four tabs, each tab corresponding to a page displaying options for each type of *fill style*. Make page selections by simply clicking on the appropriate tab.

All of the **Fill Style** dialogs share some common controls:

List window All available *fill styles* are graphically sampled in a scrollable list. When you click on any pattern, its editable properties are displayed in the dialog's right pane and the **Fill Style Name** updates accordingly.

New Creates a *fill style*. Select the type from the *Type of New Style dialog*. Four options are available:

- **Brush Pattern**
- **Hatch**
- **Bitmap File**
- **Symbol**

Clone Creates a new *fill style* by copying the currently selected *fill style*. The new style is added to the end of the list and is made current for editing or use.

Delete Deletes the selected *fill style*. Any *fill style* can be deleted except "**Hollow**" and "**Solid**".

Rename Renames the selected fill style. Any fill style can be renamed except "**Hollow**" and "**Solid**".

Use Gallery File Opens the *Load Gallery dialog*, where you can specify an existing **FG7** gallery file. **EasyCAD** lets you import styles contained in *gallery* files.

Fill Style Name Pick an available fill style from the list to apply, edit, or delete. When you click on any name, the pattern's editable properties are displayed in the dialog's right pane and the *List window* updates accordingly. The selected style is made current.

Outlined Draws the outline to be drawn around the fill pattern. The outline will be drawn in the current line style and color. When off, the bounding entity is suppressed from view.

Update List Resets the *Fill Styles status* to show only **HOLLOW**, **SOLID**, and those styles used in the *current drawing*. New *fill styles* are added to this list, whether they are used or not.


Style status Displays the selected style's **ID#** and type.

Text Equivalent: **FSTYLE**

Brush Pattern Fill Style

BRUSH PATTERN fill patterns are fill patterns composed of a repeating 8x8 matrix of pixels. Brush pattern fills are drawn in the selected **EasyCAD** color. This type of fill offers less constraint than others in pattern layout because you can “**paint**” it. Since brush patterns are drawn at the pixel level, they do not scale up or down with drawing. They will always appear the same size on your printouts.

The **Fill Style** dialog automatically updates to show the editing controls appropriate to the selected **fill style** type.



You can *create*, *edit*, or *delete* brush pattern *fill styles*.


Pattern Sample Displays a real-size, repeating sample of the brush pattern as it would appear in actual use.

Pattern Edit An **8x8 matrix** of **pixels** that let you modify the selected brush pattern. Click on any pixel to toggle it **ON** or **OFF**. Watch the **Pattern Sample** to visually assess your modified pattern

Restore Restores the edited pattern to its state before the dialog was opened. All session pattern edits for the displayed *fill style* will be lost.

Hatch Fill Style

HATCH fill patterns are composed of true line entities. Up to four lines can be used to create the repeating pattern. Hatch patterns should be used when outputting to pen plotters since they consist of plottable vector entities.



- Dialog Options

Sample

Displays a scale sample of the *fill style*, reflecting pattern changes as you make them.
- Sample size**

Sets the number of times the pattern is repeated in the sample. For instance, if you set the size to "4", the defined pattern is displayed in a **4x4 matrix**.
- Show Hatch by Color**

Temporarily shows each line in a different color to assist in editing. These colors are never displayed in the actual drawing.
- Hatch Line Edit

Hatch Edit describes the position, scale, and orientation of each line that comprises the hatch pattern. The display updates depending on which line is displayed (cycle using the **Prior** and **Next** buttons).

Prior

Updates parameter display/edit for the prior hatch line.

Hatch Line status

Displays the current hatch line. Use the Prior and Next buttons to move the list.

Next

Updates parameter display/edit for the next *hatch line*.

Add

Creates a new hatch line. The *hatch line* number is updated in the **Hatch Line** status. New *hatch lines* are created using default parameters. The new *hatch line* is immediately made current for editing.

Rmv Removes the current *hatch line*.

Offset side Sets vertical displacement value for the current *hatch line*, measured from the nominal origin of the hatch pattern (**lower left**).

Offset along Sets horizontal displacement value for the current *hatch line*, measured from the nominal origin of the hatch pattern (**lower left**).

Spacing Sets the repeat distance (in **EasyCAD** units) for the current *hatch line*. This spacing is the perpendicular distance between the repeated lines.

Angle Sets the bearing of each line in the line set. The angles correspond to the default **EasyCAD** orientation, where the "3 o'clock" position equals 0° and positive rotation is counter-clockwise.

Scale Multiplies the offset, spacing, and segment values by the specified factor.

N Segments... Switches to the segment edit mode. N is the current number of segments.

Segment Edit Use the **Segment Edit** mode to describe each of the lines that can comprise a hatch pattern. If your pattern uses only solid lines, then would not have to edit segments. However, if your hatch pattern requires the use of dashed lines, define them here.

Segment length Specifies the length of a line segment or gap, as shown in the Segment List below. You can enter a new segment by typing a length. Positive numbers are visible segments, and negative numbers create gaps of that length.

Change Updates the selected segment with the Segment length value.

Before Inserts the Segment length segment or gap before the selected segment.

After Inserts the Segment length segment or gap after the selected segment.

Remove Deletes the selected segment from the Segment List.


Segment List Displays all segments that define the current hatch line. To select any segment, pick it from the list.

Flip Toggles the +/- of each segment value. Positive values are visible segments, while negative values are gaps.

Close segment list Ends the segment edit mode and returns you to the regular fill style dialog.

Bitmap Files Fill Style

BITMAP (BMP) FILES can be used as a fill pattern. A single image can comprise the entire fill, or smaller bitmap images can be tiled to produce a repeating effect. Bitmap fills can be useful in creating a realistic texture or background in a drawing.



Segment Edit Sample Displays a scale sample of the *fill style*, reflecting pattern changes as you make them.

Find File Opens the standard File dialog, filtered to display **BMP** files in the current folder. If you pick a valid bitmap image file, it is used for the selected *bitmap fill style*.

Bitmap file Displays the current bitmap image used for the selected *fill style*. To specify a different image file, type a new path/name or click Find File.

Choose one of the following options to specify *bitmap fit* and *scaling*.

Copy to top left extents The specified image retains its original size, and it abuts itself to the upper left corner. If the image is larger than the drawn box, it will clip to the right or bottom as needed. If the image is smaller than the drawn box, the blank area will appear transparent.

Stretch to fit The image conforms to the aspect ratio of the rectangle you draw. The image is centered in the fill boundary. Note that this option may distort the image. For instance, a square image will appear stretched in one direction if you fill a rectangular box.


Expand to fit extents The image is scaled to fit entirely within the fill boundary, without clipping. The image is centered in the fill boundary and maintains its original aspect ratio. Any blank area in the box will appear transparent.

Expand to fill extents The image is scaled to completely fill the boundary, clipping as needed. The image is centered in the fill boundary and maintains its original aspect ratio.

Tiled to fill extents The image maintains its original size and aspect ratio, and repeats itself within the fill boundary as to fill it. The "**start**" image aligns to the top left extents. Edges will clip as needed.

Symbol Fill Style

SYMBOL FILLS provide a means of arraying **EasyCAD** drawing entities as a fill pattern. This type of fill provides great flexibility in design since anything you draw in **EasyCAD** can be turned into a symbol fill. Symbol fills are vector entities that can be plotted on a pen plotter.



Segment Edit Sample Displays a scale sample of the *fill style*, reflecting pattern changes as you make them.

Sample size Sets the number of times the pattern is repeated in the sample. For instance, if you set the size to "4", the defined pattern is displayed in a 4x4 matrix.

Symbol name Specifies the symbol to be used in the fill pattern. To see a list of all available symbols in the drawing, click the drop arrow. You can pick a symbol from this list.

X Step Distance Specifies the distance (in drawing units) between the repeating pattern objects in the **X (horizontal)** direction.

X Step Distance Specifies the distance (in drawing units) between the repeating pattern objects in the **Y (vertical)** direction.


X Scale Horizontally scales the symbol in the fill pattern by the specified factor.

Y Scale Vertically scales the symbol in the fill pattern by the specified factor.

XY Rotation Rotates the symbol within the pattern by the specified angle.

Pattern Rotation Rotates the entire pattern by the specified angle.


Line Width



The **LINE WIDTH** command displays the '*Line Width*' dialog box. Use this command to set the *line width* for all new entities.

Understanding Line Widths

LINE WIDTH is a *geometric entity property*, in the same manner that each entity possesses *color* and *layer* information. As such, the *current line width* is displayed on the *Status bar*, labeled with the tag '**LWid:**' as seen below.



Current Line Width status window

All new entities will be created with the *current line width*. *Line widths* are always expressed in terms of the *current drawing UNITS*.


If the *line width* is **0.0** (zero), the entity will *display* and *print* in the usual *one pixel width*.

If the *line width* is greater than the *nominal 0.0 width*, it will draw with the entity's *fill style*. New entities with *line width* will *fill* with the *current fill style* as displayed on the *Status bar*. *Line widths always scale up or down*, depending upon your *zoom factor*, to the *minimum one pixel display width*.

If you wish to *draw filled polygons*, set a current fill style to something other than **HOLLOW** and use a **0.0 Line Width**. If you assign a *line width* to a *polygon*, the *polygon* will be **HOLLOW** and the line defining the *polygon* edge will be *filled* with the specified **Line Width**. For instance, if you draw a polygon with a width of **0.25**, **EasyCAD** will draw the *polygons outline* with a **0.25 Line Width** and *fill* only the *outline*, NOT the *interior of the polygon*.

Any entities combined in a **MULTIPOLY** will redraw with a *line width* of **0.0** for fill pattern display. Remember that the intention of the **MULTIPOLY** command is combining entities for fill or hatching. When a **MULTIPOLY** is **EXPLODED**, the component entities revert to their original *line width* and display appropriately.

Line Width dialog box




NOTE: *Line Widths* are *always geometrically scaled* when *zooming in* or *out* and when *printed they obey the scale set in the 'Print Drawing' dialog box*.

Text equivalent to display the dialog box: **LWIDTHD**

Macro equivalent to bypass the dialog box: **LWIDTH**

Pen Thickness



PEN THICKNESS is the *display* and *printing of thicker lines* for entities. Specify or change the desired *pen thickness* by clicking directly on the indicator labeled with the tag '**PThk:**' as seen below.

The term **PEN THICKNESS** is used because it is analogous to the older *pen type plotters* that used an *ink pen of a specific thickness* such as **.1mm, .3mm, 1mm** etc. These pens always draw that *exact line thickness* when plotting the drawing. Likewise our **PEN THICKNESS** property always *prints* and *displays* the *same thickness* no matter the *scale* or *zoom factor* you use when printing the drawing.




Current Prn Thickness status window

The *Status bar* displays the *current pen thickness*. Any entities you draw will use this *pen thickness*. You can access the '*Pen Thickness*' *dialog* by clicking directly on the *Pen Thickness indicator window*. **EasyCAD** displays the '*Pen Thickness*' *dialog*, which lets you specify *paper scale thickness* and millimeter units.

Pen Thickness Dialog Box

Pen Thickness dialog box



Pen thickness is always in *paper scale* meaning that it is unaffected by the current drawing **UNITS** setting. Its **UNITS** are always determined by that specified in the *Pen Thickness dialog*. **UNITS** are specified in **MILLIMETERS (mm)** or **INCHES** inches.

Valid values for *pen thickness* are **0.0** through **2.54 mm** (**0.0** through **0.100** inches).

Current Pen Thickness Specifies the *pen thickness* value in millimeters. This *pen thickness* will be applied to all new entities.

Show pen thickness on display If **unchecked** it suppresses screen display of *pen thicknesses*. Use this option for *faster screen redraws* should it become an issue. Checking this option will **NOT** affect any entities' *actual pen thickness* settings or printing of them; only their display is affected.

Show pen thickness when printing If **unchecked**, it suppress transmission of *pen thickness information to the printer without actually changing these settings*.

Map outline color to Pen Thickness All **256 drawing colors** are available for mapping. Click the '*Edit Color Map*' button to configure the color mapping.


Edit Color Map button Displays the *'Map Colors to Pen Thickness'* dialog box. Settings configured in this dialog box only take effect if the *'Map outline color to pen thickness'* box is checked.

To change the *pen thickness* of an existing entity:

Use the [Edit > Change > Pen Thickness] command to select the entities to change and type a *new Pen Thickness followed by the 'mm' for MILLIMETERS*. If you do not follow the *new Pen Thickness value with the 'mm'* the selected entities **WILL NOT CHANGE**

Text equivalent: PTHICK

Map Color to Pen Thickness dialog box



The *'Map Color to Pen Thickness'* dialog is displayed when you click the *'Edit Color Map'* button on the *'Pen Thickness'* dialog.

The controls here allow you to assign a *pen thickness* to each of EasyCAD's 256 *drawing colors*. The *pen thicknesses* set in this dialog are **NOT** assigned to each entity. If you use the [Info > List] command and select an entity, its *pen thickness* would list as *'0.00000mm'* because the *'Map outline color to pen thickness'* option is just a translator and doesn't directly effect entities.

If you send a drawing to another EasyCAD user and that EasyCAD's *color map* was not enabled or was set with different *pen thicknesses* than your EasyCAD, the *pen thickness* would obey that color map. If you want your *pen thicknesses* to be *portible* between EasyCAD users, you should *manually assign pen thickness* to each entity in the drawing as you draw it. You may also write a **Macro** to automate this process.

A *pen thickness* specifically assigned to an entity in the drawing take precedence over a *pen thickness* specified in the *'Map Color to Pen Thickness'* dialog. If you set the default *pen thickness* to *'.4mm'* and draw a *green line*, it will retain this *pen thickness* when the drawing is *saved*. If you are using the *'Map outline color to pen thickness'* feature and *color #1 green* is set to *'.1mm'*, the *green line* you drew previously will use the *'.4mm'* *pen thickness* in stead of the *'.1mm'* set in the *'Map Color to Pen Thickness'* dialog.

This means that *only entities with a '0.00000mm' pen thickness will obey the 'Map outline color to pen thickness' settings in EasyCAD.*

The settings in this *'Map Color to Pen Thickness'* dialog only take effect if the *'Map outline color to Pen Thickness'* box is checked on the *'Pen Thickness'* dialog.

How Color Maps Are Saved

When a drawing is *saved*, it includes a *copy* of the *Pen Thickness color map settings then in effect* in the 'ECW7.CMP' file in the \EasyCAD7 folder. However, simply loading the file *does not modify the current color map settings*. To use the current drawing's *color map* select the [Specs > Color Map > Use Dwg Map] command.

The [Specs > Color Map > Use Dwg Map] command copies the loaded drawing's color map to your *current settings*, and *will be used until you change them*. It is best to save your *standard color map settings once*, and each time after you *edit* them. In that way, you can use [Specs > Color Map > Use Dwg Map] command to use settings appropriate to a particular drawing, then select the [Specs > Color Map > Load Saved] command to *restore your standard color map settings for Pen Thickness*.

Pen Thickness window Specifies the 'Pen Thickness' *value* to map for the *selected color number*. The *thickness* you choose is in *paper scale*; it will *not scale up or down with the drawing print scale*. When you click on a color its *current setting* is displayed in this *value window*. Change it by clicking in the window and typing a *new value* followed by 'mm' for *millimeter*. If you do NOT type the 'mm', *the default value will NOT change when you click the SET button*.

Set Accepts the *entered value* as the *pen thickness* for the *selected color*.

Print Black Forces printing of the selected color to *black*. This display is NOT affected by this option. Only the *print preview* and *actual plots* will show selected lines in *black*.

Color list Select a color from this scrolling list to assign a new width. The actual drawing color is shown in the first small box, the plotting color is in the adjacent small box, followed by its palette number and the current line width. The plotting color is only affected when the **Print Black** option is selected for that color. The colors 0-255 correspond to the 256 available drawing colors. Use the [Specs > Select Color] command to see or modify the palette.

Load Color Map

The [Specs > Color Map > Load Saved] command loads a *color map pen thickness settings* saved with the [Specs > Color > Map Save Current] command. The file named 'FCW7.CMP' is automatically created with the [Specs > Color > Map Save Current] command in the \EasyCAD home folder. The [Specs > Color Map > Load Saved] command *reads the values* from the 'FCW7.CMP' file into the *current color map pen thickness settings*, which continue to be saved in the registry.


This command is helpful for *restoring your regular settings after you've used the* [Specs > Color Map > Use Dwg Map] command to temporarily update your color mapping.

Text equivalent: **SAVECMAP**

To *view* or *edit the current color pen thickness mapping*, click in the '*Pen Thickness*' status window or select the [Specs > Pen Thickness] command and click '*Edit Color Map*' button to display the '*Map Colors to Pen Thickness*' dialog.

Keep in mind that *color map settings* only take effect if the '*Map outline color to pen thickness*' box is checked on the '*Pen Thickness*' dialog as seen below.

Pen Thickness dialog box



Text equivalent: **LOADCMAP**

Save Color Map

The [Specs > Color Map > Save Current] command writes the **current color map settings** to the file '**ECW7.CMP**' in the \EasyCAD home directory. *Use this command to preserve your preferred or default settings should you change them. Restore your color map pen thickness set* by using the [Specs > Color Map > Load Saved] command.

To *view* or *edit the current color map settings* select the [Specs > Pen Thickness] command and click '*Edit Color Map*' button to display the '*Map outline color to pen thickness*' dialog.

Keep in mind that *color map settings* only take effect if the '*Map outline color to pen thickness*' option is checked on the *Pen Thickness* dialog seen above.

Text equivalent: **SAVECMAP**


Using a Drawing's Color Map

The [Specs > Color Map > Use Dwg Map] command *loads* and *uses* the *active* drawing's *stored color map values* for automatically mapping various *pen thicknesses* values to entities drawn with *specific colors*. Unless the [Specs > Color Map > Use Dwg Map] command is used, EasyCAD will continue to use the *color map settings stored in the registry*.


Note that using the [Specs > Color Map > Use Dwg Map] command will *overwrite the current registry values*, and *all subsequent drawings will use the new settings*. To *prevent accidental loss of your preferred or default settings*, use the [Specs > Color Map > Save Current] command *before using* [Specs > Color Map > Use Dwg Map] command *and use the* [Specs > Color Map > Load Saved] command *afterward to restore the original color map values*.

To *view* or *edit* the *current color map values*, click in the '*Pen Thickness*' status window or select the [Specs > Pen Thickness] command and click the '*Edit Color Map*' button to display the '*Map Colors to Pen Thickness*' dialog box as seen below.

Pen Thickness dialog box



Map Color to Pen Thickness dialog box



Keep in mind that *color map settings only take effect if the 'Map outline color to pen thickness' box is checked on the 'Pen Thickness' dialog as seen on the previous page.*

Text equivalent: **DWGCMAP**



Dimension Style icon

Dimension Style

The **DIMENSION STYLES** command displays the *Dimension Style dialog box*, which allows you to set formatting options for dimensions you are about to draw. In other words, changes made with this command only affect new dimensions, not existing dimensions.

All dimension entities possess a *dimension style* entity property.

Dimension properties can be applied as a set using *named dimension styles*, but if desired, each property can be modified independently from a defined style.

Named *dimension styles* are not entity properties. Rather, they only *define a set of dimension specifications* for *new dimensions*. That is why, for instance, you cannot select entities by *dimension style*.

To set the text color different from the rest of the dimension, use the **CHANGE C2** command [**Edit > Change > Fill (2nd) Color**], and apply it to the selected dimension(s). Only the text will redraw with the secondary color. The leaders, extension lines, and arrowheads will remain the same as the primary color.

Formatting options you can control include:

- **Arrowheads:** Type, Length, Height.
- **Leaders:** Formatting.
- **Options:** Tolerances, center marks, centerlines.
- **Text:** Font, placement, height, decimal places, prefix, suffix, alignment with arrows.

To change the dimension style for a single existing dimension:

Use the **EDIT** command [**Edit > Edit**].

To change a collection of dimensions already drawn:

Use the **CHANGE > DIMENSION STYLE** command [**Edit > Change > Dimension Style**].

Dimension Style dialog box



- Dimension Style Names**
- Style Name** Select a *named dimension style* from a drop-down list of available styles. **EasyCAD** displays the format settings in the dialog.
- AutoUpdate** When checked, **EasyCAD** automatically applies the current format to all dimensions with the same *named dimension style*. If you want dimensions of the same named style to have different formats, leave this option unchecked.
- Add** Creates a *new dimension style*. Initially, the new style will acquire the current listed properties. As styles are added, they are auto-named #n, where n is the next ordinal number. To rename any style, click into the **Name** field and type in a new name.
- Delete** Deletes the selected *dimension style*.
- Arrowhead Properties**
- Type** Select the **arrowhead style** from a drop-down list of available styles.
- Length** Length of **arrowhead** from **endpoint** to **base** (drawing units).
- Height** Base width of **arrowhead** (drawing units).
- Thickness** Pen thickness of arrowheads.
- Leaders**
- Offset Dim Point** Specifies the **distance from the edge of a dimensioned entity to the start of the extension line**.

Dimension Text Fonts and their Properties

Extend past text Specifies the distance of the extension line beyond the dimension line.

Thickness Pen thickness of leader lines.

Font Select a font for dimension text and numbers from the drop-list of available fonts.

More Fonts Select to add fonts to the drop-down list. For more information on specific font types, see the **TEXT PROPERTIES** command.

VPos Select placement of dimension text relative to the dimension line, for horizontal dimensions. Available choices are Above/Centered/Below. Centered text will break the dimension line. During placement, Any of these settings can be manually overridden by holding down the **SHIFT** key.

HPos Select placement of dimension text relative to the dimension line, for horizontal dimensions. Available choices:

- Auto-Left: Dynamic cursor displays Dim Text in middle; but if text will not fit, the Dim Text position defaults to left. Can be overridden during placement.
- Auto-Right: Dynamic cursor displays Dim Text in middle; but if text will not fit, the Dim Text position defaults to right. Can be overridden during placement.
- Center/Left/Right: Dim Text forced to middle/left/right position, respectively. Cannot be overridden during placement (unless manually repositioned by holding down **SHIFT** key).

Height Specify the height of dimension text in drawing units.

Dec. Pl. Specify the number of decimal places to be displayed for individual dimensions drawn in this style.

Text Format Use this field to specify **fixed prefix** or **suffix text** that is appended to the true dimension value. The "<>" is used as a placeholder for the true value. If the value placeholder is omitted, the value is not included in the **dimension** output.

Scale value by Typically used only to deal with the **AutoCAD DWG/DXF** import/export issues. This value is used as a scale factor. The true dimension is multiplied by the scale factor, and the scaled value is represented by the dimension text. **Scale value = 1 represents actual dimension.**

Baseline Spacing Specifies the automatic spacing between **BASELINE DIMENSIONS** (drawing units).

Vector Text Thickness Pen thickness of **vector text only**. Only applicable if **.FNT** or **.SHX** fonts are used (**not TrueType®**).

Options **Align text with arrows** Check to align text with the dimension line, regardless of orientation. If not checked, dimension text will always display horizontally.

Show Center Mark Check to display center marks, which are small crosses **EasyCAD** creates at the center of dimensioned circles or arcs.

Show Center Line Check to display center lines, which consist of alternating short and long dashes. **EasyCAD** automatically draws them as extension lines for dimensioned circles and arcs. Center marks are always created whenever center lines are drawn.

Text equivalent: **DSTYLES**

Arrowhead Style




Arrowhead styles available in EasyCAD

Changing the **arrowhead style** with the **ARROWHEAD STYLE** command changes the arrowheads on all existing entities in your drawing. If you want to add arrowheads to selected entities, use **CHANGE** [Edit > Change].

This command **does not affect dimension arrowheads in any way**. To manage **arrowheads** on **dimensions**, use the **DSTYLES** command [Specs > Dimension Style].

Arrowhead Style dialog box



To use, select an arrowhead type from the drop list, and edit the length and/or height of the **arrowhead** as desired.

Style Select the arrowhead style from the drop list. The **arrowhead style** you select will be applied to currently selected entity.

Length Sets the length of the arrowhead in drawing units. If you edit this value, the height will automatically update to maintain the arrow's aspect ratio.

Height Sets the height of the arrowhead in drawing units, measured as the total height of *both* **arrowheads**. When the **Length** value is changes, **Height** updates by the same factor to maintain the arrow's aspect ratio. You can override this suggested value by entering a different height.


Text equivalent: **ASTYLE**

Text Properties

TEXT PROPERTIES displays the *Text Properties dialog box* with choices for height, angle, line spacing, stretch, justification, and fonts for text you are about to create.

To change a single existing text entity (either the text or properties), use the **[Edit > Edit]** command. To change the text properties for any number of existing text entities, use **[Edit > Change > Text Properties]**. To change the text value for any number of existing text entities, use **[Edit > Change > Text]**.

Text Properties dialog box



Text Styles Creation

Style Name Select a named text style from a drop-down list of available styles. EasyCAD displays the format settings in the dialog.

AutoUpdate When checked, EasyCAD automatically applies the current format to all text with the same named dimension style. If you want text of the same named style to have different formats, leave this option unchecked.

Add Creates a new text style. Initially, the new style will acquire the current listed properties. As styles are added, they are auto-named #n, where n is the next ordinal number. To rename any style, click into the Name field and type in a new name.

Delete Deletes the highlighted *text style*.

Text Properties

Height The height of a capital letter. The default text height is 0.2 units high. To change, type a new value in drawing units (for text 1/2 unit high, type .5 or 1/2).

Angle The bearing at which text is drawn. **Positive angles are measured counterclockwise.** For best results, use angles between -90° and 90°. **The default angle is 0 degrees horizontal.** To change, type a positive or negative bearing.

Spacing % The vertical spacing between text baselines. The default spacing of each new text entity is specified at **150% of its height below the last text.** (If the new text is 1 inch high, its base line is 1.5 inches below the old text, making the lines 0.5 inch apart.) To change, type a different value in percent units.

Stretch The horizontal (or along the baseline) proportion of the text entity. The default stretch is 1 unit. A value of 2 would produce text that is twice as wide as normal. To change, type a different scale value.

Use New Metrics When on, this switch enables enhanced text handling (introduced in **EasyCAD** version 6.02). Text heights for **TrueType**® fonts will be more closely matched over a wider variety of typefaces. For new drawings, this option defaults to **ON**, while the option defaults to **OFF** when existing drawings are loaded. You can choose individual text entities to use (or not use) new metrics by using the **CHANGET** command.

Character Style

Style switches Select the check boxes for the desired effects for the selected **TrueType**® font. Styles may be combined to produce differing effects. For new drawings, the switches default to all off. Results of each character style (Outline cannot be displayed through this help system):

Text Position

Angle fixed When checked, the bearing angle of the selected text is locked. This prevents the text characters from rotating, even if the text entity itself is rotated. This can be handy when text is in a callout or balloon.

Justify Justify sets text baseline justification. The default justification is Bottom Left. To change, select a different option.

Font Types you can use

Available Font list **EasyCAD** supports three different types of fonts - **TrueType**, **EasyCAD DOS .FNT** and **AutoCAD® .SHX vector fonts**. Which one you choose depends upon your needs.

To add more fonts to the available list, click the **More Fonts** button and add fonts in the Add New Font Properties dialog box.

Windows TrueType®

Windows comes pre-loaded with a number of **bitmap** based **TrueType**® fonts, and their presentation quality is quite good. Additional fonts can be readily purchased or obtained through many sources. Since **TrueType**® fonts are available for use in all your Windows programs, you can maintain a consistent typeface throughout your drawings and other Windows produced documents. The biggest drawback of **TrueType**® fonts is the inability to precisely control the size and aspect ratio of typefaces as seen on the screen (at different zoom factors), and in printed hardcopy. This inconsistency is an innate characteristic of **TrueType**® fonts and cannot be corrected by **EasyCAD**. The default font is **Arial**.

EasyCAD DOS .FNT Vector Fonts


FNT Vector Fonts are font types used in the **DOS** version of **EasyCAD** or **FastCAD**. **Vector fonts** should be used when precise control over your text's size and aspect ratio is required. Text on printed circuit boards, or used as labels in boxes or balloons, are good applications for **vector fonts**. Vector fonts should also be used if you are printing to a pen-type plotter, since most pen plotters cannot print **TrueType**® fonts, especially if the text is rotated. The drawbacks to **vector fonts** are their relatively plain appearance and limited availability. **EasyCAD** ships with eight

AutoCAD® .SHX Vector Fonts

SHX Vector fonts are proprietary font types compatible with AutoCAD®.

You should use the .SHX font type if you are interchanging EasyCAD files with AutoCAD® systems. The specified .SHX file must be in your \EasyCAD7 home folder in order for these fonts to be used (they are not organic to an AutoCAD® .DWG or .DXF file).

Select Font dialog box



This dialog appears when you choose the *More Fonts* button in the *Text Properties dialog box* or the *Dimension Styles dialog box*.

Use this dialog to add fonts to the **available font list** in the *Text Properties dialog box*. Choose one of the fonts you wish to add. A list of all **TrueType®** fonts installed in **Windows**, **EasyCAD .FNT** and **AutoCAD® .SHX vector fonts** that are resident in your \EasyCAD7 folder are available in this window. When you select a font, the preview box shows you a sample of the typeface. Choose **OK** to add the *selected font* to the list, or **Cancel** to abort font addition.


NOTE: Any font of a supported type can be used in **EasyCAD**, but only after it has been “added” through this dialog. Any combination of font types, **.TTF**, **.FNT** and **.SHX** fonts can be used.

If you wish to use the same set of fonts in new drawings, use the **TEMPLATE** feature. Start a new drawing, add the desired **FONTs**, and use the **SAVE AS** command to save the file as a **.FT7 TEMPLATE** file. Then use the **TEMPLATE** command to make it the current **TEMPLATE** to be used when you select [**File > New Drawing**] to start a new drawing file.

*Text equivalent: **TSPEC***

Font

Click the drop arrow at the right end of the **FONT Status window** and select the **current font** from those available in the drop-down menu.




You can also type **FONT** at the command line and type a **FONT name** including its extension such as **SMOOTH.FNT**, type a font **ID#**, or right-click and select a **FONT** from the *Select Font dialog* that opens. All new text entities are drawn using the **current font**.

The specified **FONT** must already have been added to the *available font list*, as displayed in the *Text Properties dialog*.

You can also left-click inside of the **FONT Status window** to open the '*Font Management' dialog box* or use the [Specs > Text Properties] command to open it to **ADD NEW FONTS** and manage *available fonts*.

To make a **FONT active**, type **FONT** at the command line:


- The prompt reads "**Font name or # [dialog]:**". To specify the active font:
 - Type a **font name** and **press ENTER**.
 - Type a **font ID #** and **press ENTER**.
 - Right-click to display the *Select Font dialog*. Click the desired **font name**.




EasyCAD makes the specified *font active*. The **Font Status window** is updated to reflect the change as seen below.



Text equivalent: **TSPEC**



Specs > Time and Date



Clicking the [**Specs > Time and Date**] command opens the **TIME AND DATE FORMATS** dialog box.


The settings in this dialog box determine the format for the **CURRENT DATE** and **CURRENT TIME** *text* entities that you place in the drawing by using the [**Draw > Text > Current Date**] and [**Draw > Text > Current Time**] commands. These *text* entities constantly update as you work on the drawing you place them in.

You may insert more than one **CURRENT DATE** and **CURRENT TIME** entities in the drawing and each may have a different format.

NOTE: If you want to freeze one of these **CURRENT DATE** and **CURRENT TIME** entities select the [**Edit > Explode**] command and select it. It now becomes a normal **TEXT** entity.

Text equivalent: **TDFMT**

Toggle Frames



TOGGLE FRAMES displays or hides *wall network*, *smooth polygon*, and *spline FRAMES*.

In the illustration above, the *spline frames* are represented as *angular lines*. On the *wall network* a *dot* will appear at each *node*. *Frames* will appear *light gray* on the actual drawing screen.

When frames are on, a check mark appears on the menu showing this state.

By default, **CTRL+F** toggles frames on or off. You can also type the macro equivalents at the command prompt to toggle frames display (see the macro box below).

Text equivalent: **FRAMETOG** or **CTRL+F**

Toggle Crosshairs


TOGGLE CROSSHAIRS enables or disables the full-screen crosshair cursor used for second and subsequent point (or entity) selections. The current state of the crosshairs cursor is saved in the Windows registry.

When crosshairs are on, a check mark appears on the menu showing this state.

Text equivalent: **XHTOG** or **CTRL+T**

Attach Mode

Attach Mode dialog box



Attach Button ON



Attach Button OOFF

ATTACH MODE displays the *Attach Modes dialog* that allows you to set the active modifier(s). The *active modifiers* work with the **ATTACH** function and is only active when the Attach button is on.

When multiple modifiers are selected, **EasyCAD** process modifiers in the order encountered in the dialog. If both **EPT** and **MID** are enabled, the closest one of the two is used.

Click the *Attach button* to activate this feature. Also, to display the dialog at any time, you can right-click the *Attach button*.

EasyCAD allows you to select any combination of seven modifiers:

Intersection of two entities Uses the **INT** modifier when an intersection is picked. Note that the attach form on the intersection modifier works in single-pick mode. That is, the pick box must enclose an intersection. This form on **INT** does not prompt for two entities as with the regular **INT** modifier. If no valid intersection is picked, **EasyCAD** tests the pick against the next checked modifier in this dialog.

Mid or End point of segment Uses the **MIDS** and **EPTS** modifiers when an entity is picked, using whichever is closest to the pick point. Note that these are the segment midpoint and endpoints. For instance, if you pick a side of a box, the point will lock to the midpoint or endpoint of that line segment, whichever is closer, and not the midpoint of the entire box.

Endpoint of entity Uses the standard **EPT** modifier, locking to the midpoint of the picked entity.

Center of entity Uses the standard **CEN** modifier, locking to the center point of the picked entity.

Midpoint of entity Uses the standard **MID** modifier, locking to the nearest midpoint of the picked entity.

Fraction along entity Uses the specified integer value to lock to the nearest fraction along the picked entity. For instance, if you enter the value "8" and pick a line, **EasyCAD** locks to 1/8th division point nearest the point you picked. This could correspond to the endpoint or midpoint of the picked entity. Note that this modifier works along the entire entity length, not the picked segment of a polygon, path, etc. Note that most of the prior listed options, by their nature, supercede Fraction along entity. To ensure successful interpretation of this option, uncheck all preceding options except Intersection of two entities.

Point on entity Uses the standard **ON** modifier, locking to the point on the entity nearest to the pick point. Note that all of the prior listed options supercede Point on entity (except for an invalid Intersection... pick). To ensure successful interpretation of this option, uncheck all preceding options.


Text equivalent: **ATCHMODE**

Installed XPs

eXtended Procedures are assembly-language modules that let qualified third party developers add new commands and entities to **EasyCAD**. Each module can contain many commands. Unlike macros, *external procedure* commands run at full **EasyCAD** speed and otherwise act just like normal **EasyCAD** commands (they Undo, they repeat properly, modifiers work with them, and so on).

External modules can include custom associative dimensions; parametric symbols such as walls with intelligent windows and doors; real-time process control; date/time stamping; simulation modeling; pop-up calculators—almost anything programmers can imagine and tell their computers to do.

INSTALLED XPs displays the *Installed XP Modules* dialog box. All loaded **XP**'s are listed. Choose the **About** button to get additional information on the selected module. This information is provided by the author of the individual **XP** commands. A list of commands found in the **XP** text screen and a description of each function should appear.



Choose the **OK** button to close the dialog box and return to the drawing screen.

To Install an XP:

XP installation is automatic when a valid **XP** module (with *.DLL filename extension) is in the **EasyCAD** folder.


To Remove an XP:

To unload an **XP** module, remove the *.dll file from the **EasyCAD** folder.

Text equivalent: **XPCFG**


Screen Tools

TOOLS allows you to customize **EasyCAD**'s appearance. Any of the available screen settings can be toggled on or off, or repositioned.



The exact number and names of each control bar can vary depending upon your configuration. The illustration below shows the default configuration:

Display/Position controls Click directly onto each check box to control visibility and positioning. The active or "on" setting is highlighted in **red/black**, while the available "off" options are highlighted in **white/gray**.



Prompt bar Located along the bottom edge, it contains the command prompt and button controls.

Tracking Contains cursor tracking, font, text height, pen thickness, and line width status controls.

Styles Contains text style, dimension style, workplane, and sheet status controls.

Electric.FS7 Symbols Positions the **Symbol Catalog Viewer** displaying it currently loaded **.FS7** filename

Color Bar Color Bar, as configured.

Standard Icons Contains zoom and spec icons.

Draw Icons Contains 2d drawing icons.

Edit Icons Contains 2d editing icons.

File Icons Contains file, bookmark, and search icons.

Use 24x24 Icons Click this box to display the larger 24x24 pixel Icons.


Show Scrool Bars Check this box to display the vertical and horizontal Scrool Bars in each drawing window

Text equivalent: **TOOLS**

Loading a Custom .CFG Screen Configuration File

The **LDCFG Macro** command allows you to *load a custom .CFG file* saved from the ‘Select Screen Tools’ dialog box as seen below.

Select Screen Tools dialog box



In the ‘Select Screen Tools’ dialog box above the ‘HIDE’ boxes have been selected to *turn off* ‘All Icon Bars and Symbol Catalog Viewer’ to give the maximum screen area to display the drawing. The ‘Save Config As’ button was clicked and the configuration file was saved as ‘No_Icon_Bars_On’. The file is automatically saved with the .CFG filename extension.

Any .CFG screen configuration file may be reloaded from the ‘Current Configuration File’ window pull down menu.

You may alternatly use the **LDCFG Macro** command and type the ‘filename.cfg’ from the keyboard to load any .CFG file without having to open the ‘Select Screen Tools’ dialog box. It may also be added to a *custom menu selection* or *run from a Macro*.

See the **EasyCAD Help Topic ‘Macros > Sample Macros > Load a Custom .CFG Screen Configuration File from a Menu or Macro’** for more details.


Macro syntax - LDCFG <filename.CFG>

Text equivalent: LDCFG

Units


The **UNITS** command tells **EasyCAD** how to relate its **internal unit system** to the **real world**. You can define **EasyCAD**'s **UNITS** as anything you wish. When you start a drawing, the default **EasyCAD UNIT** equals **one inch in the real world**. **Inches**, **feet**, **millimeters**, and **meters** are *predefined shortcuts* for changing to some commonly used **UNITS**. You can define other **UNITS**, such as **miles** or **microns**, and assign them to the **CUSTOM UNITS** definition. **UNITS** should be defined before you start to draw. Otherwise, you may have to *scale individual entities later on*.

Inches per unit This is the conversion factor **EasyCAD** needs to calculate **Dimensions** and *print your drawing to scale*. Enter a new number of **inches per unit**. For example, to define each **UNIT** as **one mile**, type **"63360"** (**5280 feet per mile times 12 inches per foot**).




Decimal places This window allows you to change the **number of decimal places** that the [**Indo > Distance**] command displays in its on-screen dialog box and the [**Info > List**] command displays in the **LIST** window for **LENGTHS** of **LINES** and their **LINE WIDTH** and **BEARING ANGLES**.

This setting has *no control over* the **number of decimal places** for **DIMENSIONS**.



Distance Display Format

UNITS dialog box



The setting in the '**Distance display format**' window determines how your **DIMENSIONS**, as well as the **DISTANCE** is calculated and displayed when using the **DIMENSION** commands or the [Info > Distance] command.

In the **DIMENSIONS** illustrated below the **UNITS** are set to **INCHES**. The **NUMERIC** '**Distance display format**' shows **509.504** which is **INCHES** since the **UNITS** are set to **INCHES**.


The other '**Distance display format**' settings show the **59.504 INCH DIMENSION** in each of the other equivalent formats. The only thing that was changed after the **DIEMSNION** was drawn was to select the [Specs > Units] command and select a different '**Distance display format**' option.

If you have a drawing and the '**Distance display format**' was set to '**Decimal Inches**' for **DIMENSIONS** and you need to give the drawing to someone who wants to see the **DIMENSIONS** in the equivalent of **MILLIMETERS** just select the [Specs > Units] command and select the '**MILLIMETERS**' option from the '**Distance display format**' window.


You '**DON'T NEED TO CHANGE THE UNITS VALUE TO MILLIMETERS**', just select **DIMMETERS** from the '**Distance display format**' window in the **UNITS** dialog box.

The 'Distance display format' may be set for the following:



Numeric format – 59.504 -- **Numeric Units** value displays with no ' ', mm or m designator. The **DIMENSIONS** numbers would display the same no matter what the **UNIT** value is set for.





Decimal Inches format – 59.504"






Fractional Inches format – 59 1/2"



Feet and Inches format – 4'-11 1/2"



Meters format – 1.511 m**Millimeters format – 1511.400 mm**

Note: If you want **DIMENSIONS** to display as '**Feet & Inches**', you do **NOT** need to change your **UNITS** from **INCHES** to **FEET**, just select '**Feet and Inches**' from the '**Distance display format**' window in the **UNITS** dialog box.

Rescale Units



When *checked* (default state), *changing the drawing UNIT* setting will cause all entities *scale so that they retain their same, absolute size*.

For example, if **RESCALE** is *checked*, a **line** with a **'1.0 inch length'** will **DIMENSION** as a **'25.4 mm'** if the **UNITS** are changed to **MILLIMETERS**. This is the number of **MILLIMETERS in an INCH**. In effect, *the drawing will remain unchanged except for the drawing UNITS display in a DIMENSION or DISTANCE command*.


Remove the check from the RESCALE box then change the drawing UNIT setting and the entities will be RESCALED by the amount of the UNIT value.

For example, when **RESCALE** is **UNCHECKED** and the **UNITS** are changed to **MILLIMETERS**, a **'1.0 inch line'** will **DIMENSION** as a **'1.0 mm line'**. All other *scaleable properties* will use the *redefined UNITS* and will be *resized by that value*.

Note: The **RESCALE** option is *always checked (on) unless you explicitly uncheck the control and change the drawing UNITS to resize the entities*.

Using the RESCALE option to rescale an Entire Drawing.

If you get a drawing in **AutoCAD .DWG or .DXF** format and you measure the length of a **line** and it is supposed to be **'10 feet long'** but its **length measures '10 inches'**, you know that it is **'12 times to small'**.




Instead of using the [**Edit > Scale > Scale value**] command to **resize the whole drawing**, **remove the check from the RESCALE box** then select **'Feet'** in the **'Drawing Units'** window and click **OK**.

Now if you draw a **DIMENSION** on the **line** that measured **'10 inches'** before the **RESCALE**, it will now display as a **'10 foot long line'**.

Dimension Bearing Angle Distance Format

The **BEARING ANGLE DISTANCE FORMAT** setting determines display when you select the **[Info > Bearing]** command. You are prompted to pick two points and the **BEARING ANGLE** between them is displayed in a dialog box.




Decimal Degrees



Degrees Minutes Seconds



Surveyors Bearings




Dimension Angle Width Format


The **BEARING ANGLE WIDTH FORMAT** setting determines the display of **ANGULAR DIMENSIONS** when you select **[Dimensions > Full Angular]** and the **[Dimensions > Quick Angular]** **DIMENSIONS** commands.



Decimal Degrees



DMS Degrees, Minutes & Seconds




Options

The **OPTIONS** command lets you configure certain **EasyCAD** screen and setup options. Invoking the command displays the *Options dialog box*. Simply select to *enable* or *disable* available *options*.

Other display options such as *displaying* or *hiding* the *Icon bar*, *Status bar*, and *Color bar*, can be configured using the **SCREEN TOOLS** command, selectable from either [Specs > Screen Tools] or by choosing the ‘*Configure Screen Tools*’ icon.

Options Settings dialog box



Enable periodic updates of changes during redraws (slower but good for large drawings) This setting is recommended.

Save drawings in Compressed format Choose to *enable automatic .FC7 file compression*. *File compression* is on the order of **50% of the original size** (actual rates vary depending upon the file content). Using this option can cause *longer file saves*. *Opening compressed files is automatic and transparent*. Current versions of **EasyCAD v7** can open all compressed **.FC7** files and open without any additional software or utilities. However, versions of **EasyCAD** prior to **v6.03 cannot open compressed files**. This setting is saved in the registry. Use this option if you are transmitting drawing files over the Internet, or saving to limited capacity media.

Enable entity-select right -button popup menu Choose this option to enable the *Entity Selection popup menu* after a right-click when you are prompted to select entities. This presents a *popup menu* with the ‘**DO IT**’ command at the top and additional entity selection methods such as by *and*, *not*, *layer*, *color*, *entity type* etc.. If this box is *unchecked* and you have selected entities by *each* or *window*, a right-click will *immediately process the command*. If you had selected the **ERASE** command and picked some entities, a right-click would *immediately ERASE them*. You don’t need to click the ‘**DO IT**’ command.

Enable left button command prompt actions Enabled, the **left button**, like the **right**, when clicked at the command prompt, will **repeat the prior command**.


Disabled, an **XP**, which is a **custom add-on module**, can intercept the left click at command prompt and perform a **custom action**. Unless you have a **custom XP** add-on installed that uses this, you will see no difference when **Enabled** or **Disabled**.

Group parts on insertion Check this box if you want drawings that you insert with the **INSERT PART** command to automatically be **GROUPED**. Remember that if the drawings you are inserting have **GROUPED** entities already, this will create an additional nested **GROUP**. If you need to use single entity edit commands on **GROUPED** entities you will need to click the **Locked button**, edit the entities and then click the **Unlocked button** again to lock the **GROUPS**. If this box is unchecked, inserted drawings will **NOT** be **GROUPED**.

Use tooltip color for control background This allows the Windows tooltip background color to apply to the **status bars** and command line. This can be useful in making the text in these windows stand out. You could set your Windows **tooltip text color to white** and the **tooltip background color to black**. This makes the text much easier to read.

Draw high resolution conics (slower) Enabled this makes the **CIRCLES**, **ARCSW** and **SPLINES** look much smoother on the screen. Screen refreshes will be slower on older video cards and computers especially if you have a large number of these entities in the drawing. The visual quality of these entities on the screen has no effect on the printed output. The quality of the printed drawing is totally dependent on the printer drivers resolution setting.


Display Cursor Tracking Tooltip This turns on the floating command line with the **xy tracking** and the **command prompts** for the **current command** and follows the cursor arrow as you move it around the screen.



Because the command line prompts are displayed at the cursor location you can focus your attention there and not have to look at the command line at the bottom of the screen.

Display frozen Layers in Gray. When this **OPTION** is **ENABLED** all entities that are on **currently frozen Layers** will be displayed in **GRAY**. This makes it easy to know which entities are on **FROZEN LAYERS** at a glance.

Pick Aperture The value entered here determines the *pixel size* of your *entity selection pick box*. The *pick box* is displayed when you select entities, usually during draw or edit commands. Changing this value is helpful if your screen resolution is finer or coarser than usual, or if extreme precision is required for your entity selections. The *default aperture size is 4 PIXELS*. The current setting is saved for all sessions until you change it again.



Text equivalent: **OPTIONS**


DWG/DXF Options

The **DWG/DXF Options** command allows you to save your **EasyCAD** drawing to a specific version of **AutoCAD**®'s native **DWG** or **DXF** file formats. When you use the **SAVE AS** command to save to a **DXF** or **DWG** format, it will save to the version you specify here. The option you select is saved in the registry, so it will persist for future **EasyCAD** sessions.

To set the **AutoCAD**® **SAVE AS** version, click to expand the drop list, select the desired version, then choose the **OK** button.

By default, **EasyCAD** saves to the **AutoCAD**® **release 11, 12** or **LT** file format specifications. These version offer the most versatility since newer releases of **AutoCAD**® can successfully import this drawing format. However, you can specifically direct the output to **release 13, release 14** and **AutoCAD**® **2000** file formats. **AutoCAD**® releases earlier than 11 are typically not in use, but **EasyCAD** gives you the option of saving to release 2.5, 2.6, 9, and 10 specifications.

DWG/DXF Conversion Options dialog box



Expand specified extents by 1% to insure all edge-bounding lines are received by the receiving program

Check this option if edge entities are not displaying properly (i.e., they are not visible) after importing into another program. This instance may occur when your image is brought in as **DXF** clip-art to a **non-CAD** application such as word processor.

Explode dimensions for exact visual similarity to the original drawing

Check this option to *explode dimensions* to component text, lines, arcs, polys, etc. Doing so will ensure that the dimensions will appear positionally correct after import/export. If not checked, dimensions are converted to associative dimension entities, but may not visually match. The following associative dimension entities are supported by this option:

Optimize text width scaling based on the assumption that text originated in .FC7 file

If you convert **AutoCAD®** .DWG or .DXF files you may consider purchasing or obtaining some **AutoCAD®** .SHX *vector text fonts*. These .SHX vector fonts should reside in the \EasyCAD7 home directory. When you *import* .DWG or .DXF files and you have the .SHX font file it uses, you will see them in the drawing. If you do **NOT** have the .SHX font it references, **EasyCAD** will substitute the **Arial TrueType®** *bitmapped font*. When **TrueType®** fonts are substituted, the *font metrix* will change a bit each time you *import* or *export* to **DWG** or **DXF format**. If you use the **AutoCAD®** .SHX vector fonts, the text will make a perfect round trip and always look the same.

Info Commands

Getting information about your drawing

Commands under the **Info menu** calculate and display coordinates, angle, distance, and area of entities. Others count and total entities as well as provide information about them.

LIST displays entity properties and geometry for selected entities.

EXTENTS returns the drawing coordinate extents.

COUNT ALL totals all entities by type.

COUNT totals selected entities by type.

CUURDINATE displays the x,y,z coordinates of any specified location.

BEARING calculates the angle between two points.

DISTANCE calculates the distance between two points.

DISTANCE... calculates the distance between two points, returning extended info.

LENGTHALONGTH calculates the distance along an entity.

AREA calculates the area of a specified polygon.

CALCULATE returns the solution of an algebraic expression.

List

The **LIST** command displays the entity properties and geometry for each entity selected. For example, you can review the coordinates of an entity, the layer it resides on, its color and style characteristics, etc.

To get an entity **LIST**, select [**Info > List**]:

1. Select the entities you wish to obtain information on.
2. **EasyCAD** displays a scrollable text window of information for each entity selected. Use the scroll bar to view more pages. To close the window and return to your drawing, press **esc** or click the *Close icon*.

Note: Even though **LIST** displays all relevant properties of each selected entity, you cannot select or change anything in the list display. However, from the text window's title bar, you can click the *Print icon* to print the contents, or the *Save icon* to save the contents to a specified text file.

Entity properties typically returned by the [**Info > List**] command:

- **Entity type and tag number.**
- **Outline color: # (RGB)**
- **Fill color: # (RGB)**
- **Line style: name (#)**
- **Fill Style: name (#)**
- **Material: name (#)**
- **Lyer: name (#)**
- **Sheet: name**
- **Workplane: name (#)**
- **Pen thickness: mm**
- **Line width**
- **All geometric parameters that FastCAD uses to construct the entity.**
- **Node lists of paths, polygons, and splines.**
- **Groups, multipolys, and their sub-records.**
- **Text specifications.**
- **Area of polygons.**

For any *symbol reference*, **LIST** displays the **name**, **insertion point**, **scaling**, and **rotation**. You cannot select *symbol definitions* using **LIST**. Instead, select the [**Insert > List SymDef...**] command to see list information about *symbol definitions*.

Text equivalent: **LIST**

Extents

The [**Info > Extents**] command lists the drawing extents in a dialog box. The drawing extents are the boundary coordinates (in drawing units) that would include every entity in your drawing, regardless of whether or not it were visible.

Sometimes, a drawing with very large extents, especially relative to the intended drawing area, can cause problems. For instance, if you were drawing a three-inch widget detail and you accidentally create/copy/move a rivet two miles away, your zooms and selection windows may behave erratically. Use this command to check the drawing extents.

Text equivalent: **EXTENTS**

Count All

The **COUNT ALL** command totals all entities for an entire drawing, and displays quantities sorted by entity type.

When you invoke [**Info > Count All**], **EasyCAD** displays a text window with as much information as will fit on one screen. Use the scroll bar to view more pages or close the window to return to your drawing.

Text equivalent: **COUNTA**

Count

The [**Info > Count**] command displays the quantity of selected entities, sorted by entity type (like **LIST** without the detail).

When you invoke **COUNT**, select entities using normal methods. **EasyCAD** then displays a text window with as much information as will fit on one screen. Use the scroll bar to view more pages or close the window to return to your drawing.

Text equivalent: **COUNT**

Coordinate

[**Info > Coordinate**] displays the *x,y,z coordinates* of any specified location in your drawing.

To get the *coordinates* of any point, select [**Info > Coordinate**]:

. The prompt reads "**Point to identify:**". Pick a point in a drawing window.

EasyCAD displays the *x,y,z coordinates* in a message box, using the current distance display format (feet-and-inches, numeric, etc.) as specified by the **UNITS** command [**Specs > Units**]. Click **OK** to clear the message.

Text equivalent: ID

Bearing

BEARING calculates the *angle* (measured counterclockwise, from zero degrees at 3 o'clock) of an imaginary line between two points. (**elevation**).

To calculate the angle between two points, select [**Info > Bearing**]:

1. The prompt reads "**1st point:**". Pick a point in a drawing window, or type coordinates.
2. The prompt reads "**Next point [done]:**". Specify a second point.

EasyCAD displays the angle from the first point to the second point in a message box. Click **OK** to clear the message.

Text equivalent: BEARING

Distance

[Info > Distance] calculates the *distance between two points you pick*.

To calculate the *distance between two points*, select [Info > Distance]:


1. The prompt reads "**Distance from:**" Pick a point in a drawing window, or type numeric coordinates.
2. The prompt reads "**Distance to:**". Specify a second point. **EasyCAD** displays the distance in a message box, using the current distance display format (feet-and-inches, numeric, etc.) as specified by the **UNITS** command [Specs > Units]. Click **OK** to clear the message.

Note: You can also use the **LIST** command [Info > List] to find the length of an existing line entity.

Text equivalent: DIST

Distance...

[Info > Distance...] calculates the *distance between two points*, returning the *bearing, distance*, and delta *x,y,z between* two specified points. This information is displayed in a dialog with edit controls so that ^C can place the values on the *clipboard*.



Distance Information dialog box

To calculate the *distance between two points*, select [Info > Distance...]:

1. The prompt reads "**1st point:**". Pick a point in a drawing window, or type numeric coordinates.
2. The prompt reads "**Next point [done]:**". Specify a second point. **EasyCAD** displays the bearing, distance, and *x,y,z distance* in a message box, using the current distance display format (feet-and-inches, numeric, etc.) as specified by the **UNITS** command [Specs > Units]. Click **OK** to clear the message.

Information in this dialog can be highlighted and copied to the *clipboard* by pressing **CTRL+C**.

Text equivalent: DIST2

Length Along

[Info > Length Along] calculates the *distance along an entity between two points* on that entity.

To measure the *length along on an entity*, select [Info > Length along]:

1. The prompt reads "**Select entity:**" Select an entity with the pick cursor.
2. The prompt reads "**From point on entity [all]:**" Specify a starting point. If you right-click or press ENTER, the entire length of the selected entity will be displayed.
3. If you selected a point on the entity, the prompt reads "**To point on entity:**" Select the ending measurement point on the entity.
4. **EasyCAD** displays the distance in a message box, using the current distance display format (feet-and-inches, numeric, etc.) as specified by the **UNITS** command [Specs > Units]. Click **OK** to clear the message.

Text equivalent: **LENGTH**

Area

[Info > Area] calculates the *area* bounded by an *imaginary polygon*, a *real polygon*, a *smooth polygon*, a *circle*, or an *ellipse*.

To measure the *area* on your drawing, select [Info > Area]:

1. The prompt reads "**1st point [enter to select]:**"
 - Right-click or press **ENTER** to select a *circle*, *ellipse*, or *poly* entity with the pick cursor. **EasyCAD** displays the *area* in a *message box*. Click **OK** to clear the message.
 - Specify a start point for a polygon used to describe the bounded area you are measuring.
2. If you picked a point with the mouse, the prompt reads "**Next point:**". Specify a second point, then continue picking points around the area you want to measure.
3. Right-click to complete the imaginary polygon. **EasyCAD** displays the area in a message box. Click **OK** to clear the message.

Text equivalent: **AREA**

Calculate

The [Info > Calculate] command accepts an *algebraic expression*, including parenthetical expressions, and returns the solution value in a message box.

Text equivalent: **CALC**

Macro Commands

Automate your tasks with simple macro or scripts

You can use **EasyCAD**'s macro facility to increase your efficiency, especially if you use repetitive and complex command sequences to accomplish tasks. A macro is simply a series of **EasyCAD** commands that are performed in sequence. But instead of typing the commands, they are run automatically from a script you write. A macro can be very simple or very complex.

Technically, here is how macros work: **EasyCAD** keeps a lookup table or dictionary of macro names and their definitions. Whenever **EasyCAD** gets a term (a word or value ended by a delimiter) from your typing, from a script, or from a menu, it checks the macro table to see if that term has been defined as a macro name. If it has, **EasyCAD** replaces the macro name with the stored text (the macro code you have written).

You can store text in a macro name, either by defining a name with the **Macro** and **Endm** (End Macro) commands, or by using the name as a destination variable for a command like **GV** (Get Value). The stored text can be:

- A single value (for example, **2** stored in the name **RED**);
- A renamed command (for example, **DSTYLE** stored in the name **Dims**);
- A command with one or more parameters (for example, the name **Square** could contain **Rpoly 4** to let you start a 4-sided regular polygon by typing "Square");
- A series of commands making up a macro program.

You can use text equivalents of **EasyCAD**'s menu commands in a macro program. You can also use the special macro programming commands explained in the **Macro Command Reference** (reference **EasyCAD**'s on-line **Help facility**). These special commands let you write programs that:

- Ask the user to enter points, values, text, and other data (prompting for user input);
- Store the data in variables;
- Use the stored data in drawing and editing operations;
- Make calculations based on stored data (calculating with variables);
- Compare values in variables and make decisions based on the results (controlling program flow);

- Jump to a label within the macro or repeat a series of commands (controlling program flow);
- Call other macros as subroutines, for up to 16 levels of nesting.

You do not have to write programs to use the special macro commands. For example, if you want to draw several lines radiating from a common point, you could use **GP** (**GET POINT**) to store the point in a *function key*, then press the key to enter the first point of each line. Using macro commands from the keyboard can help you learn how they work. If you intend to write complex macros (using branching, looping, and so on), this discussion assumes that you are already familiar with basic programming concepts.

Quick Primer on Macro Creation

About Delimiters

A delimiter tells **EasyCAD** where a command or parameter ends. A delimiter can be a **space** (); a **semicolon** (;); the **equal sign** (=); the **ENTER** key (**carriage return**); the **TAB** key; or the **right mouse button**.

When you define macros, you should keep these rules in mind:

1. Some commands require an *extra delimiter* before your macro can continue to the next command. These include:
 - Commands that automatically repeat or continue until you press the right mouse button to end them. Examples include many **DRAW** commands.
 - Commands like **DISTANCE** (in the *Info menu*) that display an alert box.
2. **SPACEBAR** or **TABs** are always a *delimiter* except in the parameters (responses) that follow these commands:
 - **Dprompt** (Some text that asks for some input).
 - In values to be entered in editable dialog-box items.
3. **SEMICOLON** is always a delimiter inside a macro definition. Because a semicolon does act as a delimiter in a script or macro, it is impossible to include literal semicolons in macro parameters.
4. **ENTER** (carriage return) and the right mouse button only work from the keyboard. **EasyCAD** “counts” the carriage returns that end each line in a macro, menu, or script file.

About Function keys

A **function key** (for example, **F2**) is a special kind of macro name. The **function key F1** is special: it provides context-sensitive help anywhere in the program and cannot be used for anything else. Also, the **F10** key is used by Windows to access the menu bar, as is the **ALT** key. **EasyCAD** recognizes the rest of the function keys, the **10 standard function keys (F2-F9, F11, F12)** and the same keys combined with the **CTRL** key, and/or the **SHIFT** key. You can refer to a function key by its name (**F2**, **CF1**, **SF6**,

SCF9, etc.), or just press the key or key combination.

1. To define a function key in a macro file, enter **Macro**, then the name of the function key (**F4**, **SF1**, etc.), then the text you want to store in it.
2. Enter “**Endm**” on a line by itself to end the definition. Function key variables are also useful when you are working within **EasyCAD** for storing a point or a value to use over and over during a work session. Define the function key with the **Macro** and **Endm** commands, or use a **Get** command like **GP (Get Point)** to store data in a function key.

Note: In **ECW7.MNU**, several function keys have been predefined to select modifiers. For example, **F4** enters the **CEN (Center)** modifier. Several **CTRL-alpha** keys (**^A**, **^S**) are also defined there.

Programming macros

Unlike true programming languages, a macro language does not know the difference between a macro used as a program, a macro used as a variable (a point, value, or other data), and literal text (a **EasyCAD** command, a file name, or text to be drawn). It is up to you to avoid name conflicts.

Terms that would be macro expanded can avoid expansion by preceding them with an exclamation mark (!). This lets you define a new macro called **Color** that can call **COLOR (EasyCAD's color command)** inside itself, yet use the original command.

Within a macro table, make sure that each variable, label and macro name you use is unique. Also, never use a **EasyCAD** command (text equivalent) as a macro name (unless you want to redefine what that command does). Never use numbers as macro or variable names. Try to avoid using file names. If you write macros for other users, consider starting all **macro**, **label**, and **variable names** with a **dollar sign (\$)** or some other unlikely character to avoid name conflicts.

Variables are never further expanded. A value defined with **macro...endmacm** will be expanded as long as necessary.

To run a macro, type its name. You can also run a macro by including it in a customized menu. But remember, a macro will run only if its **macro definition** is loaded (as a **.MAC** file) along with the **menu (.MNU)**.

A macro can call another macro by name, effectively running it as a subroutine. **EasyCAD** allows up to 16 levels of nested macros. When **EasyCAD** finishes performing the text in the called macro, or executes an **exitm** command, control returns to the next command in the calling macro. Under some conditions (such as the user canceling by pressing the right mouse button at a prompt), you may want to end all macros and return to the “**Command:**” prompt without returning to the calling macro. To do this, use **Exitam (Exit All Macros)**.

Load Macros

[**Macros > Load Macros**] clears any existing macro definitions, then loads a new macro table from a macro file. (This is faster than defining macros by using **EDIT MACRO**.)

To use, type a file name or select a file with the mouse. You need to select an existing macro file that ends in a *.mac* file name extension.

By default, when you start a work session, **EasyCAD** looks for the file **FC7.MAC**, and automatically loads the file if it finds it in the current directory. **EasyCAD** has provided this file to demonstrate some of the basic macro programming principles.

You can use the **LOADMACM** command to bypass the dialog box. This can be helpful if you are using a macro to load a new macro file. This action resets the variable table—**EasyCAD** ignores everything in the current macro after it encounters **LOADMACM <filename>**.

Text equivalent: **LOADMAC**

Edit Macros

When you select [**Macros > Edit Macros**], **EasyCAD** displays a text-editing window with which you can *edit* or *modify* the *current macro table*. While typing, you can:

- Use the keyboard **ARROW** keys, **HOME**, and **END** to move the cursor within the editing window;
- Press **DEL (Delete)** to delete the character under the cursor;
- Press **BACKSPACE** to delete characters to the left of the cursor;
- Type special characters using the **ALT** key.
- Use Window's **Cut (^X)**, **Copy (^C)**, and **Paste (^V)** functions to transfer text in and out of a plain-text word processor, like **Notepad**.

The current macro table is the area in memory that **EasyCAD** uses to store the active macro definitions. As such, if you make changes to the current macro table, they will be forgotten at the end of the session or when another macro file is loaded in its place. Use **SAVE MACROS** to make those changes permanent in a macro file.

Text equivalent: **EDITMAC**

Save Macros

[**Macros > Save Macros**] saves all existing macro definitions to a macro file for later loading with **LOADMAC**. Type a file name or select a file with the mouse. Use caution when saving over an existing macro file. The best strategy is to create, edit, and test a set of macros using small, individual macro files. Do not save the macros in one big macro file until they are thoroughly debugged, and keep a backup copy of the macro files in case you want to change the macros later.

Text equivalent: **SAVEMAC**

Clear Macros

[**Macros > Clear Macros**] completely *clears* the *macro table*, eliminating all macro, *label*, *function key*, and *variable definitions*. If your macros do not work and you cannot figure out why, *conflicting macro* and *variable names* are usually to blame. Use **CLEAR MACROS**, then reload the macros *one at a time* from their individual files.

Text equivalent: **CLEARM**

List Variables

The [**Macros > List Variables**] command displays the current variables and their associated values. Listed variables may have been processed directly from a macro or from the keyboard. Variables persist until the current **EasyCAD** session is closed, the **CLEAR MACROS** command is used, or **EDIT MACROS** is used and the macro has been modified. The variable list is presented in a text window.

Any time a macro instruction is processed, the variable and its value is appropriately appended or updated in the list. In this manner, the table can be a valuable macro debugging tool.

Text equivalent: **LISTVARS**

Save Variables

[**Macros > Save Variables**] creates a script that may be run with **SCRIPT** or **SCRIPTM** to restore the values of the current variables.

This command, and the ability to read saved variables, is helpful in a number of ways. For instance, you can use [**Macros > Save Variables**] to save calculated or retrieved values that you can pass on to another macro, or even to another application. You use one macro with different starting conditions, based upon user input, conditional tests, or other contexts. You can create a variable list with a text editor and save or edit it for use with your macros.

Typically, you will run **SAVEVARS** from a **macro**. The typical syntax is:

SAVEVARS <filename>

The **.scr** extension is automatically appended. The file is saved to the application path unless you specify otherwise.

To utilize the saved variables in a macro, use the **SCRIPTM** command:

SCRIPTM <filename>

Each line of the saved variable file is processed and loaded into memory. Macros can now utilize these macros as if they were initialized internally.

To manually create a variable list, use a text editor such as **NED**. For each variable you want to define, add a line using the following pattern:

GL;<variable name>;<variable value>

You do not need to specify the variable type (such as integer, word, line, etc.).

EasyCAD will determine the type based on the value assigned. Be sure to save the file as a regular text file with an **.scr** extension.


Text equivalent: **SAVEVARS**

Using Actions

ACTIONS allow you to make your drawings interactive. Like an Internet web page, you can define "**hotspots**" on your drawings that perform designated actions when you click on them with a mouse. These hot spots are called action buttons.



The cursor changes to a pointer whenever it crosses an action hotspot.



An action button is a hidden rectangular area in your drawing to which you attach a **EasyCAD** macro. When you activate the button by clicking it, **EasyCAD** executes the designated macro. Actions are ideal for interactive tutorials, live presentations, and for creating active graphic models - drawings that do something instead of just sitting there.

To see how actions can be used, load the supplied drawing **actdemo.FC7**. This drawing shows fluids moving through a system of pipes and valves. For each step in the actions sequence, layers are turned on and off.

A drawing with actions loads just like a regular drawing, except that its hotspots are always in an interactive state. (This behavior is different than in previous versions, where an action drawing had to be activated.)

Whenever you run a mouse over an action button, the cursor changes to a pointing cursor to let you know. To run the assigned function, just **click on the hotspot** (either a left-click or right-click works).

For example, move the mouse over the water valve. Note how the cursor arrow changes to the pointer hand. This indicates that you are over a hotspot. Click to open the valve. The previously empty pipe is now filled with water! Try the other hotspots and see if you can get light from the lamp. (Hint: the boiler needs water, fuel, and someone to hit the ignition switch.)

Define Action command

Use **[Macros > Define Actions]** to create or add action buttons to a drawing.

To *define* an *action button*, select **[Macros > Define Action]** from the menu.

1. **EasyCAD** opens an *Edit Text dialog box*. Type in a macro name or script text and click **OK**.

The macro name or script you enter here will activate when the action button is clicked. If using a macro, the macro must be defined in a loaded .mac file. To define macros, see the section titled "**Adding New Action Macros**".

2. The prompt reads "**Hotspot window:**". Pick two corner points in a drawing window to define the size and shape of the action button.

EasyCAD draws an *action* as a *rectangular frame around its active area*, with the attached macro name displayed below it. The label is there so you can select the action for editing.

Once the action is tested, you will probably wish to make the button and text invisible. First you need to label the button for the user. There are two approaches:

- Add a box (polygon entity) and text to describe what the action does. This approach models a Windows-type button.
- Draw actual objects over the action button. This way, the user can activate the invisible button by selecting the visible object. For example, the user can select a door to open or close it, select a flower to make it bloom, or view a detail of a mechanical assembly by selecting the part to be magnified.

To make action buttons visible, use **ACTVIS**.

To hide action buttons, use **ACTHIDE**.

Show Actions command

Use [**Macros > Show Actions**] to make action buttons visible. Action buttons are always active, even when they are hidden. However, if you wish to edit or delete an action button, you need to first make it visible.

ACTVIS works with all action buttons in your drawing. There is no way to select specific actions buttons to be visible or hidden. You can simulate this behavior by isolating certain buttons on different layers, and then hide or show those layers as desired. Note that action buttons on hidden layers still respond to user clicks.

Action buttons on hidden sheets are never visible or active.

To make all action buttons visible, select [**Macros > Show Actions**] from the menu.

• **EasyCAD** redraws the drawing with all buttons visible.

To hide all action buttons from view, use the **ACTHIDE** command [Macros > Hide Actions].

Hide Actions command

Use [**Macros > Hide Actions**] to make action buttons invisible to the user. *Action buttons* are always active, even when they are hidden. In most cases, you would hide the buttons from the user, using some other visual aid integral to the drawing to act as the hotspot indicator.

If you wish to edit or delete an action button, you need to first make it visible. To make action buttons visible, use the **ACTVIS** command [**Macros > Show Actions**].

ACTHIDE works with all action buttons in your drawing. There is no way to select specific actions buttons to be visible or hidden. You can simulate this behavior by isolating certain buttons on different layers, and then hide or show those layers as desired. Note that action buttons on hidden layers still respond to user clicks.

Action buttons on hidden sheets are never visible or active.

To hide all action buttons, select [**Macros > Hide Actions**] from the menu.

EasyCAD redraws the drawing with all buttons hidden (but still active).

Modifiers

Tools to help you draw with precision

Speed up with function keys

Many of the function keys have been preassigned to some of the modifiers using EasyCAD's standard menu.

For instance, if you needed to use the EPT (endpoint) modifier, you could hit the F5 key instead of choosing [Mod > Endpoint] from the menu, or typing EPT at the command prompt.

To see how each Function key is assigned, just pull down the *Mod menu*.

The **Mod menu** includes several modifiers that lock to exact points on existing entities. The use of modifiers are essential to precision drawing. Without them, you would have difficulty selecting the exact center of a circle, or the midpoint of a line, for instance.

Modifiers often work in conjunction with another drawing or editing command. When such a command prompts you to select a point or entity, use modifiers to precisely specify and narrow the selection.

EasyCAD's array of modifiers include the following:

- | | | |
|--------------------|--------------------|-------------------|
| • Endpoint | • Perpendicular to | • Tangent to |
| • Center | • Angle to | • Reference point |
| • Midpoint | • Percent along | • Same X |
| • Nearest point on | • Distance along | • Same Y |
| • Intersection of | • Bearing to | • Like |
| • Parallel to | | |

Each specific modifier is described in more detail later in this section. But let's start with a general overview of how to use a modifier:

1. Activate a command (such as **LINE**) that prompts for a point.
2. Select a modifier to lock the first point to an existing entity. **EasyCAD** asks what entity the modifier refers to.
3. Pick a point on the entity within the cursor's pick box. If **EasyCAD** does not find an appropriate entity after using the left mouse button once, you must re-select the modifier again, then continue with the command.


To specify a default, always ready-to-use modifier, use the **Attach mode**. Right-click the **Attach button** to specify a default modifier. Then make sure the **Attach button** is on (depressed). Now, whenever you are prompted for a point, that modifier is always active. It can be overridden by another modifier you select from the menu or type in.



Attach button

Modifiers always override **Button bar** settings such as **Snap**, **Ortho**, or **Attach**.

Endpoint modifier




Endpoint modifier icon

The **ENDPOINT modifier** locks to the **ENDPOINT** of certain entities. As with all modifiers, you must first select a drawing or editing command such as **LINE**. The prompt reads “**Endpoint os entity:**”. Select a point on the desired entity. **EasyCAD** will lock to the *nearest* endpoint. Please refer to the chart below for the effect of **ENDPOINT** on various types of entities.

<i>Entity</i>	<i>EPT locks on to</i>
Line <i>or</i> Line Arrow	Nearest end of line
Arc <i>or</i> Arc Arrow	Nearest end of arc
Dimension	End of leader closest to dimensioned entity
Polygon	First point on first node
Path <i>or</i> Path Arrow	End of total length nearest pick point
Circle	Nearest (0°, 45°, 90°, 135°, 180°, 225°, 270°, 315°) point
Ellipse	Nearest end of either axis
Point	On the point
Smooth Polygon	First point on first node
Spline <i>or</i> Spline Arrow	First or last node, nearest to pick
Text	Nearest end of text, along baseline

Text equivalent: EPT

Endpoint of seg modifier




The **ENDPOINT OF SEG** modifier locks to *segment endpoints*. It differs from the regular **ENDPOINT** modifier when you select *paths, polygons, splines*, and *SPolys*. When you use the regular **ENDPOINT** modifier on such entities, **EasyCAD** always locks to the *first or last points in the node list*. **ENDPOINT OF SEG locks to the node nearest your pick point**. For *splines* and *SPolys*, the *segment endpoint* is in part determined by the *spline resolution* set by the **SPLRES** command.

As with all *modifiers*, you must first select a drawing or editing command such as **LINE**. The prompt reads "**Endpoint of segment:**" and a pick box cursor is displayed. Pick a point on the entity segment you want the endpoint of. Please refer to the chart below for the effect of **ENDPOINT OF SEG** on various types of entities.

Entity	EPTS locks on to
Line	Nearest endpoint point of segment
Arc or Arrow	Nearest end of arc
Dimension,	End of leader on dimensioned entity
Path or Arrow	Nearest end of segment nearest to pick
Polygon	Nearest end of segment nearest to pick
Circle	Not applicable
Ellipse	Not applicable
Point	On the point
Smooth Polygon	Node nearest to pick (see SPLRES)
Text	Not applicable

Text equivalent: **EPTS (or press the function key F5)**

Center modifier



Center modifier icon

The **CENTER** modifier locks to the **center** of existing entities.

As with all modifiers, you must first select a drawing or editing command such as **LINE**.


The prompt reads “**Center of entity:**”. Select a point on the desired entity.

EasyCAD locks to the entity's **CENTER**. Please refer to the chart below for the effect of the **CENTER** modifier on various types of entities.

<i>Entity</i>	<i>CEN locks on to</i>
Arc, Circle, or Ellipse	Center
Arrow, Line, Path, or Polygon	Middle of entity's geometry
Dimension	<i>Not applicable</i>
Point	On the point
Smooth Polygon or Spline	Middle of entity's geometry
Text	Middle of text, along baseline

*Text equivalent: **CEN** (or press function key F4)*

Midpoint modifier



Midpoint modifier icon

The **MIDPOINT** *modifier* locks to the *midpoint* of certain entities.

As with all *modifiers*, you must first select a drawing or editing command such as **LINE**..


When you select **MID**, the prompt reads “**Middle of entity:**”. Select a point on the desired entity.

EasyCAD locks to the entity’s **MIDPOINT**t. Please refer to the chart below for the effect of **MID** on various types of entities.

<i>Entity</i>	<i>MID locks on to</i>
Arc	Halfway along arc
Arrow or Line	Middle of picked line
Path or Polygon	Middle of total length (between first/last nodes)
Dimension	<i>Not applicable</i>
Circle	180° on circle
Ellipse	End of major axis (opposite from start)
Point	On the point
SPoly or Spline	Middle of total length (between first/last nodes)
Text	Middle of text, along baseline

Text equivalent: **MID**

Midpoint of Seg modifier



The **MIDPOINT OF SEG** modifier locks to the *middle* of certain entities *segments* such as *polygon sides* and *path segments*..

As with all modifiers, you must first select a drawing or editing command such as **LINE**.

When you select **MIDPOINT OF SEG** modifier [Mod > Midpoint of seg] the prompt reads "Middle of entity:". Select a point on the desired entity.

EasyCAD locks to the entity's *segment* **MIDPOINT**. Please refer to the chart above for the effect of **MIDPOINT OF SEG** on various types of entities.

Text equivalent: MIDS (or press the function key F3)

Mid of 2 EPTS modifier

The **MID OF 2 EPTS** *modifier* allows you to *automatically* use the **ENDPOINT OF SEG** *modifier* on two *selected entities* such as *lines*, *splines* or the *segments of polygons* or *paths*.

As with all *modifiers*, you must first select a drawing or editing command such as **LINE**..

1. When you select the **MID OF 2 EPTS** *modifier* [Mod > Mid of 2 EPTS], the prompt reads “**Endpoint of segment:**”.
2. Select a point on the *1st entity* and the prompt again reads “**Endpoint of segment:**” Select a point on the *2nd entity*..

EasyCAD starts the *first point of the new LINE* midway between these two *segments* **ENDPOINTS**.

Text equivalent: **MID2;EPTS;^D;EPTS;^D;**

Mid of 2 CEN modifier

The **MID OF 2 CEN** *modifier* allows you *automatically* use the **CENTER** *modifier* on two *selected entities* such as *lines, circles, arcs, splines* or the *center of polygons* and *SPoly geometry*.

As with all *modifiers*, you must first select a drawing or editing command such as **LINE**..

1. When you select **MID OF 2 CEN** *modifier* [Mod > Mid of 2 CEN], the prompt reads “Center of entity:”.
2. Select the *1st entity* and the prompt again reads “Center of entityt:” Select the *2nd entity*..

EasyCAD starts the first point of the new **LINE** midway between these two entities **CENTER** points.

Text equivalent: **MID2;CEN;^D;CEN;^D;**

Mid of 2 MIDS modifier

The **MID OF 2 MIDS** *modifier* allows you *automatically* use the **MIDPOINT OF SEG** *modifier* on two *selected entities* such as *lines, splines* or the *segments of polygons* or *paths*.

As with all *modifiers*, you must first select a drawing or editing command such as **LINE**..

1. When you select **MID OF 2 MIDS** *modifier* [Mod > Mid of 2 MIDS], the prompt reads “**Middle of segment:**”.
2. Select a point on the *1st entity* and the prompt again reads “**Middle of segment:**”
Select a point on the *2nd entity*..

EasyCAD starts the *first point of the new LINE* midway between these two segments **MIDPOINTS**.

Text equivalent: **MID2;MIDS;^D;MIDS;^D;**


Nearest Point On modifier

The **NEAREST POINT ON** *modifier* locks to a point mathematically **ON** any entity selected within the cursor's pick box. As with all modifiers, you must first select a drawing or editing command such as **LINE**. The prompt reads "**Point on entity:**". Pick a point on the entity you want to lock on to. If you do not select an entity or valid point, **FastCAD** returns to the original prompt.

The **NEAREST POINT ON** modifier will supersede any **Snap** or **Attach** settings.

*Text equivalent: **ON** (or press function key F9)*

Intersection of modifier



Intersection modifier icon


The **INTERSECTION OF** *modifier* locks to *the point where two entities intersect*. As with all modifiers, you must first select a drawing or editing command such as **LINE**.

When you select **INTERSECTION OF** you are prompted for the "**Intersection point or 1st entity:**". If the pick box contains an intersection, it will automatically be selected. If you select an entity, but do not enclose an *intersection* in the pick box, you will see the "**2nd entity to intersect:**" prompt. Select a point on another entity and **EasyCAD** will automatically find their (**nearest**) **INTERSECTION point**..

Two selected entities don't actually have to cross. **FastCAD** will calculate the mathematical intersection of the entities.

*Text equivalent: **INT** (or press function key F6)*

Parallel To modifier




The **PARALLEL TO** modifier locks the rubber-band cursor **PARALLEL** to an existing *reference entity*. You can use **PARALLEL TO** whenever **EasyCAD** prompts you for a point. The *reference entity* can be a *line*, *text*, *polygon side*, *spline*, and so on. If you select a *circular reference entity*, such as an *arc*, *circle*, or *ellipse*, the direction is locked **PARALLEL** to the pick point's *tangent*.

Usually you will place at least one point before selecting **PARALLEL TO**. The prompt reads "**Parallel to entity at:**".

1. Select a point on the reference entity. **EasyCAD** returns to the command you were using, but now the rubber-band cursor locks to the same angle as the reference entity.
2. The prompt changes to "**Point along bearing line [distance]:**". Stretch the cursor in either direction until it looks the way you desire, then pick that point. To draw a line with an entered length (rather than one visually specified), type in a distance in drawing units. If the length is positive, the line is drawn towards the reference entity. If the length is negative, it draws away from the entity.

Text equivalent: **PRL (or press function key F11)**

Perpendicular To modifier




The **PERPENDICULAR TO** *modifier* locks the rubber-band cursor **PERPENDICULAR** to (at right angles to) an existing *reference entity*. You can use **PERPENDICULAR TO** whenever **EasyCAD** prompts you for a point. The *reference entity* can be a *line*, *text*, *polygon side*, *spline*, and so on. If you select a *circular reference entity*, such as an *arc*, *circle*, or *ellipse*, the direction is locked **PERPENDICULAR** to the pick point's *tangent*.

Usually you place at least one point before selecting **PERPENDICULAR TO** (or pressing **F12**). The prompt reads "**Perpendicular to entity at:**" and the cursor changes to a pick box.

1. Pick a point on the reference entity. **FastCAD** returns to the command you were using, but now the rubber-band cursor locks at the angle of the reference entity plus (or minus) **90°**.
2. The prompt changes to "**Point along bearing line [distance]:**". Stretch the cursor in either direction until it looks the way you desire, then pick that point. To draw a line with an entered length (rather than one visually specified), type in a distance in drawing units. If the length is positive, the line is drawn towards the reference entity. If the length is negative, it draws away from the entity.

Text equivalent: PRP (or press function key F12)

Angle To modifier



The **ANGLE TO** modifier locks the rubber-band cursor at an angle you specify to an existing reference entity. You can use **ANGLE TO** whenever **EasyCAD** prompts you for a point. The *reference entity* can be a *line*, *text*, *polygon side*, *spline*, and so on. If you select a *circular reference entity*, such as an *arc*, *circle*, or *ellipse*, the direction is locked relative to the pick point's *tangent*.

1. Usually you will place at least one point before selecting **ANG**. The prompt reads "**Degrees bearing:**". Type a positive or negative angle, which can include amounts like **11.05** or **22+1/2**.
2. Now the prompt reads "**At angle to entity at:**", and the cursor changes to a pick box. Pick a point on the reference entity. **EasyCAD** adds the angle you entered to the angle of the reference entity, locking the rubber-band cursor to the resulting angle.
3. The prompt changes to "**Point along bearing line [distance]:**". Stretch the cursor in either direction until it looks the way you desire, then pick that point. To draw a line with an entered length (rather than one visually specified), type in a distance in drawing units. If the length is positive, the line is drawn towards the reference entity. If the length is negative, it draws away from the entity.

Text equivalent: **ANG**

Percent Along modifier

The **PERCENT ALONG** *modifier* selects a point at a specified **PERCENTAGE** of the *reference entity's length*. For most referenced entities, **PERCENT ALONG** treats the *nearest endpoint from the selection point as its beginning*. For example, **75%** of a line is three-fourths of the way along its length, starting at the end nearest the selection point.

1. As with all modifiers, you must first select a drawing or editing command such as **LINE**. The prompt reads “**% along:**”.
2. Enter a number. For example, to select a point **1/4** of the way along a line, type “**25**” and press ENTER. Now the prompt reads “**along entity:**”.
3. Select a point on the entity you want a percentage of (remember that the selection point on the reference entity controls which end **EasyCAD** starts from when calculating the percentage distance). You can use percentage values less than **0%** or more than **100%** on some entities. For example, you could use **125%** to select a point **1/4** of the way beyond the end of a line.

<i>Entity</i>	<i>% locks on to</i>
Arc,	% length, from nearest picked end.
Arrow, Dimension, or Line	% line length, from nearest picked end.
Path or Polygon	% overall length, from nearest picked end.
Circle	% circumference length from 0°, from direction closest to pick.
Ellipse, Elliptical Arc	<i>Not applicable.</i>
Point	On the point.
SPoly or Spline	% length along curve, from nearest picked end. (values <0% or >100% act like 0%)
Text	<i>Not applicable.</i>

Text equivalent: %

Percent Along seg modifier

The **PERCENT ALONG SEGMENT** *modifier* selects a point at a *specified percentage of the reference entity's segment length*. For most referenced entities, %S treats the *nearest endpoint from the selection point as its beginning*. For example, **75%** of a line is three-fourths of the way along its length, starting at the end nearest the selection point.

This command differs from the regular **PERCENT ALONG** *modifier* when certain entities are picked. % considers an entire **path, poly, or spline length** when determining *distance along*, whereas %S considers only the selected **path, poly, or spline segment**.

1. As with all modifiers, you must first select a drawing or editing command such as **LINE**. When prompted for a point, select **[Mod > Percent Along seg]**.
2. The prompt reads "**% along:**". Enter a number between **0** and **100**. For example, to select a point **1/4** of the way along a line, type **25** and press **ENTER**.
3. Now the prompt reads "**along segment:**", and the cursor changes to a pick box. Pick a point on the entity you want a percentage of (remember that the selection point on the reference entity controls which end **EasyCAD** starts from when calculating the percentage distance).

EasyCAD snaps the point as specified.

Note: On some entities, you can use percentage values less than **0%** or more than **100%**. For example, you could use **125%** to select a point **1/4** of the way beyond the end of a line.

Entity	%S locks on to
Arc	% length, from nearest picked end.
Arrow, Dimension, or Line	% line length, from nearest picked end.
Path or Polygon	% segment length, from nearest picked node.
Circle	% circumference length from 0°, from direction closest to pick.
Ellipse, Elliptical Arc	<i>Not applicable.</i>
Point	On the point.
SPoly or Spline	% segment length, from nearest picked node. (values <0% or >100% act like 0%)
Text	<i>Not applicable.</i>

Text equivalent: %S (or press function key F7)

Distance Along modifier


The **DISTANCE ALONG** *modifier* selects a point at a specified **DISTAAANCE** of the *referenced entity's length*. For most referenced entities, **DISTANCE ALONG** treats the nearest endpoint from the selection point as its beginning.

1. As with all modifiers, you must first select a drawing or editing command such as **LINE**. To invoke the **DISTANCE ALONG** *modifier*, select [**Mod > Distance Along**], or press **F8**.
2. The prompt reads "**Distance:**". Enter a *length* or *distance* value. For example, to select a point 1.5 inches of the way along a 10-inch line, type 1.5 and press enter. Now
3. The prompt reads "**Along entity:**" and the cursor changes to a pick box. Pick a reference entity. Where you select the point determines which end **EasyCAD** starts from when calculating the distance. You can use distance values less than 0 on some entities. For example, you could use -2 to specify a point 2 units beyond the end of a line.

Entity	DIST locks to
Arc	Distance along circumference, from nearest end
Arrow, Dimension, or Line	Distance from nearest end point
Path or Polygon	Distance (overall) from nearest start/end node
Circle	Distance along circumference, counter-clockwise from 0° end
Ellipse, Elliptical Arc	<i>Not applicable</i>
Point	On the point
SPoly or Spline	Distance along curve, from nearest start/end node (values <0 act like 0)
Text	<i>Not applicable</i>

*Text equivalent: **DIST** (or press function key F8)*

Degrees on modifier



The **DEGREES ON** modifier selects a point at a specified *number of DEGREESs around an arc, circle, ellipse, or elliptical arc*. Angles are measured **counterclockwise** from **zero degrees at 3 o'clock**.


First select a drawing or editing command such as **LINE**. When prompted for a point, invoke the **DEGREES ON** modifier.

1. The prompt reads "**Degrees bearing:**". Enter an angle value. For example, to select the 1 o'clock point on a circle, type "60" and press **ENTER**.
2. The prompt reads "**Degrees relative to entity:**" and the cursor changes to a pick box. Pick a point on the reference entity.

Note: On an *ellipse* or *elliptical arc*, **DEGREES ON** selects points at a true bearing angle from the *center* of the *ellipse*. For example, points 10° apart around an ellipse are *not* evenly spaced on its circumference.

Text equivalent: **DEG**

Bearing Angle modifier




The **BEARING ANGLE** *modifier* locks the rubber-band cursor to a **BEARING ANGLE** that you specify. You can use **BEARING ANGLE** whenever **FastCAD** prompts you for a point. Unlike **PARALLEL TO**, **PERPENDICULAR TO**, and **ANGLE TO**, this *modifier* doesn't ask for a reference entity—the angle is measured counter-clockwise from 0° at 3 o'clock (horizontal). The **BEARING ANGLE** *modifier* works a little like *polar coordinates*, except that here you may specify distance visually instead of typing both an angle and distance.

Usually you will place at least one point before selecting **BEARING ANGLE**.

1. The prompt reads "**Degrees bearing:**". Type a positive or negative angle, which can include amounts like **11.05** or **22+1/2**. **EasyCAD** returns to the command you were using, but now the rubber-band cursor locks to the angle you specified.
2. The prompt changes to "**Point along bearing line [distance]:**". Stretch the cursor in either direction until it looks the way you want, then select the next point for your command. You can choose to enter a specified length. **EasyCAD** then snaps to the specified distance in the specified bearing.

Text equivalent: **BRNG**

Tangent to modifier



The **TANGENT TO** *modifier* selects a point on a **circle**, **arc**, **ellipse**, **spline**, or **smooth polygon** that forms a **TANGENT** from the last point selected. You can use **TANGENT TO** whenever **EasyCAD** prompts you for a point.

Usually you will place at least one point before selecting **TANGENT TO**. First select a drawing or editing command. When prompted for a point, invoke the **TANGENT TO** modifier.

- The prompt reads “**Tangent to entity:**” and the cursor changes to a pick box. Select an entity near the desired point of tangency.

EasyCAD draws the line or line segment tangent to that entity.

Text equivalent: **TAN**

Change @ Ref Point modifier

EasyCAD stores the coordinates of the last point used in drawing or editing an entity - for example, the end of a line. **EasyCAD** uses this stored point as a reference point for the **SAME X (vertical-lock)** and **SAME Y (horizontal-lock)** modifiers and to calculate the three forms of relative coordinates. You can use the **CHANGE @ REF POINT** modifier to change the *reference point* to *any other point*.

First, select a drawing or editing command, then select **CHANGE @ REF POINT**.

The prompt reads "**@ Reference point:**". Specify a new point by picking a point on the screen, or by typing numeric coordinates. **CHANGE @ REF POINT** is especially effective used in combination with other modifiers to set the *reference point* to the *endpoint*, *center*, etc., of an existing entity.

Text equivalent: REF

Same X modifier

The **SAME X modifier** is a special *modifier* that *aligns points VERTICALLY* with the *reference point* by keeping the **x coordinate the same as the last point**. (It's like a one-time **ORTHO** lock.) First select a drawing or editing command, specify the first point in the command, and then invoke the **SAME X modifier**.

- **EasyCAD's** prompt doesn't change. When you specify the next point, **EasyCAD** locks the point to the nearest point that lines up vertically with the last point used in drawing or editing.

For an example of **SAME X** used in drawing a line, start the **LINE** command, and then specify the first point.

1. When **EasyCAD** prompts for "**Next point:**", select **SAME X** from the Mod menu.
2. The prompt still reads "**Next point:**". Using the mouse, pick a point on the screen. **EasyCAD** draws the line from the first point to a point directly above or below the first point (depending on where you picked). In other words, **EasyCAD** gives the new point the same x coordinate as the first point, while using the **y coordinate** you picked with the cursor.

You can combine **SAME X** with **CHANGE @ REF POINT** to align a new entity with an existing entity. For example, to align a *new circle* with the *center* of an *existing circle*: Select **CIRCLE > RADIUS & CENTER [Draw > Circles > Radius and Center]**. When **EasyCAD** asks for a *center point*, select **CHANGE @ REF POINT** from the *Mod menu*. Then select **CEENTER** from the *Mod menu*, and pick an existing **circle**. **EasyCAD** resets the reference point to the *center* of the **circle**. The prompt reads "**Center point:**" again. Select **SAME X** from the *Mod menu*, then select a point below the *old circle*. **EasyCAD** draws the *new circle* with its *center* perfectly aligned with the *center* of the *old circle*.

Text equivalent: SAMEX

Same Y modifier

The **SAME Y** *modifier* is a special *modifier* that *aligns points HORIZONTALLY* with a *reference point* by keeping the **y coordinate the same as the last point**. (It's like a one-time **ORTHO** lock.) First select a drawing or editing command, specify the first point in the command, and then invoke the **SAME Y** modifier.

EasyCAD's prompt doesn't change. When you specify the *next point*, **EasyCAD** locks the point to the *nearest point that lines up horizontally with the last point used in drawing or editing*.

Text equivalent: **SAMEY**

Like modifier

Learn to Like Like and Keep Like

LIKE is an often underutilized modifier that can speed up your work considerably.

KEEP LIKE can quickly reset all your current drawing properties to that of an existing entity you select. Such properties include color, layer, line style, fill style, line width, pen thickness and text and dim styles if applicable. If you use many different properties in your drawing, KEEP LIKE can do in two steps what would otherwise take dozens!

The LIKE modifier isn't quite so powerful. But its use still precludes many dialog box selections you might otherwise make.

Because the LIKE modifier snares the property values from the entity, you don't need to know what those values are beforehand. That might save you a few [Info > List] calls.

The **LIKE** modifier allows you to *select an entity and use all of its properties (layer, color, line style, fill style, line width, pen thickness, dimension style etc.) and apply them to the next entity you will draw. EasyCAD's default properties settings are NOT effected.*

This is a very quick way of *using all the properties of an existing entity at once and applying them to only the next entity you draw.* This bypasses the need to reset each property from various dialog boxes such as *Text Properties, Layer Management* etc. for just drawing one entity and then having to reset them back for the next new entities you will draw.

If you are using the **CHANGE** command to modify only one property of one or more entities such as *color, pen thickness, layer* etc. the **LIKE** modifier is a real time saver.

For example, **LIKE** can help you *change the color of selected entities to be the same color as an existing entity:*

1. Use the **CHANGE COLOR** command [Edit > Change > Color] to select the entities whose *color* you wish to modify.
2. After choosing **OK-Do it**, the prompt reads "Color value [dialog]:".
3. Select [Mod > Like] (or press F2).
4. The prompt reads "Like entity:".
5. Select an entity that has the *desired color*. All selected entities will now have the desired color.

Another example is to move all entities that share a common layer:

1. Use the **MOVE** command and select by *Layer*. The prompt reads "Layer name or # [dialog]:".
2. Select [Mod > Like] (or press F2).
3. The prompt reads "Like entity:".
4. Select an entity that you know is on the *desired layer*. All entities that share that *layer name* will be selected for the **MOVE** command.

If you wish the *properties of the selected entity to persist*, use the **KEEP LIKE** command (*see below*) instead.

Text equivalent: LIKE (or press function key F2)

Keep Like modifier

The **KEEP LIKE** command allows you to *select an entity and use all of its properties (layer, color, line style, fill style, line width, pen thickness, dimension style etc.) and apply them to all new entities you will draw. These properties reset all of the previous default property settings*.

This is a very quick way of resetting all properties at once without going to each dialog box such as *Text Properties, Layer Management* etc to do so.

KEEP LIKE makes current (for all new entities to be drawn) the following entity properties: *to*

- **Color**
- **Fill (2nd) color**
- **Pen thickness**
- **Layer**
- **Line style**
- **Fill style**
- **Pen Thickness**
- **Line width**
- **Text properties**
- **Dimension properties**

For instance, if you wish to draw all new entities that will have the same *properties as an existing entity* (but different from your current settings),

1. Select the **KEEP LIKE** command [**Mod > Keep Line**].

The prompt reads “**Keep properties of entity:**”.

2. Select the existing entity that uses the properties you want the *new entities to use*.
3. Select the **LINE** command and draw a **LINE**. The new line, as well as all new entities, will draw with the *same properties as the entity you previously selected*.

NOTE: You may use the **KEEP LIKE** command in the *middle* of a **DRAW** command. Say you selected the **BOX** command and placed its first corner, you can go to the *Mod menu*. and select **KEEP LIKE**, pick an existing entity then place the opposite corner of the **BOX**. The new **BOX** will be the same *layer, color, line style, fill style, line width, pen thickness, dimension style* as the selected entity and all of the *default properties* will have changed. You can see them update in the various *property status windows* on the *Tool bar*.

If you only want the *next entity you are about to draw to use the properties* of an existing entity, use the **LIKE** modifier *after you have selected a DRAW* or **EDIT** command. **EasyCAD's default properties will NOT change** when using the **LIKE** modifier.

Text equivalent: **KEEP**

Help Commands

Instant on-line help is a mouse click away

Contents
Quick Help
Current command
How to Use Help
About FastCAD...
About our website...
Guided Tour

Help menu

EasyCAD provides comprehensive on-line help through the **Help menu**. The on-line help is handy when you need instruction or clarification during a command. This feature is called *context sensitivity*. For instance, if you are *dimensioning an angle* and need assistance, you can hit the **F1 key while in the command** to automatically display the **DIMA** help topic. Note that the term “**on-line**”, in this sense, refers to help topic availability while working with the program, *not* transmission via the Internet.

New help files are provided along with each relevant program update. The on-line help file also contains advanced information not found in this printed volume, such as macro programming commands, and conventions governing customization of menus, icon bars, etc.

Help

Use the **HELP** command to display the contents/index window for **FastCAD’s on-line** help. You can open the topic directly, or search for it in the on-line index. Access **HELP** by pressing **F1** while **EasyCAD’s** prompt is in the “**Command:**” state, or by selecting [**Help > Contents**] from the **Help menu**.

Unlike most keyboard function keys, **F1 cannot be redefined**. Windows always reserves **F1** for *on-line help systems*. (*F10 is the other keyboard function key that cannot be redefined; Windows reserves F10 for menu focus.*)

Quick Help is essentially identical to **Help**.

*Text equivalent: **HELP** (or press function key **F1**)*

*Text equivalent: **QHELP***

Current Command Help

Use in mid-command to activate context sensitive help for that command. You can also invoke this command by **pressing the F1 key** during a command.

For instance, run the **LINE** command [**Draw > Line**] command. When the prompt reads “**1st point:**”, press the **F1 key** or choose [**Help > Current Command**] from the **Help menu**. The on-line help topic for the **LINE** command is displayed.

*Text equivalent: **HELPCON***

How to use Help

This is the Windows “**How to use Help**” topic. If you have any trouble navigating or using the on-line help program, try this command.

*Text equivalent: **HELPHELP***

About EasyCAD

The **ABOUT** command displays the **EasyCAD** “**About...**” message box. Important information such as the exact *version number*, *release date*, and *serial number* can be found here.

*Text equivalent: **ABOUT** or **VER***


About our website

WEBINFO provides information on the **Evolution Computing website**, as well as an option to link directly if you are Internet capable. Access this command by using [**Help** > **About our website...**].

*Text equivalent: **WEBINFO***

Guided Tour

EasyCAD Guided Tours are interactive, message box-driven tutorial systems. If you’re new to **EasyCAD**, these guides offer a useful introduction to basic concepts.



*Text equivalent: **GUIDE***

EasyCAD V7 Command List

Alphabetical list of EasyCAD's command set

%	Percent Along modifier
%S	Percent Along Segment modifier (F7)
ABOUT	Display Version & Registration Information
ABOVE	Move entity to display after another
ACTHIDE	Hide Action buttons from user
ACTION	Define an Action button
ACTVIS	Show Action buttons
ADDSHT	Add Sheet
AGRID	Align Grid
AHEAD	Add Arrowhead to existing entity
ANG	Angle to modifier
ARC3	Start, Middle and End Arc, draw
ARCA	Arc w/ Arrowhead to end, draw
ARCAS	Arc w/ Arrowhead from start, draw
ARCB	Start, End and Bulge Arc, draw
ARCD A	Arc w/ Double Arrowheads, draw
ARCR	Center and Radius Arc, draw
ARCS	Center, Start, End Arc, draw
ARCW	Wedge (multipoly), draw
AREA	Area display, calc
ASAVE	AutoSave options
ASTYLE	Arrowhead Style
ATCHMODE	Select Attach mode
ATCHOFF	Turn Attach mode Off
ATCHON	Turn Attach mode On
ATCHT	Toggle Attach mode On/Off
ATCHTOG	Toggle Attach mode On/Off
ATTRIB	Define Symbol Attribute
BACK	Draw entity behind others
BEARING	Bearing display, calc
BELOW	Move entity to display before another
BEZ	Bezier curve, draw
BKGND	Background color
BOOKMARK	Edit bookmarks
BOX	Box, draw
BREAK	Break entity

BRNG	Bearing modifier
CALC	Calculate
CARCD	Chained Arcs, draw
CARY	Circular Array, draw
CEN	Center modifier (F4)
CHAM	Chamfer two entities, draw
CHAMFER	Chamfer two entities, draw
CHANGE	Change properties, display dialog
CHANGEAS	Change Arrowhead Style
CHANGECL	Color, Change
CHANGECL2	Secondary color, Change
CHANGED	Dimension Style, Change
CHANGEFS	Fill Style, Change
CHANGEL	Layer, Change
CHANGELS	Line Style, Change
CHANGELW	Line Width, Change
CHANGEPT	Pen thickness, Change
CHANGESCL	Changes all symbol definition colors to current
CHANGESCLBB	Changes all symbol definition colors to color by block
CHANGESLYR	Change all symbol definitions entities to a new Layer
CHANGET	Text Properties, Change
CHANGETX	Text, Change (same as CHANGEX)
CHANGEX	Text, Change (same as CHANGETX)
CIR2	2 Point Circle, draw
CIR3	3 Point Circle, draw
CIRD	Diameter and Center Circle, draw
CIRP	Center and Point On Circle, draw
CIRR	Radius and Center Circle, draw
CIRTAN2	Circle Tangent to 2 Circles, draw
CIRTAN3	Circle Tangent to 3 Circles, draw
CLEARMC	Clear macros from memory
CLIPCOPY	Copy to Clipboard (^C)
CLIPCUT	Cut to Clipboard (^X)
CLIPOPT	Options for Clipboard
COLOR	Set Current Color
COLORDLG	Set Current Color with dialog
CONNECT	Connect entity
CONNECTC	Connect Copy entity
CONVF	Convert Multiple Files
CONNECTCPY	Connect Copy entity
COPY	Copy entity
COPYSHIT	Copy entities to another sheet
COUNT	Count selected entities
COUNTA	Count All entities
CPART	Create Part
CPARY	Circular Part Array
CPARYM	Circular Part Array - macro version
CSNAPOFF	Turn Cursor Snap Off
CSNAPON	Turn Cursor Snap On

CSNAPTOG	Toggle Cursor Snap On/Off
CTRLP	Create Control Points for SmartSym
DBLN	Chain of Parallel Lines, draw
DEFSYM	Define a Symbol
DEG	Degree modifier
DELNODE	Delete Node
DELVN	Delete Named Vied
DELSHT	Delete Sheet
DELSYM	Delete Symbol Definition
DIMA	Angular Dimension
DIMAQ	Quick Angular Dimension
DIMB	Baseline Dimension
DIMD	Diameter Dimension
DIMH	Horizontal Dimension
DIML	Linear Dimension
DIMO	Ordinate Dimension
DIMP	Parallel Dimension
DIMR	Radius Dimension
DIMV	Vertical Dimension
DISCARD	Discard current drawing
DIST	Distance Along modifier (F8) (in mod context)
DIST	Distance display, calc (in command context)
DIST2	Expanded distance display, calc
DISTANCE	Distance display, calc
DOVE	Create Dome
DONUT	Create Donut (multipoly)
DRAG	Drag (move while displaying dynamic cursor)
DRAGCPY	Drag copy
DSTRETCH	Dynamic Stretch
DSTYLES	Dimension Style dialog box
DWGCMAP	Use drawing's color map
DYNEDIT	Dynamic Edit entity
DYNPAN	Dynamic Pan
DYNROT	Dynamic Rotate
DYNROTC	Dynamic Rotate Copy
DYNROTCPY	Dynamic Rotate Copy
DYNSCL	Dynamic Scale
DNSCLC	Dynamic Scale Copy
DYNSCLCPY	Dynamic Scale Copy
ECOFF	Echo Off (macro stream)
ECON	Echo On (live input)
EDIT	Edit entity
EDITMAC	Edit Macro file
EGRID	Edit Grid
ELIPA	Elliptical Arc, draw
ELIPC	Ellipse, Circle at Angle to Window, draw
ELIPI	Ellipse, Center and Inclination, draw
ELIPP	Ellipse, Center and Axis Points, draw

END	Exit EasyCAD
EPT	Endpoint modifier
EPTS	Endpoint of Segment (F5)
ERASE	Erase entity
EXIT	Exit EasyCAD
EXITAM	Exit All Nested Macros
EXITM	Exit Current Macro
EXPLODE	Explode entity
EXPSYM	Explode symbol reference
EXTENTS	List drawing extents
EXTRACT	Extract Symbol Attributes
FIL	Fillet two entities
FILLET	Fillet two entities
FLIP	Flip between last UNDO and REDO
FONT	Select Current Font
FONTDLG	Select Current Font
FRAMEOFF	Turn Frame display Off
FRAMEON	Turn Frame display On
FRAMETO	Toggle Frame display visibility (^F)
FREEZE	Freeze layer
FREEZEA	Freeze All layers
FRONT	Front entity
FSTYLE	Fill Style
FSTYLEDLG	Fill Style dialog box
GA	Get bearing angle
GD	Get distance
GE	Get Point on Entity
GL	Get Line (CR ends)
GN	Get Number (integer)
GO	Go to Macro Label
GOTO	Go to Macro Label
GP	Get Point (2d/3d)
GRIDANG	Rotate angular grid
GRIDOFF	Turn Grid display Off
GRIDON	Turn Grid display On
GRIDT	Toggle Grid display On/Off
GRIDTOG	Toggle Grid display On/Off
GRIDV	Specify square Grid Value
GROUP	Group entity
GUIDE	On-line Guide (tutorial)
GUIDEM	On-Line Guide from Macro
GV	Get real value
GW	Get Word (space/tab/CR ends)
HELP	Contents of Help
HELPCON	Current command Help
HELPHelp	How to Use Help
HELPN	Get Help by Context Number

HIDE	Hide layer
HIDEA	Hide All layers
HIDESHT	Hide Sheet
HORZ	Same Y modifier
ID	Coordinate display, calc
IFDEF	IF (Variable defined) Go
IFERR	IF (Error) Go
IFN	IF (Negative Value) Go
IFP	IF (Positive Value) Go
IFZ	IF (Zero Value) Go
INDEX	Make Fast Search Index
INSNODE	Insert Node
INSSYM	Draw Symbol
INSSYMD	Draw Symbol
INT	Intersection of modifier (F6)
INT2	Intersection (force 2 picks for macros)
KEEP	Keep Like
KEEPTH	Keep text height & angle
LAYER	Select Layer
LAYERCPY	Copy entity to Layer
LAYERDLG	Select Layer dialog box
LDCFG	Load a custom .CFG screen configuration file
LDSYMDEF	Load part as symbol definition
LENGTH	Length along modifier
LIKE	Like modifier (F2), Like command
LINE	Line
LINE2	Line
LINEA	Arrow Line
LINEDA	Double arrow line
LIST	List entity
LISTLYR	List layers
LISTSYM	List Symbol Definitions
LISTVARS	List Macro Variables
LNPRP	Perpendicular modifier
LNPRPL	Perpendicular at length modifier
LOAD	Open drawing file (^O)
LOADCMAP	Load saved .cwm color map file
LOADM	Load (name from cmd line)
LOADMAC	Load Macro file
LOADMACM	Load Macro File (name from cmd line)
LOCKOFF	Turn Group Locking Off
LOCKON	Turn Group Locking On
LOCKT	Toggle Group Locking On/Off
LOCKTOG	Toggle Group Locking On/Off
LSTYLE	Line Style
LSTYLEDLG	Line Style dialog box
LWIDTH	Line Width

LWIDTHD	Line Width dialog box
MCOLOR	Change marking (entity selection) color
MDCTL	Multi-Drawing Control
MENU	Load Menu file
MENUD	Specify Default Menu
MENUDM	Specify Default Menu (from cmd line)
MID	Midpoint modifier
MID2	Midpoint between 2 points
MIDS	Midpoint of Segment (F3)
MIRCPY	Mirrored Copies
MIRROR	Mirror entity
MOVE	Move entity
MOVESHT	Move entities to another sheet
MPOLY	Create Multipoly
MPOLY2	Create Multipoly
NED	Launch NED Text Editor
NEW	New drawing (^N)
NEWW	New Drawing Window
NOTES	File Notes
OFFSET	Offset a chain of entities
OFFSET1	Offset a single entity
OFFSETCPY	Offset a chain of entities, copy properties
ON	On modifier (F9)
OPEN	Open drawing file (^O)
OPENBC	Open current bookmarked drawing
OPENBN	Open next bookmarked drawing
OPENBP	Open prior bookmarked drawing
OPENDOC	Open File with Associated Program
OPENND	Open next drawing in file history
OPENPD	Open prior drawing in file history
OPTIONS	Select Program Options
ORIGIN	Change Origin
ORTHOFF	Turn Ortho Off
ORTHON	Turn Ortho On
ORTHT	Toggle Ortho On/Off
ORTHTOG	Toggle Ortho On/Off
PAN	Pan drawing view
PART	Insert Part
PARTM	Insert Parm (cmd line)
PARY	Part Array
PARYM	Part Array (cmd line)
PASTE	Paste from Clipboard (^V)
PATH	Create Path
PATH3	Create Path3
PATHA	Path w/ Arrowhead, draw
PATHDA	Path w/ Double Arrowheads, draw

PCHANGE	Change Properties Dialog
PEDIT	Properties Edit
PICT	Insert bitmap image into drawing
POINT	Create Point
POLY	Create Polygon
PRINT	Print current drawing (^P)
PRINTSU	Print Setup
PRL	Parallel to modifier (F11)
PROTECT	Prevent files from being modified and/or printed
PRP	Perpendicular to modifier (F12)
PSPLINE	Create Parabolic Spline
PSPOLY	Create Parabolic SPoly
PTHICK	Set pen thickness
PURGESYM	Purge unused symbol definitions
PURGEUNDO	Remove current undo information
QUIT	Exit FastCAD
RDOFF	Redraw Off
RDON	Redraw On
REDO	Redo last UNDO (^Y)
REDOA	Redo all UNDO's
REDRAW	Redraw the screen
REF	Reference Point modifier
RENSYM	Rename symbol reference
REPEAT	Rectangular Array
REPSYM	Replace Symbol
RESTORE	Restore drawing file
ROOM	Draw room (wall network)
ROTALN	Rotate and align
ROTATE	Rotate entity
ROTCPY	Rotated Copies
RPOLY	Create Regular Polygon
RUN	Run Actions
RUNAPP	Run external application
SAMEX	Same X modifier
SAMEY	Same Y modifier
SAVE	Save Current drawing (^S)
SAVEAS	Save As... (^A)
SAVECMAP	Save current color map to .cwm file
SAVEMAC	Save Macro File
SAVEMACM	Save Macro File (cmd line)
SAVEVARS	Save macro variables
SCALE	Scale entity
SCALEXY	Differential Scale
SCLCPY	Scaled Copies
SCRIPT	Load Script file
SCRIPTM	Load Script file (cmd line)
SEARCH	Search drawing files for specified text

SELAW	Select Active Window
SELSHT	Select Sheet
SETLAYER	Set Current Layer
SGRID	Select Grid dialog box
SHEET	Manage sheets
SHOW	Show layer
SHOWA	Show All layers
SHOWSHT	Show Sheet
SNAPOFF	Turn Snap Off
SNAPON	Turn Snap On
SNAPT	Toggle Snap On/Off
SNAPTOG	Toggle Snap On/Off
SNAPV	Specify Snap Value
SOUND	Play a standard .WAV sound file
SPLINE	Create Cubic B-Spline
SPLINEA	Spline w/ Arrowhead, draw
SPLINEDA	Spline w/ Double Arrowheads, draw
SPLIT	Split entity
SPLRES	Change Spline Resolution
SPLRESD	Specify Default Spline Resolution
SPOLY	Create 2d Cubic B-SPoly
STRETCH	Stretch entity
SVNAME	Set view name
SYMBOL	Draw Symbol Reference
SYMBOLD	Draw Symbol Reference
TABLE	Make a TABLE of Rows and Columns of Text
TAN	Tangent to modifier
TANGENT	Tangent Line to two entities, draw
TCHAM	Chamfer & Trim
TDATE	Insert the Current Date as a piece of Text
TDFMT	Opens the Time and Date Format dialog box
TEMPLATE	Load new template
TEMPLATEM	Load new template (cmd line)
TEXPORT	Export the data from a TABLE to .CSV format
TEXT	Text, draw
TFIL	Fillet & Trim
TFILE	File Text, draw
TFILENAME	Inserts the current drawing name as a piece of Text
THAW	Thaw layer
THAWA	Thaw All layers
TIMPORT	Import .CSV data into a TABLE
TOOLS	Display Tools dialog box
TPRINTSU	Setup Text Printing Options
TRIM	Trim entity
TRIMIE	Trim inside entities
TRIMINT	Trim to intersection
TRIML	Trim to specified length
TRIMOE	Trim outside entities
TRIMTO	Trim to specified entity

TSPEC	Text Properties dialog box
TTIME	Inserts the Current Time as a piece of Text
UNDO	Undo (^Z)
UNGROUP	Ungroup entities
UNITS	Units dialog box
VER	About EasyCAD...
VNAMES	View Names Dialog
VPCOPYW	Copy Windows View to Viewport
VPORT	Create Viewport
WALL	Wall, draw
WCENTER	Set Walls Specified by Center Mode
WCWIDA	Change wall width
WCWIDE	Change wall end width
WCWIDS	Change wall span width
WEBINFO	Go to our web site
WLADD	Add wall
WLCUT	Cut wall
WLEFT	Set Walls Specified by Left Side Mode
WLOFST	Offset wall
WLRMV	Remove wall
WLWID	Set wall width
WPDEF	Define 3d Workplane
WPDEFW	Define 3d Workplane Window
WPDEL	Delete 3d Workplane
WRIGHT	Set Walls Specified by Right Side Mode
XHTOG	Toggle crosshairs display
XHOFF	Turn Crosshairs Off
XHON	Turn Crosshairs On
XPINFO	Get Info on Installed XP Modules
XREF	Insert eXternal REference
XREFDLG	External Reference Management Dialog
ZCEN	Zoom Center view
ZEXT	Zoom Extents view
ZHGT	Zoom Height view
ZIN	Zoom In view
ZLAST	Zoom Last view
ZNAME	Zoom Named View
ZOUT	Zoom Out view
ZTEXT	Zoom Text
ZTEXTD	Zoom Text (dialog)
ZWID	Zoom Width view
ZWIN	Zoom Window view
ZWPLANE	Zoom to the current Workplane

Index

Symbols

% ALONG modifier 379
< (polar coordinates) 37
? (search wildcard) 82
@ (relative coordinates) 37
~ (relative polar coordinates) 37
2 Point Circle command 92
3 Point Circle command 93

A

ABOUT command 390
ABOVE command 225
absolute coordinates 37
absolute tracking 16
ACADOPT 349
ACTION 364
actions
 using 363–365
active drawing windows 20
ACTVIS 365
Add New Font Properties dialog box 330
adding rooms to wall networks 143
adding walls to wall networks 145
AGRID 286
AHEAD 197
Align Grid command 286
alphabetical list of commands 391
ANG 378
Angle Grid command 287
Angle to modifier 378
angles 37
 dimensioning 164, 166
Angular Dimension (Full) command 164
Angular Dimension (Quick) command 166
angular dimensions
 full 164
 quick 166
angular grids 290, 291
aperture adjustment 346
Arc Arrow (to End) command 134
Arc Arrow (to Start) command 134
Arc Double Arrow command 135
ARC3 99
ARCA 134
ARCAS 134
ARCB 100
ARCD A 135
ARCR 97
ARCS 96
arcs 96–103
 arrowed 134
 center, start, end 96
 chained arcs 101
 double arrowed 135
 dynamic editing 183
 editing parameters 181
 fillets 127
Arcs sub-menu 96
ARCW 102
AREA command 356
arrays 240–241
 circular 241
 parts inserted as 251
 parts inserted as circular 253
Arrowhead Style command 327
Arrowhead Style dialog box 327
arrowheads
 adding to/removing from existing entity 181, 197
 changing current style 198, 199
 setting in dimensions 324
arrows 133
 double arrows 135
 drawing leaders 133
 setting current style 327
ASAVE 64
ASTYLE 327
ATCHMODE 334
attach 334
Attach button 12, 366
attach mode 366
 drawing dimensions 153
 overriding with modifiers 366
 setting mode 12
Attach Mode command 334
ATTRIB 278
attributes 243, 278
 defining 278
 extracting 278
AutoCAD® .SHX vector fonts 330
AutoSave 64
AutoSave Options dialog box 64

B

background color 73
background color in clipboard 71
Background command 73
Baseline Dimension command 162–163
Bearing Angle modifier 383
BEARING ANGLEDISTANCE FORMAT 345
BEARING command 354
bearings 37
BELOW command 226
BEND 222
BEZ 115
Bezier command 115
Bitmap Files 305
bitmap files fill style 305, 310
bitmap images
 as fill style 310
 editing parameters 182
 using in clipboard 69
bitmaps, fill style 305
BKGND 73
BKM FastCAD Bookmark files 53
BOOKMARK 54
Bookmark & Search Icon bar 45, 53
bookmarks 53–57
 about 53
 creating 54
 editing lists 54
 viewing lists 54
BOX command 111
BREAK command 220, 222
BRNG 383
brush pattern fill style 304, 307
Brush Patterns 304
Button bar 10, 12

C

CALC 356
Calculate command 356
CARCD 101
Cartesian coordinates 36
CARY 241
CEN 369
Center and Inclination Ellipse command 122
Center and Point On Circle command 89
Center and Radius Arc command 97
Center modifier 369
Center, Start, End Arc command 96

Chained Arc command 101
CHAM 128
CHAMFER 128
Chamfer & Trim command 129
Chamfer Only command 128
chamfers 128
 chamfer only 128
Change > Diameter 199
Change > Radius 199
Change All SymDefs > Change All Layers 275
CHANGE command 186
change commands 186–202
 arrowhead presence 197
 arrowhead style 198, 199
 color by block 191
 dimension style 194
 fill style 193
 layer 192
 line style 193
 line width 194
 pen thickness 192
 symbol colors 273
 text 195
 text properties 196
 wall width (entire network) 148
 wall width (one end of span) 150
 wall width (single span) 149
Change Wall Width command 148
Change Wall Width End command 150
Change Wall Width Span 149
Change-2nd Color command 191
Change-Arrow command 198
Change-Arrowhead command 197
Change-Color by Block command 191
Change-Color command 190
Change-Dimension Style command 194
Change-Fill Style command 193
Change-Layer command 192
Change-Line Style command 193
Change-Line Width command 194
Change-Pen Thickness command 192
Change-Properties command 187
Change-Symbol Color by Block command 274
Change-Symbol Scale command 272
Change-Text command 195
Change-Text Properties command 196
CHANGEAS 198
CHANGECD 190
CHANGECD2 191
CHANGED 194

- CHANGEFS 193
- CHANGEL 192
- CHANGELS 193
- CHANGELW 194
- CHANGEPT 192
- CHANGESCB 274
- CHANGESLYR 275
- CHANGESS 272
- CHANGET 196
- CHANGETX 195
- CHANGEEX 195
- CHGCBB 191
- CHGDIA 199
- CHGRAD 199
- CIR2 92
- CIR3 93
- Circle at Angle to Window Ellipse command 121
- circles 89–95
 - dynamic editing 183
 - editing 90
 - editing parameters 181
- Circles sub-menu 89
- Circular Array command 241
- circular dimensions
 - diameter 169
 - radius 168
- circular grids 289
- Circular Part Array command 253–254
- CIRD 90
- CIRP 89
- CIRR 91
- CIRTAN2 94
- CIRTAN3 94
- Clear Macros command 361
- CLEARM 361
- Clip menu 66–71
- Clip Options command 70
- clipboard 66, 69–71
 - copying to 69
 - cutting to 69
 - pasting from 69
 - setting options 70
- CLIPCOPY command 69
- CLIPCUT command 69
- CLIOPT 70
- Close window icon 23
- COLOR 294
- Color bar 15, 190
- color by block 24
- color maps
 - loading default 319
 - saving default 320
 - using drawing's stored 321
- color numbers 15, 295
- Color status 16
- colors
 - assigning line width to 318
 - background 73
 - by block 191
 - changing in symbol definitions 273
 - entity selection 73
 - selecting 294
 - symbols 263
- command prompt 10, 12
- compressed FCW files 346
- CONNECT command 212
- CONNECTC 233
- connecting entities 212
- context-sensitive help 389
- control points 262
- Convert Files command 59
- CONVF 59
- Coordinate command 354
- coordinate system 39
- coordinates
 - absolute 37
 - entering 36
 - polar (<) 37
 - relative (@) 37
 - relative polar (~) 37
- COPY command 230
- Copy Connect command 233–234
- Copy menu 229–241
- copy origin 231
- Copy to Layer command 232
- Copy to Sheet command 260
- copying entities 229–241
 - in a circular array 241
 - in a drawing 230
 - to another layer 232
 - to clipboard 69
 - while dynamically scaling 235
 - with dynamic cursors 231
- COPYSHT 260
- Count All command 353
- COUNT command 353
- COUNTA 353
- CPART 255
- CPARY 253
- Create Part command 255

cross-hatching 304
 crosshairs 284, 333
 CTRL+A (Save drawing as) 47
 CTRL+C (Clipboard copy) 69
 CTRL+O (Load drawing) 44
 CTRL+S (Save drawing) 46
 CTRL+V (Clipboard paste) 69
 CTRL+X (Clipboard cut) 69
 CTRL+Y (Redo) 68
 CTRL+Z (Undo) 67
 CTRLP 265
 Cubic B-spline command 116
 Cubic B-SPoly command 117
 CURRENT DATE 107
 CURRENT DRAWING 109
 current work layer 296
 Cursor Snap button 12
 cursor snap, toggling 12
 cursors
 adjusting pick box aperture size 346
 toggling crosshairs 333
 with action buttons 363
 curves, creating from paths 182
 custom units 340
 customizing
 256-color palette 294
 background color 73
 color mapping 318
 drawing screen 12
 icon bars 13
 selection (marking) color 73
 cutting to clipboard 69
 cutting walls 146

D

datum dimensioning 160
 DBLN 85
 Decimal Inches format 342
 decimal places 325
 default values 25
 Define Action command 364
 Define Attribute command 278
 Define Symbol command 264
 DEFSYM 264
 DEG 382
 Degrees On modifier 382
 Delete Node command 223
 Delete SymDef command 269
 deleting

 all unused layers 297
 layers 296
 symbol definitions 269
 unused symbol definitions 270
 delimiters 358
 DELNODE 223
 DELSYM 269
 Diameter and Center Circle command 90
 Diameter Dimension command 169
 DIMA 164
 DIMAQ 166
 DIMB 162
 DIMD 169
 Dimension Angle Width Format 345
 Dimension icon 323
 Dimension Style
 status indicator (active dimension style) 18
 dimension style 323
 Dimension Style command 323
 Dimension Style status 18
 Dimension Styles dialog box 194
 dimension text 325
 dimensions 34
 attach mode 153
 drawing
 angular, full 164
 angular, quick 166
 baseline 162
 diameter 169
 horizontal 157
 ordinate 160
 radius 168
 vertical 158
 DWG/DXF options 350
 dynamic editing 155
 editing
 changing existing dimensions 194
 editing properties 155
 fixed value 155, 163, 165, 167
 DIMO 160
 DIMP 159
 DIMR 168
 DIMV 133
 displacement values, entering 39
 DIST 355, 381
 DIST2 355
 distance
 entering values 39
 Distance Along modifier 381
 Distance command 355

- Distance2 command 355
- DLL XP module files 336
- DMS bearings 38
- DMS Degrees, Minutes and Seconds 345
- DONUT command 95
- double arrows 135
- Double Lines command 85
- DRAG command 201
- Drag Copy command 231
- DRAGCPY 231
- dragging entities
 - copying 231
 - moving 201
 - rotating 210
 - scaling 207
 - scaling copies 235
- Draw Symbol command 276
- drawing files
 - autosave 64
 - converting 59
 - quitting 65
 - startup templates 63
- drawing screen
 - setting view names 76
- Drawing Sheets dialog 258
- drawing windows
 - closing 21
 - multiple 20
 - naming 21
- DSTRETCH 204
- DSTYLES 323
- DWG files
 - converting multiple files 59
 - setting save version 349
- DWG/DXF Options command 349
- DWGCMAP 321
- DXF files
 - converting multiple files 59
 - setting save version 349
- dynamic cursors 25
- dynamic edit 183
- DynTrack 25
- used when copying 231
- Dynamic Edit command 183–185
- Dynamic Pan command 77–78
- dynamic panning 72
 - configuring mouse buttons 346
- Dynamic Rotate command 210
- Dynamic Rotate Copy command 237–238
- Dynamic Scale command 207

- Dynamic Scale Copy command 235
- DYNEDIT 183
- DYNPAN 77–78
- DYNROT 210
- DYNROTC 237
- DYNSCL 207
- DYNSCLC 235
- DYNSTRETCH 203
- DynTrack 25

E

- edge locking 149, 151
- Edit Bookmarks command 54
- EDIT command 181–182
- Edit Grid command 288–290
- Edit Macros command 360
- Edit Text dialog 106
- Editing Angular Grids 290, 291
- Editing Circular Grids 289
- Editing Rectangular Grids 288
- EDITMAC 360
- EGRID 288
- ELIPA 123
- ELIPC 121
- ELIPI 122
- ellipses
 - dynamic editing 184
 - editing parameters 181
- Ellipses sub-menu 120
- Elliptical Arc command 123
- EMF Enhanced Metafile
 - enabling for clip operations 71
 - setting size options 71
 - using in clipboard 69
- END 65
- Endpoint modifier 367
- entities
 - editing 181
 - understanding 34
- Entity Properties dialog 187, 188, 200
- entity selection
 - enabling popup menus 346
- EPT 367
- ERASE command 180
- erasing wall spans 147
- EXIT command 65
- extended procedures 336
- EXTENTS command 353
- EXTRACT 278

Extract Attributes command 278

F

F1 (Help) 389

F11 (Parallel modifier) 376

F12 (Perpendicular modifier) 377

F2 (Like modifier) 387

F4 (Center modifier) 369

F6 (Intersection modifier) 375

F7 (% modifier) 380

F8 (Distance Along modifier) 381

F9 (On modifier) 375

FCD FastCAD/EasyCAD DOS files

converting multiple files 59

FCT FastCAD Template files 63

Feet and Inches format 342

feet, UNITS option 340

FIL 126

File Text command 107

Fill Style icon 304

Fill Style status 17

fill style types

bitmap files 305, 310

brush patterns 304, 307

hatch 305, 308

symbol fills 305, 312

fill styles

changing for an existing entity 193

line width effect upon 313

multipoly 136

setting current style 304

status indicator (active fill style) 17

FILLET 126

Fillet & Trim command 127

Fillet Only command 126

fillets 126

fillet & trim 127

fixed dimension value 155, 163, 165, 167

FLIP command 68

FNT vector fonts 329

FONT command 331

fonts

adding to available list 330

Fractional Inches format 342

frames 116, 140, 284

FRAMETOG 333

Freeze All command 300

FREEZE command 300

FREEZEA 300

freezing layers 300

FRONT command 224

FSC Symbol Catalog files

changing colors in 273

creating from parts 271

using with viewer 243

FSC symbol catalog files 274

FSTYLE 304

Full Angular Dimension command 164

function keys

as macro names 358

with modifiers 366

G

Grid button 12, 284

GRIDANG 287

grids 42, 284, 285–290

aligning 286

angling 287

angular 290

editing angular 290, 291

editing circular 289

editing rectangular 288

selecting active 285

GROUP command 256

groups 256–257

listing 357, 358, 360

locking & unlocking 12

ungrouping one level 256

GUIDE command 390

H

hatch fill style 305, 308

hatching 304

HELP command 389

Help menu 389–390

HELPCON command 389

HELPHelp 390

Hide Actions command

ACTHIDE 365

Hide All command 299

HIDE command 299

HIDEA 299

hiding layers 299

horizontal locking

Ortho button 12

I

- icon bars 13
 - positioning 13
- icons
 - Bookmark icons 53
 - Select Color 15
- ID 354
- inches
 - pen thickness option 316
 - per unit 340
 - UNITS option 340
- Info menu 351–356
- Insert menu 243–278
- Insert Node command 223
- Insert Part command 246
- Insert XREF command 248
- INSNODE 223
- INSSYMD 276
- installation 3
- Installed XP Modules dialog box 336
- Installed XPs command 336
- INT 375
- Internet 1, 4, 390
- Intersection of modifier 375

K

- KEEP command 388
- Keep Like command 388
- KEEP modifier 388
- Keep Text Height and Angle command 107
- KEEPTHA 107

L

- LAYER 296
- Layer icon 296
- Layer Name dialog box 297
- Layer status 17
- LAYERCPY 232
- LAYERDLG 296
- layers 41, 296–300
 - changing for an existing entity 192
 - copying entities to another 232
 - creating new 296
 - deleting 296
 - freezing 300
 - hiding 299
 - hiding all 299

- introduction 40
- listing all in drawing 300
- Merge & Standard 299
- names 297
- ordering 296
- parts 245
- purge unused 297, 300
- setting current 299
- showing 299
- status 17, 297
- thawing 300

LDSYMDEF 271

leaders 133

LENGTH 356

Length Along command 356

LIKE modifier 387

Line Arrow command 133

LINE command 84

Line Double Arrow command 135

Line Perpendicular at Length command 87

Line Perpendicular command 86

Line Style command 301–303

Line style dialog 302

Line Style icon 301

Line Style status 17

line styles

- changing for an existing entity 193
- status indicator (active line style) 17

Line Tangent to Two Entities command 88

Line Width command 313–314

Line Width Settings dialog box 313

Line Width status 17

line widths

- changing for an existing entity 194
- mapping to color when printing 318
- status indicator (active line width) 17

LINEA 133

linear dimensions

- baseline 162
- dynamic editing 185
- horizontal 157
- vertical 158

LINEDA 135

lines 84–88

- arrowed 133
- double arrowed 135
- dynamic editing 183
- editing parameters 181

Lines sub-menu 84

LIST command 352

List Layers command 300
 List Symdef command 269
 List Variables command 361
 listing
 all entities in drawing 352
 all layers in drawing 300
 properties for any entity 352
 sheets 259
 symbols in drawing 269
 LISTLYR 300
 LISTSYM 269
 LISTVARS 361
 LNPRP 86
 LNPRPL 87
 LOAD 44
 Load as Symdef command 271
 Load Color Map 319
 Load Color Map command 319
 Load Macros command 360
 LOADCMAP 319
 LOADMAC 360
 Lock button 12
 locking groups 256
 LSTYLE 301
 LSTYLEDLG 301
 LWIDTH 313
 LWIDTHD 313

M

MAC files
 editing 360
 Macro menu 357–365
 macros
 clearing from memory 361
 editing loading files 360
 listing variables in 361
 programming 359
 Make Control Points command 265–267
 manual conventions 2
 Map Color to Line Width dialog box 318
 Maximize window icon 20
 MCOLOR command 73
 MENU command 60
 menus
 Clip 66–71
 Copy 229–241
 customizing 11
 Help 389–390
 Info 351–356

Insert 243–278
 Macro 357–365
 Mod 366–388
 overview 7
 using 11
 View 72–82
 Merge layer 245, 299
 message boxes 25
 Meters format 343
 meters, UNITS option 340
 MID 370
 Midpoint modifier 370
 millimeters
 UNITS option 340
 Millimeters format 343
 MIRCPY 239
 MIRROR command 213
 Mirrored Copies command 239
 mirroring entities 213
 MLTEXT 105
 Mod menu 366–388. *See* modifiers
 modifiers 36, 334, 366–388
 center 369
 endpoint 367
 general usage 366
 introduction 42
 like 387
 midpoint 370
 percent along 379
 mouse
 configuring buttons for dynamic pan 346
 MOVE command 202
 Move to Sheet command 260
 MOVESHT 260
 moving entities 201–202
 in a drawing 202
 to another layer 192
 using dynamic cursors 201–202
 MPOLY2 136
 Multi Line Text command 105
 multiple drawing windows 20
 multiple level undo 67
 Multipoly command 136
 multipolys
 creating 136
 line width effects upon 314

N

Nearest Point On modifier 375

NEW command 43
New Drawing Window command 20
NEWW 20
Node Edit > Insert 223
nodes
 editing in a path or poly 182
 in walls 139
 inserting in paths/polys 223
 inserting/deleting in path or poly 184
 repositioning in path or poly 184
NOTES command 58
Numeric format 342

O

OFFSET 130
Offset Chain command 130
Offset Copy command 132
Offset One command 131
OFFSET1 131
OFFSETCPY 132
offsetting entities 130
 walls 144
ON 375
OPEN command 44
Open Next command 45
Open Prior command 45
OPENND 45
OPENPD 45
options
 clipboard 70
 screen tools 12
 setting DWG/DXF 349
OPTIONS command 346
Options dialog box 346
ordering entities on the screen
 bring to front 224
 move above selected entity 225
 move below selected entities 226
Ordinate Dimension command 160
ordinate dimensions
 dynamic editing 185
ORIGIN command 74
ortho
 when copying 181, 230
 when creating mirror lines 240
Ortho button 12

P

palette 294
PAN 78
Pan View command 78
panning your view
 using the PAN command 78
Parallel Dimension command 159
Parallel to modifier 376
PART 246
Part Array command 251–252
parts 34, 245–255
 about 245–278
 arraying 251
 circular array 253
 defined 243
 inserting into drawing 246
 loading into symbol catalogs 271
 Merge layer 299
 pasted from clipboard 69
 ungrouping 256
PARY 251
PASTE command 69
PATH command 112
Path Double Arrow command 135
PATHDA 135
paths
 arrowed 133
 change to arrow 182
 deleting nodes 223
 double arrowed 135
 drawing 112
 editing
 inserting/deleting nodes 184
 reshaping 184
 editing parameters 182
 inserting nodes 223
Paths and Polys sub-menu 111
PCHANGE 187
PEDIT 200
pen plotters 305
pen thickness 17, 315
 changing for an existing entity 192
Pen Thickness command 315
Percent Along modifier 379
Perpendicular Line command 86
Perpendicular to modifier 377
polar coordinates 37
polar tracking 16
POLY 113

Polygon command 113
 polygons 111
 box 111
 cubic B-SPoly 117
 deleting nodes 223
 drawing 113
 drawing regular 114
 inserting nodes 223
 popup menus
 toggling 346
 Walls 151–152
 preferences 346
 Print Setup command 49
 printing
 large drawings as tiles 51
 line widths mapped to color 318
 portrait/landscape orientation 52
 setup 49
 sheets 51, 258
 to a file 51
 PRINTSU 49
 PRL 376
 Properties Edit command 200
 PRP 377
 PTHICK 315
 Purge Symbol Definition command 270
 PURGESYM 270
 purging unused layers 297

Q

Quick Angular Dimension command 166
 QUIT 65

R

Radius and Center Circle command 91
 Radius Dimension command 168
 recovering a drawing file 65
 Rectangular Array command 240
 rectangular grids 288
 Redo All command 68
 REDO command 68
 REDOA 68
 REDRAW command 73
 REF 385
 Reference Point modifier 385
 Regular Polygon command 114
 relative coordinates 37
 relative polar coordinates 37

relative tracking 16
 REPEAT 240
 Replace Symbol command 268
 REPSYM 268
 Rescale Units 344
 resizing
 drawing windows 21
 ROOM command 142–144
 rooms 139
 adding to wall networks 143
 drawing 142–144
 ROTALN 211
 Rotate Align command 211
 ROTATE command 209
 Rotated Copies command 238
 rotating entities 209–212
 connect 212
 dynamic rotate 210
 rotate 209
 rotate and align 211
 rotating grids 287
 ROTCPY 238
 RPOLY 114

S

Same X modifier 385
 Same Y modifier 386
 SAMEX 385
 SAMEY 386
 Save All command 48
 Save As command 47
 SAVE command 46
 Save Macros command 361
 Save Variables command 362
 SAVEALL 48
 SAVEAS 47
 SAVECMAP 320
 Savel Color Map command 320
 SAVEMAC 361
 SAVEVARS 362
 saving drawing files
 automatically 64
 in compressed mode 346
 SCALE command 206
 Scale XY command 208
 Scaleable Hatching 305
 Scaled Copy command 236–241
 scaling dimensions 325
 scaling drawings for printing 51

- scaling entities 206–208
 - copy & dynamic scale 235
 - dynamic scale 207
 - scale 206
 - scale XY 208
- SCLCPY 236
- Screen Tools icon 12
- SCRIPT command 61
- scroll bars 346
- SEARCH command 56–57
- searching
 - files for specific text 56
- SELAW 20
- Select Active Window command 20
- Select Color command 294–295
- Select Color dialog box 294
- Select Color icon 15, 294
- Select Grid command 285–286
- Select Grid System dialog box 285
- Select Layer command 296–300
- Set Current Layer command 299
- Set View Name command 76
 - with multiple drawing windows 21
- SETLAYER 299
- SGRID 285
- SHEET command 258–259
- Sheet Name
 - status indicator (active sheet name) 18
- Sheet Name status 18
- sheets 257–260
 - managing 258
 - printing 51
- Shoe Actions command 365
- Show All command 299
- SHOW command 299
- SHOWA 299
- showing layers 299
- SHX vector fonts 330
- Single Line Text command 104
- smart symbols
 - defined 262
 - inserting in walls 140
- snap 42
- Snap button 12
- Specs > Time and Date 332
- SPLINE 116
- Spline Arrow command 134
- Spline Double Arrow command 135
- SPLINEA 134
- SPLINEDA 135
- splines 115
 - arrowed 134
 - creating from paths 182
 - deleting nodes 223
 - double arrowed 135
 - editing
 - inserting/deleting nodes 184
 - reshaping 184
 - editing parameters 182
 - inserting nodes 223
- Splines and SPolys sub-menu 115
- SPOLY 117
- SPolys 115
 - cubic B-Spoly 117
- Standard Icon bar 14
- Standard layer 299
- Start, End and Bulge Arc command 100
- Start, Middle and End Arc command 99
- Status bar 8, 16, 83
- status indicator (active color) 16
- STRETCH command 205
- Stretch Tips 204
- stretching entities 203, 205
- styles
 - arrowhead 327
 - dimension 323
- Surveyors Bearings 345
- surveyor bearings 38
- SVNAME 76
- switches 42
- Symbol Catalog files
 - creating 24
- Symbol Catalog viewer 243, 263
- symbol definitions 261
- symbol fill style 305, 312
- Symbol Fills 305
- symbol references 261
- symbols 34, 261–278
 - adding references to drawing 276, 279
 - attributes, defining 278
 - attributes, extracting 278
 - changing colors 273
 - color by block 24
 - colors 263
 - creating catalog from parts 271
 - defined 243
 - deleting definitions from drawing 269
 - listing 269
 - Merge Layer 299
 - purging unused definitions 270

- replacing 268
- smart 262
- using in fill style 312
- using instead of parts 244

system colors 295

system fonts 329

system requirements 3

T

TAN 384

TANGENT 88

Tangent to 2 Entities Circle command 94

Tangent to 3 Entities Circle command 94

Tangent To modifier 384

TCHAM 129

technical support 4

TEMPLATE command 63

templates 35, 63, 330

TEXT 104

text 104–107

- changing properties 196
- dimensions 325
- editing 106
- editing a single instance 182
- editing multiple instances 195
- font setting 331
- inserting from a text file 107
- keeping height and angle 107, 110
- pasting from clipboard 69
- repositioning 184
- setting properties 328
- special characters 104, 105

Text > Current Date 107

Text > Current Drawing 109

Text > Current Time 108

Text dialog box 195

text entities

- searching files for specific 56

Text Height

- status indicator (current text height) 18

Text Height status 18

Text Properties command 328

Text Properties dialog 196

Text Properties dialog box 328

TFIL 127

TFILE 107

Thaw All command 300

THAW command 300

THAWA 300

thawing layers 300

tiled printing 51

TIME AND DATE FORMATS 332

title bar 8, 9, 21

Toggle Crosshairs command 333

Toggle Frames command 333

Tracking status 16

TRIM command 214

Trim Inside Entities command 218

Trim Outside Entities 219

Trim to Entity command 215

Trim to Intersection command 216

Trim to Length command 217

TRIMIE 218

TRIMINT 216

TRIML 217

trimming entities 214–219

- inside entities 218
- outside entities 219
- regular trim 214
- to a selected entity 215
- to intersection 216
- to length 217

TRIMOE 219

TRIMTO 215

TSPEC 328

tutorial. *See* GUIDE command

Type styles

- status indicator (current type style) 18

U

un-freezing layers 300

un-hiding layers 299

UNDO command 67

undo commands 67–68

- flip 68
- redo 68
- redo all 68
- undo 67

UNGROUP command 256

units 35

Unlock button 12

- group editing 256

unlocking groups 256

Use Drawing Color Map command 321

Use Dwg Map 321

user options 346

V

- variables 361
- vector fonts 329
- VER 390
- version, determining 390
- Vertical Dimension command 133
- vertical locking
 - Ortho button 12
- View menu 72–82
- view names
 - recalling via view sets 75
 - setting view names 76
- View Sets command 75
 - multiple drawing windows 21
- VSET 75

W

- Wall Add command 145–146
- WALL command 141
- Wall Cut command 146
- Wall Offset command 144
- Wall Remove Side command 147
- Wall Width command 148
- walls
 - adding to existing networks 145
 - breaking 146
 - changing width of all spans 148
 - changing width of one span 149
 - changing width of span end 150
 - drawing 139
 - edge locking 149, 151
 - editing 139
 - inserting smart symbols 140, 276, 279
 - removing spans 147
 - setting width 148
- Walls popup menu 151–152
- WCWIDA 148
- WCWIDE 150
- WCWIDS 149
- Wedge Arc command 102
- Window Control Bar Icons 22
- WLADD 145
- WLCUT 146
- WLOFST 144
- WLRMV 147
- WLWID 148
- write-protect entities
 - frozen layers 300

- hidden sheets 257

- www.fastcad.com 1

X

- XHTOG 333
- XP modules 336
- XPCFG 336
- XREF 248
- XREFs
 - editing existing 182
- xrefs 244
 - inserting into drawing 248
 - relation to symbols 262

Z

- ZCEN 79
- ZEXT 81
- ZHGT 80
- ZIN 79
- ZLAST 81
- ZNAME 81
- Zoom Center command 79
- zoom commands 72, 77–82
- Zoom Extents command 81
- Zoom Height command 80
- Zoom In command 79
- Zoom Last command 81
- Zoom Named command 81
- Zoom Out command 79
- Zoom Text command 82
- Zoom Width command 80
- Zoom Window command 78
- zooming
 - by window 78
 - multiple drawing windows 20
 - out (shrink) 79
 - pan 78
 - to a specified height 80
 - to a specified width 80
 - to previous view 81
- ZOUT 79
- ZTEXT 82
- ZWID 80
- ZWIN 78